# MS410 Series

## User's Guide

**September 2012** **www.lexmark.com**

Machine type(s):

4514

Model(s):

420, 430

# Contents


## Safety information.....5

## Learning about the printer.....7

Finding information about the printer.....7
Selecting a location for the printer.....8
Printer configurations.....9
Using the printer control panel.....11
Understanding the colors of the Sleep button and indicator lights.....12
Using the Embedded Web Server.....12
Using the Local Printer Settings Utility.....13

## Additional printer setup.....14

Installing internal options.....14
Installing hardware options.....19
Attaching cables.....20
Setting up the printer software.....21
Networking.....24
Verifying printer setup.....29

## Loading paper and specialty media.....31

Setting the paper size and type.....31
Configuring Universal paper settings.....31
Using the standard bin and paper stop.....32
Loading trays.....32
Loading the multipurpose feeder.....37
Linking and unlinking trays.....40

## Paper and specialty media guide.....43

Paper guidelines.....43
Using specialty media.....46
Storing paper.....48
Supported paper sizes, types, and weights.....49

## Printing.....52

Printing a document.....52

Printing information pages....53
Canceling a print job....53

**Understanding the printer menus....55**

Menus list....55
Paper menu....55
Reports menu....64
Network/Ports menu....65
Security menu....72
Settings menu....74

**Saving money and the environment....85**

Saving paper and toner....85
Saving energy....86
Recycling....89

**Securing the printer....90**

Using the security lock feature....90
Statement of Volatility....90
Erasing volatile memory....91
Erasing non-volatile memory....91
Finding printer security information....91

**Maintaining the printer....92**

Cleaning the printer....92
Checking the status of parts and supplies....92
Estimated number of remaining pages....93
Ordering supplies....93
Storing supplies....95
Replacing supplies....96
Moving the printer....99

**Managing the printer....101**

Finding advanced networking and administrator information....101
Checking the virtual display....101
Viewing reports....101
Configuring supply notifications from the Embedded Web Server....101
Modifying confidential print settings....102

Copying printer settings to other printers....103
Restoring factory default settings....103
Creating a printer control panel PIN....103

**Clearing jams....105**

Avoiding jams....105
Understanding jam messages and locations....106
Jam, front door [20y.xx]....108
Jam, rear door [20y.xx]....111
Jam, standard bin [20y.xx]....112
Jam, pull tray 1. Push down blue flap. [23y.xx]....113
Jam, tray [x] [24y.xx]....114
Jam, MP feeder [250.xx]....115

**Troubleshooting....116**

Understanding the printer messages....116
Solving printer problems....125
Solving print problems....131
Embedded Web Server does not open....153
Contacting customer support....154

**Notices....155**

Product information....155
Edition notice....155
Power consumption....159

**Index....167**

# Safety information

Connect the power cord to a properly grounded electrical outlet that is near the product and easily accessible.

Do not place or use this product near water or wet locations.

**CAUTION—POTENTIAL INJURY:** This product uses a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

This product uses a printing process that heats the print media, and the heat may cause the media to release emissions. You must understand the section in your operating instructions that discusses the guidelines for selecting print media to avoid the possibility of harmful emissions.

**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

**CAUTION—POTENTIAL INJURY:** The lithium battery in this product is not intended to be replaced. There is a danger of explosion if a lithium battery is incorrectly replaced. Do not recharge, disassemble, or incinerate a lithium battery. Discard used lithium batteries according to the manufacturer's instructions and local regulations.

**CAUTION—POTENTIAL INJURY:** Before moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Turn the printer off using the power switch, and then unplug the power cord from the electrical outlet.
- Disconnect all cords and cables from the printer before moving it.
- If an optional tray is installed, then remove it from the printer. To remove the optional tray, slide the latch on the right side of the tray toward the front of the tray until it *clicks* into place.
- Use the handholds located on both sides of the printer to lift it.
- Make sure your fingers are not under the printer when you set it down.
- Before setting up the printer, make sure there is adequate clearance around it.

Use only the power cord provided with this product or the manufacturer's authorized replacement.

**CAUTION—SHOCK HAZARD:** If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

**CAUTION—SHOCK HAZARD:** Make sure that all external connections (such as Ethernet and telephone system connections) are properly installed in their marked plug-in ports.

This product is designed, tested, and approved to meet strict global safety standards with the use of specific manufacturer's components. The safety features of some parts may not always be obvious. The manufacturer is not responsible for the use of other replacement parts.

**CAUTION—POTENTIAL INJURY:** Do not cut, twist, bind, crush, or place heavy objects on the power cord. Do not subject the power cord to abrasion or stress. Do not pinch the power cord between objects such as furniture and walls. If any of these things happen, a risk of fire or electrical shock results. Inspect the power cord regularly for signs of such problems. Remove the power cord from the electrical outlet before inspecting it.

Refer service or repairs, other than those described in the user documentation, to a service representative.

**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock when cleaning the exterior of the printer, unplug the power cord from the electrical outlet and disconnect all cables from the printer before proceeding.

**CAUTION—POTENTIAL INJURY:** To reduce the risk of equipment instability, load each tray separately. Keep all other trays closed until needed.

**CAUTION—SHOCK HAZARD:** Do not set up this product or make any electrical or cabling connections, such as the fax feature, power cord, or telephone, during a lightning storm.

**SAVE THESE INSTRUCTIONS.**

# Learning about the printer

## Finding information about the printer

| What are you looking for? | Find it here |
|---|---|
| Initial setup instructions:<br>• Connecting the printer<br>• Installing the printer software | Setup documentation—The setup documentation came with the printer and is also available on the Lexmark Web site at http://support.lexmark.com. |
| Additional setup and instructions for using the printer:<br>• Selecting and storing paper and specialty media<br>• Loading paper<br>• Configuring printer settings<br>• Viewing and printing documents and photos<br>• Setting up and using the printer software<br>• Configuring the printer on a network<br>• Caring for and maintaining the printer<br>• Troubleshooting and solving problems | *User's Guide* and *Quick Reference Guide*—The guides are available on the *Software and Documentation* CD.<br>For updates, visit our Web site at http://support.lexmark.com. |
| Instructions for:<br>• Connecting the printer to an Ethernet network<br>• Troubleshooting printer connection problems | *Networking Guide*—Open the *Software and Documentation* CD, and then look for *Printer and Software Documentation* under the Pubs folder. From the list of publications, click the **Networking Guide** link. |
| Help using the printer software | Windows or Mac Help—Open a printer software program or application, and then click **Help**.<br>Click to view context-sensitive information.<br>**Notes:**<br>• Help is automatically installed with the printer software.<br>• The printer software is located in the printer program folder or on the desktop, depending on your operating system. |

| What are you looking for? | Find it here |
|---|---|
| The latest supplemental information, updates, and customer support:<br>• Documentation<br>• Driver downloads<br>• Live chat support<br>• E-mail support<br>• Voice support | Lexmark Support Web site—**http://support.lexmark.com**<br>**Note:** Select your country or region, and then select your product to view the appropriate support site.<br>Support telephone numbers and hours of operation for your country or region can be found on the Support Web site or on the printed warranty that came with your printer.<br>Record the following information (located on the store receipt and at the back of the printer), and have it ready when you contact customer support so that they may serve you faster:<br>• Machine Type number<br>• Serial number<br>• Date purchased<br>• Store where purchased |
| Warranty information | Warranty information varies by country or region:<br>• **In the US**—See the Statement of Limited Warranty included with this printer, or at **http://support.lexmark.com**.<br>• **In other countries and regions**—See the printed warranty that came with your printer. |

# Selecting a location for the printer

When selecting a location for the printer, leave enough room to open trays, covers, and doors. If you plan to install any hardware options, then leave enough room for them also. It is important to:

- Set up the printer near a properly grounded and easily accessible electrical outlet.
- Make sure airflow in the room meets the latest revision of the ASHRAE 62 standard or the CEN Technical Committee 156 standard.
- Provide a flat, sturdy, and stable surface.
- Keep the printer:
  - Clean, dry, and free of dust.
  - Away from stray staples and paper clips.
  - Away from the direct airflow of air conditioners, heaters, or ventilators.
  - Free from direct sunlight and humidity extremes.
- Observe the recommended temperatures and avoid fluctuations.

| | |
|---|---|
| Ambient temperature | 16 to 32°C (60 to 90°F) |
| Storage temperature | -20 to 40°C (-4 to 104°F) |

- Allow the following recommended amount of space around the printer for proper ventilation:




| | | |
|---|---|---|
| **1** | Right side | 305 mm (12 in.) |
| **2** | Front | 510 mm (20 in.) |
| **3** | Left side | 205 mm (8 in.) |
| **4** | Rear | 205 mm (8 in.) |
| **5** | Top | 305 mm (12 in.) |

# Printer configurations

**CAUTION—POTENTIAL INJURY:** To reduce the risk of equipment instability, load each tray separately. Keep all other trays closed until needed.

You can configure your printer by adding one optional 250- or 550-sheet tray. For instructions on installing the optional tray, see “Installing optional trays” on page 19.




| | |
|---|---|
| **1** | Printer control panel |
| **2** | Paper stop |
| **3** | Standard bin |
| **4** | Front door release button |
| **5** | Controller board access door |
| **6** | Standard 250-sheet tray |
| **7** | Optional 250- or 550-sheet tray |
| **8** | 50-sheet multipurpose feeder |
| **9** | Front door |

# Using the printer control panel




| | Use the | To |
|---|---|---|
| **1** | Menus button | Open the menus.<br>**Notes:**<br>• The menus are available only when the printer is in the Ready state.<br>• Pressing the button while navigating within the menus returns the printer control panel to the top-level menu screen. |
| **2** | Display | View printing options as well as status and error messages. |
| **3** | Sleep button | Enable Sleep mode or Hibernate mode.<br>**Notes:**<br>• Pressing any hard button will cause the printer to wake from Sleep mode.<br>• Pressing the Sleep button or the power switch will cause the printer to wake from Hibernate mode. |
| **4** | Stop button | • Exit the menus and return to the Ready state.<br>• Stop printer activities, such as printing or downloading fonts. |
| **5** | Right arrow button | • Scroll through menus or to move between screens and menu options.<br>• Scroll through settings or text. For menus with numeric values, press and hold an arrow button to scroll through the settings. Release the button when the value you want appears. |
| **6** | Select button | • Open a menu.<br>• Display available values or settings for a menu. The current default setting is indicated by an asterisk (*).<br>• Save the displayed value as the new user default setting. |
| **7** | Left arrow button | • Scroll through menus or to move between screens and menu options.<br>• Scroll through settings or text. For menus with numeric values, press and hold an arrow button to scroll through the settings. Release the button when the value you want appears. |
| **8** | Back button | Return to the previous screen. |

| | Use the | To |
|---|---|---|
| 9 | Indicator light | Determine the status of the printer. |

# Understanding the colors of the Sleep button and indicator lights

The colors of the Sleep button and indicator lights on the printer control panel signify a certain printer status or condition.

### Indicator light color and its corresponding printer status

| Indicator light | Printer status |
|---|---|
| Off | The printer is off or in Hibernate mode. |
| Blinking green | The printer is warming up, processing data, or printing. |
| Solid green | The printer is on, but idle. |
| Blinking red | The printer requires user intervention. |

### Sleep button light color and its corresponding printer status

| Sleep button light | Printer status |
|---|---|
| Off | The printer is off, idle or in Ready state. |
| Solid amber | The printer is in Sleep mode. |
| Blinking amber | The printer is entering or waking from Hibernate mode. |
| Blinking amber for 0.1 second, then goes completely off for 1.9 seconds in a slow, pulsing pattern | The printer is in Hibernate mode. |

# Using the Embedded Web Server

**Note:** This feature is available only in network printers or printers connected to print servers.

If the printer is installed on a network, then you can use the Embedded Web Server to do the following:

- View the virtual display of the printer control panel.
- Check the status of the printer supplies.
- Configure supply notifications.
- Configure printer settings.
- Configure network settings.
- View reports.

To access the Embedded Web Server for your printer:

1. Obtain the printer IP address:
   - From the TCP/IP section in the Network/Ports menu
   - By printing a network setup page or menu settings page, and then finding the TCP/IP section

**Notes:**

- An IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Open a Web browser, and then type the printer IP address in the address field.
3. Press **Enter**.

   The Embedded Web Server page appears.

# Using the Local Printer Settings Utility

The Local Printer Settings Utility lets you change and save settings for a printer that is connected to a computer locally through a USB or parallel cable.

To download and install the Local Printer Settings Utility, see “Installing the Local Printer Settings Utility” on page 22.

To access the Local Printer Settings Utility:

1. Click or **Start**.
2. Click **Programs** > **Lexmark** > **Local Printer Settings Utility**.

To save your settings, click **Actions** > **Apply Settings**.

You can also distribute your settings to other printers by saving the settings in a command file. To save your settings in a command file, click **Actions** > **Save As Command File**.

# Additional printer setup

## Installing internal options

**CAUTION—SHOCK HAZARD:** If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

### Available internal options

#### Memory cards

- Printer memory
- Flash memory
- Fonts

**Note:** Some internal options are available only in select printer models.

### Accessing the controller board

**CAUTION—SHOCK HAZARD:** If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

1 Open the controller board access door.



2 Use the following illustration to locate the appropriate connector.

**Warning—Potential Damage:** Controller board electronic components are easily damaged by static electricity. Touch a metal surface on the printer before touching any controller board electronic components or connectors.




| | |
|---|---|
| 1 | Memory card connector |
| 2 | Option card connector |

## Installing a memory card

**CAUTION—SHOCK HAZARD:** If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

**Warning—Potential Damage:** Controller board electronic components are easily damaged by static electricity. Touch a metal surface on the printer before touching any controller board electronic components or connectors.

An optional memory card can be purchased separately and attached to the controller board.

1. Access the controller board.

   For more information, see “Accessing the controller board” on page 14.

2. Unpack the memory card.

   **Warning—Potential Damage:** Do not touch the connection points along the edge of the card. Doing so may cause damage.

**3** Align the notch (1) on the memory card with the ridge (2) on the connector.




**4** Push the memory card straight into the connector, and then push the card toward the controller board wall until it *clicks* into place.




**5** Close the controller board access door.

**Note:** When the printer software and any hardware options are installed, it may be necessary to manually add the options in the printer driver to make them available for print jobs. For more information, see “Updating available options in the printer driver” on page 22.

## Installing an optional card

**CAUTION—SHOCK HAZARD:** If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

**Warning—Potential Damage:** Controller board electronic components are easily damaged by static electricity. Touch a metal surface on the printer before touching any controller board electronic components or connectors.

1. Access the controller board.

   For more information, see “Accessing the controller board” on page 14.

2. Unpack the optional card.

   **Warning—Potential Damage:** Avoid touching the connection points along the edge of the card.

3. Holding the card by its sides, align the plastic pins (1) on the card with the holes (2) on the controller board.



**4** Push the card firmly into place as shown in the illustration.



**Warning—Potential Damage:** Improper installation of the card may cause damage to the card and the controller board.

**Note:** The entire length of the connector on the card must touch and be flushed against the controller board.

**5** Close the controller board access door.

**Note:** When the printer software and any hardware options are installed, it may be necessary to manually add the options in the printer driver to make them available for print jobs. For more information, see “Updating available options in the printer driver” on page 22.

# Installing hardware options

## Installing optional trays

**CAUTION—SHOCK HAZARD:** If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

1 Turn off the printer using the power switch, and then unplug the power cord from the electrical outlet.






2 Unpack the tray, and then remove any packing material.

3 Remove the tray from the base.



4 Remove any packing material from inside the tray.

5 Insert the tray into the base.

6 Place the tray near the printer.

**7** Align the printer with the tray, and then slowly lower the printer into place.



**8** Connect the power cord to the printer, then to a properly grounded electrical outlet, and then turn on the printer.






**Note:** When the printer software and any hardware options are installed, it may be necessary to manually add the options in the printer driver to make them available for print jobs. For more information, see “Updating available options in the printer driver” on page 22.

# Attaching cables

Connect the printer to the computer using a USB or parallel cable, or to the network using an Ethernet cable.

Make sure to match the following:

- The USB symbol on the cable with the USB symbol on the printer
- The appropriate parallel cable with the parallel port

- The appropriate Ethernet cable with the Ethernet port

**Warning—Potential Damage:** Do not touch the USB cable, any network adapter, or the printer in the area shown while actively printing. Loss of data or a malfunction can occur.




| | Use the | To |
|---|---|---|
| **1** | USB port* | Attach an optional wireless network adapter. |
| **2** | USB printer port | Connect the printer to a computer. |
| **3** | Ethernet port* | Connect the printer to a network. |
| **4** | Parallel port* | Connect the printer to a computer. |
| **5** | Power switch | Turn on or turn off the printer. |
| **6** | Printer power cord socket | Connect the printer to an electrical outlet. |
| **7** | Security slot | Attach a lock that will secure the printer in place. |

* These ports are available only in select printer models.

# Setting up the printer software

## Installing the printer software

**Notes:**

- If you installed the printer software on the computer before but need to reinstall the software, then uninstall the current software first.
- Close all open software programs before installing the printer software.

1. Obtain a copy of the software installer package.
   - From the *Software and Documentation* CD that came with your printer.
   - From our Web site:
     Go to **http://support.lexmark.com**, and then navigate to:
     **SUPPORT & DOWNLOAD** > select your printer > select your operating system
2. Double-click the software installer package.
   Wait for the installation dialog to appear.
   If you are using a *Software and Documentation* CD and the installation dialog does not appear, then do the following:

   **In Windows 8**

   From the Search charm, type **`run`**, and then navigate to:
   Apps list > **Run** > type **`D:\setup.exe`** > **OK**.

   **In Windows 7 or earlier**

   a. Click or click **Start**, and then click **Run**.
   b. In the Start Search or Run dialog, type **`D:\setup.exe`**.
   c. Press **Enter**, or click **OK**.

   **In Macintosh**

   Click the CD icon on the desktop.

   **Note:** **`D`** is the letter of your CD or DVD drive.
3. Click **Install**, and then follow the instructions on the computer screen.

## Installing the Local Printer Settings Utility

1. Visit **http://support.lexmark.com**, and then download the software.
2. Double-click the software installer package.
3. Select an installation type, and then click **Install**.
4. Click **Install** to start the installation.
5. Click **Agree** to accept the license agreement.
6. Click **Continue**, and then follow the instructions on the computer screen.

**Notes:**

- Use the Local Printer Settings Utility to change the toner darkness, power saver, and paper size settings for all print jobs. Use the printer software to change these settings for individual print jobs.
- This utility is supported only in select printer models.

## Updating available options in the printer driver

When any hardware options are installed, you may need to manually add the options in the printer driver to make them available for use.

## For Windows users

1. Open the printers folder.

   **In Windows 8**

   From the Search charm, type **`run`**, and then navigate to:

   Apps list > **Run** > type **`control printers`** > **OK**

   **In Windows 7 or earlier**

   a. Click or click **Start**, and then click **Run**.

   b. In the Start Search or Run dialog, type **`control printers`**.

   c. Press **Enter**, or click **OK**.

2. Depending on your device, do either of the following:
   - Press and hold the printer you want to update.
   - Right-click the printer you want to update.

3. From the menu that appears, do either of the following:
   - For Windows 7 or later, select **Printer properties**.
   - For earlier versions, select **Properties**.

4. Click the **Configuration** tab.

5. Do either of the following:
   - Click **Update Now - Ask Printer**.
   - Under Configuration Options, manually add any installed hardware options.

6. Click **Apply**.

## For Macintosh users

1. From the Apple menu, navigate to either of the following:
   - **System Preferences** > **Print & Scan** > select your printer > **Options & Supplies** > **Driver**
   - **System Preferences** > **Print & Fax** > select your printer > **Options & Supplies** > **Driver**

2. Add any installed hardware options, and then click **OK**.

# Networking

**Notes:**

- Purchase a MarkNet™ N8352 wireless network adapter first before setting up the printer on a wireless network. For information on installing the wireless network adapter, see the instruction sheet that came with the adapter.
- A *Service Set Identifier* (SSID) is a name assigned to a wireless network. Wired Equivalent Privacy (WEP), Wi-Fi Protected Access (WPA), WPA2, and 802.1X - RADIUS are types of security used on a network.

## Preparing to set up the printer on an Ethernet network

To configure your printer to connect to an Ethernet network, organize the following information before you begin:

**Note:** If your network automatically assigns IP addresses to computers and printers, continue on to installing the printer.

- A valid, unique IP address for the printer to use on the network
- The network gateway
- The network mask
- A nickname for the printer (optional)

  **Note:** A printer nickname can make it easier for you to identify your printer on the network. You can choose to use the default printer nickname, or assign a name that is easier for you to remember.

You will need an Ethernet cable to connect the printer to the network and an available port where the printer can physically connect to the network. Use a new network cable when possible to avoid potential problems caused by a damaged cable.

## Installing the printer on an Ethernet network

### For Windows users

1. Obtain a copy of the software installer package.
   - From the *Software and Documentation* CD that came with your printer.
   - From our Web site:
     Go to **http://support.lexmark.com**, and then navigate to:
     **SUPPORT & DOWNLOAD** > select your printer > select your operating system
2. Double-click the software installer package.

   Wait for the installation dialog to appear.

   If you are using the *Software and Documentation* CD and the installation dialog does not appear, then do the following:

   **In Windows 8**

   From the Search charm, type **`run`**, and then navigate to:

   Apps list > **Run** > type: **`D:\setup.exe`** > **OK**

**In Windows 7 or earlier**

a Click or click **Start**, and then click **Run**.

b In the Start Search or Run dialog, type `D:\setup.exe`.

c Press **Enter**, or click **OK**.

**Note:** `D` is the letter of your CD or DVD drive.

3 Click **Install**, and then follow the instructions on the computer screen.

4 Select **Ethernet connection**, and then click **Continue**.

5 Attach the Ethernet cable when instructed to do so.

6 Select the printer from the list, and then click **Continue**.

**Note:** If the configured printer does not appear in the list, then click **Modify Search**.

7 Follow the instructions on the computer screen.

### For Macintosh users

1 Allow the network DHCP server to assign an IP address to the printer.

2 Obtain the printer IP address either:

- From the printer control panel
- From the TCP/IP section in the Network/Ports menu
- By printing a network setup page or menu settings page, and then finding the TCP/IP section

**Note:** You will need the IP address if you are configuring access for computers on a different subnet than the printer.

3 Install the printer driver on the computer.

a Insert the *Software and Documentation* CD, and then double-click the installer package for the printer.

b Follow the instructions on the computer screen.

c Select a destination, and then click **Continue**.

d From the Easy Install screen, click **Install**.

e Type the user password, and then click **OK**.
All the necessary applications are installed on the computer.

f Click **Close** when installation is complete.

4 Add the printer.

- For IP printing:
  a From the Apple menu, navigate to either of the following:
    – **System Preferences** > **Print & Scan**
    – **System Preferences** > **Print & Fax**
  b Click **+**.
  c Click the **IP** tab.
  d Type the printer IP address in the address field, and then click **Add**.
- For AppleTalk printing:

  **Notes:**

  – Make sure AppleTalk is activated on your printer.

- This feature is supported only in Mac OS X version 10.5.

a From the Apple menu, navigate to:
**System Preferences** > **Print & Fax**

b Click **+**, and then navigate to:
**AppleTalk** > select your printer > **Add**

## Preparing to set up the printer on a wireless network

**Notes:**

- Make sure your wireless network adapter is installed in your printer and working properly.
- Make sure your access point (wireless router) is turned on and is working properly.

Make sure you have the following information before setting up the printer on a wireless network:

- **SSID**—The SSID is also referred to as the network name.
- **Wireless Mode (or Network Mode)**—The mode is either infrastructure or ad hoc.
- **Channel (for ad hoc networks)**—The channel defaults to automatic for infrastructure networks.

  Some ad hoc networks will also require the automatic setting. Check with your system support person if you are not sure which channel to select.
- **Security Method**—There are three basic options for Security Method:
  - WEP key

    If your network uses more than one WEP key, then enter up to four in the provided spaces. Select the key currently in use on the network by selecting the default WEP transmit key.

    *or*
  - WPA or WPA2 preshared key or passphrase

    WPA includes encryption as an additional layer of security. The choices are AES or TKIP. Encryption must be set for the same type on the router and on the printer, or the printer will not be able to communicate on the network.
  - 802.1X–RADIUS

    If you are installing the printer on an 802.1X network, then you may need the following:
    - Authentication type
    - Inner authentication type
    - 802.1X user name and password
    - Certificates
  - No security

    If your wireless network does not use any type of security, then you will not have any security information.

    **Note:** Using an unsecured wireless network is not recommended.

**Notes:**

- If you do not know the SSID of the network that your computer is connected to, then launch the wireless utility of the computer network adapter, and then look for the network name. If you cannot find the SSID or the security information for your network, then see the documentation that came with the access point, or contact your system support person.

– To find the WPA/WPA2 preshared key/passphrase for the wireless network, see the documentation that came with the access point, see the Web page associated with the access point, or consult your system support person.

## Connecting the printer to a wireless network using Wi-Fi Protected Setup

Before connecting the printer to a wireless network, make sure that:

- The access point (wireless router) is Wi-Fi Protected Setup (WPS) certified or WPS-compatible. For more information, see the documentation that came with your access point.
- A wireless network adapter installed in your printer is attached and working properly. For more information, see the instruction sheet that came with the wireless network adapter.

### Using the Push Button Configuration method

1. From the printer control panel, navigate to:

   > **Network/Ports** > OK > **Network [x]** > OK > **Network [x] Setup** > OK > **Wireless** > OK > **Wi-Fi Protected Setup** > OK > **Start Push Button Method** > OK

2. Follow the instructions on the printer display.

### Using the Personal Identification Number (PIN) method

1. From the printer control panel, navigate to:

   > **Network/Ports** > OK > **Network [x]** > OK > **Network [x] Setup** > OK > **Wireless** > OK > **Wi-Fi Protected Setup** > OK > **Start PIN Method** > OK

2. Copy the eight-digit WPS PIN.
3. Open a Web browser, and then type the IP address of your access point in the address field.

   **Notes:**

   - The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

4. Access the WPS settings. For more information, see the documentation that came with your access point.
5. Enter the eight-digit PIN, and then save the setting.

## Connecting the printer to a wireless network using the printer software

### Using the Wireless Setup Utility (Windows only)

The Wireless Setup Utility lets you:

- Configure the printer to join an existing wireless network.
- Add a printer to an existing ad hoc network.
- Change the wireless settings after installation.
- Install the printer on additional network computers.

### Installing the Wireless Setup Utility

1. Go to the Lexmark Web site at **http://support.lexmark.com**.
2. Download the latest Wireless Setup Utility.
3. Double-click the downloaded software installer package.
4. Follow the instructions on the computer screen.

### Launching the Wireless Setup Utility

**Notes:**

- Make sure the printer is turned on.
- Make sure a wireless network adapter installed in your printer is attached and working properly.

1. Run the utility.

   **In Windows 8**

   From the Search charm, type **`Printer Home`**, and then navigate to:

   Apps list > **Printer Home** > **Settings** > **Wireless Setup Utility**

   **In Windows 7 or earlier**

   a. Click or **Start**.

   b. Click **All Programs** or **Programs**, and then select the printer program folder from the list.

   c. Select your printer, and then navigate to:
   **Printer Home** > **Settings** > **Wireless Setup Utility**

2. Follow the instructions on the computer screen.

## Using the Wireless Setup Assistant (Macintosh only)

The Wireless Setup Assistant lets you:

- Configure the printer to join an existing wireless network.
- Add a printer to an existing ad hoc network.
- Change the wireless settings after installation.
- Install the printer on additional network computers.

### Installing the Wireless Setup Assistant

1. Go to the Lexmark Web site at **http://support.lexmark.com**.
2. Download the latest Wireless Setup Assistant application.
3. Double-click the downloaded software installer package.
4. Follow the instructions on the computer screen.

### Launching the Wireless Setup Assistant

**Notes:**

- Make sure the printer is turned on.

- Make sure a wireless network adapter installed in your printer is attached and working properly.

1 From the Finder, navigate to:

**Applications** > select your printer folder

2 Double-click **Wireless Setup Assistant**, and then follow the instructions on the computer screen.

**Note:** If you encounter problems while running the application, then click ?.

### Connecting the printer to a wireless network using the Embedded Web Server

Before you begin, make sure that:

- Your printer is connected temporarily to an Ethernet network.
- A wireless network adapter is installed in your printer and working properly. For more information, see the instruction sheet that came with your wireless network adapter.

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**

- View the printer IP address on the printer control panel. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Network/Ports** > **Wireless**.

3 Modify the settings to match the settings of your access point (wireless router).

**Note:** Make sure to enter the correct SSID.

4 Click **Submit**.

5 Turn off the printer, and then disconnect the Ethernet cable. Then wait for at least five seconds, and then turn the printer back on.

6 To verify if your printer is connected to the network, print a network setup page. Then in the Network Card [x] section, see if the status is Connected.

## Verifying printer setup

### Printing a menu settings page

Print a menu settings page to review the current menu settings and to verify if the printer options are installed correctly.

**Note:** If you have not changed any menu settings, then the menu settings page lists all the factory default settings. When you select and save other settings from the menus, they replace the factory default settings as *user default settings*. A user default setting remains in effect until you access the menu again, choose another value, and save it.

From the printer control panel, navigate to:

> **Reports** > OK > **Menu Settings Page** > OK

## Printing a network setup page

If the printer is connected to a network, then print a network setup page to verify the network connection. This page also provides important information that aids network printing configuration.

1 From the printer control panel, navigate to:

> **Reports** > > **Network Setup Page** >

**Note:** If an optional print server is installed, then **`Print Network [x] Setup Page`** appears.

2 Check the first section of the network setup page and confirm that the status is Connected.

If the status is Not Connected, then the LAN drop may not be active, or the network cable may be malfunctioning. Consult your system support person for a solution, and then print another network setup page.

# Loading paper and specialty media

The selection and handling of paper and specialty media can affect how reliably documents print. For more information, see “Avoiding jams” on page 105 and “Storing paper” on page 48.

## Setting the paper size and type

1 From the printer control panel, navigate to:

> **Paper Menu** > OK > **Paper Size/Type** > OK

2 Select **Tray [x] Size** or **Tray [x] Type**, and then press OK.

3 Change the paper size or type setting, and then press OK.

**Notes:**

- The paper size setting for the standard 250-sheet tray (Tray 1), optional 250- or 550-sheet tray (Tray 2), and the multipurpose feeder must be set manually in the Paper Size menu.
- The factory default paper type for Tray 1 is Plain Paper.
- The factory default paper type for the multipurpose feeder is Custom Type 6.
- The paper type setting must be manually set for all trays.

## Configuring Universal paper settings

The Universal paper size is a user-defined setting that lets you print on paper sizes that are not preset in the printer menus.

**Notes:**

- The largest supported Universal size is 216 x 355.6 mm (8.5 x 14 inches).
- The smallest Universal size supported in the multipurpose feeder is 76 x 127 mm (3 x 5 inches). The smallest Universal size supported in the optional tray is 183 x 210 mm (7.2 x 8.3 inches).

From the printer control panel, navigate to:

> **Paper Menu** > OK > **Universal Setup** > OK > **Units of Measure** > OK > select the unit of measure > OK

### Specify the paper height and width

1 From the printer control panel, navigate to:

> **Paper Menu** > OK > **Universal Setup** > OK > **Units of Measure** > OK > select the unit of measure > OK

2 Press the arrow buttons until **`Portrait Height`** or **`Portrait Width`** appears, and then press OK.

3 Change the settings, and then press OK.

# Using the standard bin and paper stop

The standard bin holds up to 150 sheets of 20-lb paper. It collects prints facedown. The standard bin includes a paper stop that keeps paper from sliding out the front of the bin as it stacks.

To open the paper stop, pull it so that it flips forward.

**Note:** Close the paper stop when moving the printer to another location.

# Loading trays

**CAUTION—POTENTIAL INJURY:** To reduce the risk of equipment instability, load each tray separately. Keep all other trays closed until needed.

1 Pull out the tray completely.

**Note:** Do not remove trays while a job prints or while **Busy** appears on the printer display. Doing so may cause a jam.

**2** Squeeze and then slide the width guide tab to the correct position for the size of the paper you are loading.



**3** Squeeze and then slide the length guide tab to the correct position for the size of the paper you are loading.




**Notes:**

- For some paper sizes like letter, legal, and A4, squeeze and slide the length guide tab backward to accommodate their length.
- When loading legal-size paper, the length guide extends beyond the base leaving the paper exposed to dust. To protect the paper from dust, you can purchase a dust cover separately. For more information, contact customer support.
- If you are loading A6-size paper in the standard tray, then squeeze and then slide the length guide tab toward the center of the tray to the A6-size position.
- Make sure the width and length guides are aligned with the paper size indicators on the bottom of the tray.




**4** Flex the sheets back and forth to loosen them, and then fan them. Do not fold or crease the paper. Straighten the edges on a level surface.



**5** Load the paper stack.



**Notes:**

- Load with the printable side facedown when using recycled or preprinted paper.
- Load prepunched paper with the holes on the top edge toward the front of the tray.

- Load letterhead facedown, with the top edge of the sheet toward the front of the tray. For two-sided printing, load letterhead faceup with the bottom edge of the sheet toward the front of the tray.
- Make sure the paper is below the maximum paper fill indicator located on the side of the width guide.



**6** Insert the tray.

**7** From the printer control panel, set the paper size and paper type in the Paper menu to match the paper loaded in the tray.

**Note:** Set the correct paper size and type to avoid paper jams and print quality problems.

# Loading the multipurpose feeder

Use the multipurpose feeder when printing on different paper sizes and types or specialty media, such as card stock, transparencies, paper labels, and envelopes. You can also use it for single-page print jobs on letterhead.

**1** Open the multipurpose feeder.




**a** Pull the multipurpose feeder extender.

**b** Pull the extender gently so that the multipurpose feeder is fully extended and open.

**2** Squeeze the tab on the left width guide, and then move the guides for the paper you are loading.




**3** Prepare the paper or specialty media for loading.

- Flex sheets of paper back and forth to loosen them, and then fan them. Do not fold or crease the paper. Straighten the edges on a level surface.



- Hold transparencies by the edges. Flex the stack of transparencies back and forth to loosen them, and then fan them. Straighten the edges on a level surface.

  **Note:** Avoid touching the printable side of the transparencies. Be careful not to scratch them.



- Flex the stack of envelopes back and forth to loosen them, and then fan them. Straighten the edges on a level surface.

**4** Load the paper or specialty media.

**Notes:**

- Do not force paper or specialty media into the multipurpose feeder.

- Make sure the paper or specialty media is below the maximum paper fill indicator located on the paper guides. Overfilling may cause paper jams.



- Load paper, transparencies, and card stock with the recommended printable side faceup and the top edge entering the printer first. For more information on loading transparencies, see the packaging that the transparencies came in.

**Note:** When loading A6-size paper, make sure the multipurpose feeder extender rests lightly against the edge of the paper so that the last few sheets of paper remain in place.



- Load letterhead faceup with the top edge entering the printer first. For two-sided (duplex) printing, load letterhead facedown with the bottom edge entering the printer first.

- Load envelopes with the flap on the left side facedown.

**Warning—Potential Damage:** Never use envelopes with stamps, clasps, snaps, windows, coated linings, or self-stick adhesives. These envelopes may severely damage the printer.

5 From the printer control panel, set the paper size and paper type in the Paper menu to match the paper or specialty media loaded in the multipurpose feeder.

# Linking and unlinking trays

When the paper size and paper type for any trays are the same, the printer will link those trays. When one linked tray becomes empty, paper will feed from the next linked tray. It is recommended to give all unique paper, such as letterhead and different colored plain papers, a different custom type name so that the trays they are in will not automatically link.

## Linking and unlinking trays

### Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**

- View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Paper Menu**.

3 Change the tray settings to specify the paper size and type for the tray.
- To link trays, make sure the paper size and type for the tray match with that of the other tray.
- To unlink trays, make sure the paper size or type for the tray does *not* match with that of the other tray.

4 Click **Submit**.

### Using the printer settings on the computer

Depending on your operating system, access the Paper menu using the Local Printer Settings Utility or Printer Settings.

**Note:** You can also specify the paper size and type for the tray using the printer control panel. For more information, see “Setting the paper size and type” on page 31.

**Warning—Potential Damage:** Paper loaded in the tray should match the paper type name assigned in the printer. The temperature of the fuser varies according to the specified paper type. Printing issues may occur if settings are not properly configured.

## Configuring a custom paper type name

### Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**

- Print a network setup page or menu settings page, and then locate the IP address in the TCP/IP section. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Paper Menu** > **Custom Names**.

3 Select a custom name, and then type a new custom paper type name.

4 Click **Submit**.

5 Click **Custom Types**, and then verify if the new custom paper type name has replaced the custom name.

### Using the printer settings on the computer (Windows only)

Access the Custom menu using the Local Printer Settings Utility.

## Configuring a custom paper type

### Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**

- Print a network setup page or menu settings page, and then locate the IP address in TCP/IP section. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Paper Menu** > **Custom Types**.

3 Select a custom paper type name, and then select a custom paper type.

**Note:** Plain Paper is the factory default paper type for all user-defined custom names.

4 Click **Submit**.

### Using the printer settings on the computer

Depending on your operating system, access the Custom menu using the Local Printer Settings Utility or Printer Settings.

## Assigning a custom paper type

### Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**

- Print a network setup page or menu settings page, and then locate the IP address in the TCP/IP section. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Paper Menu**.

3 From the Tray Configuration section, select a paper source, and then select a custom paper type under the paper type column.

4 Click **Submit**.

### Using the printer settings on the computer

Depending on your operating system, access the Paper menu using the Local Printer Settings Utility or Printer Settings.

# Paper and specialty media guide

Additional information for printing on specialty media may be found in the *Card Stock and Label Guide* available at **http://support.lexmark.com**.

## Paper guidelines

Selecting the correct paper or specialty media reduces printing problems. For the best print quality, try a sample of the paper or specialty media before buying large quantities.

### Paper characteristics

The following paper characteristics affect print quality and reliability. Consider these characteristics when evaluating new paper stock.

#### Weight

The printer trays can automatically feed paper weights up to 120-g/$m^2$ (32-lb) bond grain long paper. The multipurpose feeder can automatically feed paper weights up to 163-g/$m^2$ (43-lb) bond grain long paper. Paper lighter than 60 g/$m^2$ (16 lb) might not be stiff enough to feed properly, causing jams. For best performance, use 75-g/$m^2$ (20-lb) bond grain long paper. For paper smaller than 182 x 257 mm (7.2 x 10.1 inches), we recommended to use 90 g/$m^2$ (24 lb) or heavier paper.

**Note:** Two-sided printing is supported only for 60–90-g/$m^2$ (16–24-lb) bond paper.

#### Curl

Curl is the tendency for paper to curl at its edges. Excessive curl can cause paper feeding problems. Curl can occur after the paper passes through the printer, where it is exposed to high temperatures. Storing paper unwrapped in hot, humid, cold, or dry conditions, even in the trays, can contribute to paper curling prior to printing and can cause feeding problems.

#### Smoothness

Paper smoothness directly affects print quality. If paper is too rough, then toner cannot fuse to it properly. If paper is too smooth, then it can cause paper feeding or print quality issues. Always use paper between 100 and 300 Sheffield points; however, smoothness between 150 and 250 Sheffield points produces the best print quality.

#### Moisture content

The amount of moisture in paper affects both print quality and the ability of the printer to feed the paper correctly. Leave paper in its original wrapper until it is time to use it. This limits the exposure of paper to moisture changes that can degrade its performance.

Store paper in its original wrapper in the same environment as the printer for 24 to 48 hours before printing. Extend the time to several days if the storage or transportation environment is very different from the printer environment. Thick paper may also require a longer conditioning period.

### Grain direction

Grain refers to the alignment of the paper fibers in a sheet of paper. Grain is either *grain long*, running the length of the paper, or *grain short*, running the width of the paper.

For 60–90-g/m$^2$ (16–24-lb) bond paper, grain long paper is recommended.

### Fiber content

Most high-quality xerographic paper is made from 100% chemically treated pulped wood. This content provides the paper with a high degree of stability resulting in fewer paper feeding problems and better print quality. Paper containing fibers such as cotton can negatively affect paper handling.

## Unacceptable paper

The following paper types are not recommended for use with the printer:

- Chemically treated papers used to make copies without carbon paper, also known as carbonless papers, carbonless copy paper (CCP), or no carbon required (NCR) paper
- Preprinted papers with chemicals that may contaminate the printer
- Preprinted papers that can be affected by the temperature in the printer fuser
- Preprinted papers that require a registration (the precise print location on the page) less than ±2.5 mm (±0.10 inch), such as optical character recognition (OCR) forms

  In some cases, registration can be adjusted with a software application to successfully print on these forms:
- Coated papers (erasable bond), synthetic papers, thermal papers
- Rough-edged, rough or heavily textured surface papers, or curled papers
- Recycled papers that fail EN12281:2002 (European)
- Paper weighing less than 60 g/m$^2$ (16 lb)
- Multiple-part forms or documents

## Selecting paper

Using the appropriate paper prevents jams and helps ensure trouble-free printing.

To help avoid paper jams and poor print quality:

- *Always* use new, undamaged paper.
- Before loading paper, know the recommended printable side of the paper. This information is usually indicated on the paper package.
- *Do not* use paper that has been cut or trimmed by hand.
- *Do not* mix paper sizes, types, or weights in the same tray; mixing results in jams.
- *Do not* use coated papers unless they are specifically designed for electrophotographic printing.

## Selecting preprinted forms and letterhead

Use these guidelines when selecting preprinted forms and letterhead:

- Use grain long for 60 to 90 g/m$^2$ (16 to 24 lb) weight paper.
- Use only forms and letterhead printed using an offset lithographic or engraved printing process.

- Avoid papers with rough or heavily textured surfaces.

Use papers printed with heat-resistant inks designed for use in xerographic copiers. The ink must be able to withstand temperatures up to 230°C (446°F) without melting or releasing hazardous emissions. Use inks that are not affected by the resin in toner. Inks that are oxidation-set or oil-based generally meet these requirements; latex inks might not. When in doubt, contact the paper supplier.

Preprinted papers such as letterhead must be able to withstand temperatures up to 230°C (446°F) without melting or releasing hazardous emissions.

## Using recycled paper and other office papers

As an environmentally conscientious company, Lexmark supports the use of recycled paper produced specifically for use in laser (electrophotographic) printers.

While no blanket statement can be made that all recycled paper will feed well, Lexmark consistently tests papers that represent recycled cut size copier papers available on the global market. This scientific testing is conducted with rigor and discipline. Many factors are taken into consideration both separately and as a whole, including the following:

- Amount of post-consumer waste (Lexmark tests up to 100% post-consumer waste content.)
- Temperature and humidity conditions (Testing chambers simulate climates from all over the world.)
- Moisture content (Business papers should have low moisture: 4–5%.)
- Bending resistance and proper stiffness means optimum feeding through the printer.
- Thickness (impacts how much can be loaded into a tray)
- Surface roughness (measured in Sheffield units, impacts print clarity and how well toner fuses to the paper)
- Surface friction (determines how easily sheets can be separated)
- Grain and formation (impacts curling, which also influences the mechanics of how the paper behaves as it moves through the printer)
- Brightness and texture (look and feel)

Recycled papers are better than ever; however, the amount of recycled content in a paper affects the degree of control over foreign matter. And while recycled papers are one good path to printing in an environmentally responsible manner, they are not perfect. The energy required to de-ink and deal with additives such as colorants and “glue” often generates more carbon emissions than does normal paper production. However, using recycled papers enables better resource management overall.

Lexmark concerns itself with the responsible use of paper in general based on life cycle assessments of its products. To gain a better understanding of the impact of printers on the environment, the company commissioned a number of life cycle assessments and found that paper was identified as the primary contributor (up to 80%) of carbon emissions caused throughout the entire life of a device (from design to end-of-life). This is due to the energy-intensive manufacturing processes required to make paper.

Thus, Lexmark seeks to educate customers and partners on minimizing the impact of paper. Using recycled paper is one way. Eliminating excessive and unnecessary paper consumption is another. Lexmark is well-equipped to help customers minimize printing and copying waste. In addition, the company encourages purchasing paper from suppliers who demonstrate their commitment to sustainable forestry practices.

Lexmark does not endorse specific suppliers, although a converter's product list for special applications is maintained. However, the following paper choice guidelines will help alleviate the environmental impact of printing:

1. Minimize paper consumption.
2. Be selective about the origin of wood fiber. Buy from suppliers who carry certifications such as the Forestry Stewardship Council (FSC) or the Program for the Endorsement of Forest Certification (PEFC). These certifications guarantee that the paper manufacturer uses wood pulp from forestry operators that employ environmentally and socially responsible forest management and restoration practices.
3. Choose the most appropriate paper for printing needs: normal 75 or 80 g/m$^2$ certified paper, lower weight paper, or recycled paper.

### Unacceptable paper examples

Test results indicate that the following paper types are at risk for use with laser printers:

- Chemically treated papers used to make copies without carbon paper, also known as *carbonless papers*
- Preprinted papers with chemicals that may contaminate the printer
- Preprinted papers that can be affected by the temperature in the printer fuser
- Preprinted papers that require a registration (the precise location on the page) greater than ± 2.3 mm (± 0.9 in.), such as optical character recognition (OCR) forms. In some cases, registration can be adjusted with a software application to successfully print on these forms.)
- Coated papers (erasable bond), synthetic papers, thermal papers
- Rough-edged, rough or heavily textured surface papers or curled papers
- Recycled papers that fail EN12281:2002 (European testing)
- Paper weighing less than 60 g/m$^2$ (16 lb)
- Multiple part forms or documents

For more information about Lexmark, visit **www.lexmark.com**. General sustainability-related information can be found at the **Environmental Sustainability** link.

# Using specialty media

## Tips on using card stock

Card stock is heavy, single-ply specialty media. Many of its variable characteristics, such as moisture content, thickness, and texture, can significantly impact print quality. Print samples on the card stock being considered for use before buying large quantities.

When printing on card stock:

- Make sure the Paper Type is Card Stock.
- Select the appropriate Paper Texture setting.
- Be aware that preprinting, perforation, and creasing may significantly affect the print quality and cause jams or other paper handling problems.
- Check with the manufacturer or vendor to ensure that the card stock can withstand temperatures up to 240°C (464°F) without releasing hazardous emissions.

- Do not use preprinted card stock manufactured with chemicals that may contaminate the printer. Preprinting introduces semi-liquid and volatile components into the printer.
- Use grain short card stock when possible.

## Tips on using envelopes

Print samples on the envelopes being considered for use before buying large quantities.

- Use envelopes designed specifically for laser printers. Check with the manufacturer or vendor to ensure that the envelopes can withstand temperatures up to 230°C (446°F) without sealing, wrinkling, curling excessively, or releasing hazardous emissions.
- For best performance, use envelopes made from 90-g/$m^2$ (24-lb bond) paper or 25% cotton. All-cotton envelopes must not exceed 70-g/$m^2$ (20-lb bond) weight.
- Use only new envelopes from undamaged packages.
- To optimize performance and minimize jams, do not use envelopes that:
  - Have excessive curl or twist
  - Are stuck together or damaged in any way
  - Have windows, holes, perforations, cutouts, or embossing
  - Have metal clasps, string ties, or folding bars
  - Have an interlocking design
  - Have postage stamps attached
  - Have any exposed adhesive when the flap is in the sealed or closed position
  - Have bent corners
  - Have rough, cockle, or laid finishes
- Adjust the width guides to fit the width of the envelopes.

**Note:** A combination of high humidity (over 60%) and high printing temperature may wrinkle or seal envelopes.

## Tips on using labels

Print samples on the labels being considered for use before buying large quantities.

**Note:** Use only paper label sheets. Vinyl, pharmacy, and two-sided labels are not supported.

For more information on label printing, characteristics, and design, see the *Card Stock & Label Guide* available at **http://support.lexmark.com**.

When printing on labels:

- Use labels designed specifically for laser printers. Check with the manufacturer or vendor to verify that:
  - The labels can withstand temperatures up to 240°C (464°F) without sealing, excessive curling, wrinkling, or releasing hazardous emissions.
  - Label adhesives, face sheet (printable stock), and topcoats can withstand up to 172-kPa (25-psi) pressure without delaminating, oozing around the edges, or releasing hazardous fumes.
- Do not use labels with slick backing material.
- Use full label sheets. Partial sheets may cause labels to peel off during printing, resulting in a jam. Partial sheets also contaminate the printer and the cartridge with adhesive, and could void the printer and toner cartridge warranties.

- Do not use labels with exposed adhesive.
- Do not print within 1 mm (0.04 inch) of the edge of the label, of the perforations, or between die-cuts of the label.
- Make sure the adhesive backing does not reach to the edge of the sheet. Zone coating of the adhesive should be at least 1 mm (0.04 inch) away from edges. Adhesive material contaminates the printer and could void the warranty.
- If zone coating of the adhesive is not possible, then remove a 2-mm (0.08-inch) strip on the leading and driver edge, and then use a non-oozing adhesive.
- Portrait orientation is recommended, especially when printing bar codes.

### Tips on using letterhead

- Use letterhead designed specifically for laser printers.
- Print samples on the letterhead being considered for use before buying large quantities.
- Before loading letterhead, flex, fan, and straighten the stack to prevent sheets from sticking together.
- Page orientation is important when printing on letterhead. For information on how to load letterhead, see:
  - “Loading trays” on page 32
  - “Loading the multipurpose feeder” on page 37

### Tips on using transparencies

- Print a test page on the transparencies being considered for use before buying large quantities.
- Feed transparencies from the standard tray, or the multipurpose feeder.
- Use transparencies designed specifically for laser printers. Transparencies must be able to withstand temperatures up to 185°C (365°F) without melting, discoloring, offsetting, or releasing hazardous emissions.

  **Note:** If the transparency weight is set to Heavy and the transparency texture is set to Rough in the Paper menu, then transparencies can be printed at a temperature up to 195°C (383°F).
- Avoid getting fingerprints on the transparencies to prevent print quality problems.
- Before loading transparencies, flex, fan, and straighten the stack to prevent sheets from sticking together.

## Storing paper

Use these paper storage guidelines to help avoid jams and uneven print quality:

- For best results, store paper where the temperature is 21°C (70°F) and the relative humidity is 40 percent. Most label manufacturers recommend printing in a temperature range of 18–24°C (65–75°F) with relative humidity between 40 and 60 percent.
- Store paper in cartons, on a pallet or shelf, rather than on the floor.
- Store individual packages on a flat surface.
- Do not store anything on top of individual paper packages.
- Take paper out of the carton or wrapper only when you are ready to load it in the printer. The carton and wrapper help keep the paper clean, dry, and flat.

# Supported paper sizes, types, and weights

For information on card stock and labels, see the *Card Stock & Label Guide*.

## Supported paper sizes

| Paper size | Standard tray | Optional 250- or 550-sheet tray | Multipurpose feeder | Duplex mode |
|---|---|---|---|---|
| **A4**<br>210 x 297 mm (8.3 x 11.7 in.) | ✓ | ✓ | ✓ | ✓ |
| **A5**<br>148 x 210 mm (5.8 x 8.3 in.) | ✓ | ✓ | ✓ | X |
| **A6**<br>105 x 148 mm (4.1 x 5.8 in.) | ✓ | X | ✓ | X |
| **JIS B5**<br>182 x 257 mm (7.2 x 10.1 in.) | ✓ | ✓ | ✓ | X |
| **Letter**<br>216 x 279 mm (8.5 x 11 in.) | ✓ | ✓ | ✓ | ✓ |
| **Legal**<br>216 x 356 mm (8.5 x 14 in.) | ✓ | ✓ | ✓ | ✓ |
| **Executive**<br>184 x 267 mm (7.3 x 10.5 in.) | ✓ | ✓ | ✓ | X |
| **Oficio (Mexico)**[1]<br>216 x 340 mm (8.5 x 13.4 in.) | ✓ | ✓ | ✓ | ✓ |
| **Folio**<br>216 x 330 mm (8.5 x 13 in.) | ✓ | ✓ | ✓ | ✓ |
| **Statement**<br>140 x 216 mm (5.5 x 8.5 in.) | ✓ | ✓ | ✓ | X |
| **Universal**[2]<br>76.2 x 127 mm (3 x 5 in.) up to 216 x 356 mm (8.5 x 14 in.) | ✓ | ✓ | ✓ | ✓ |
| **7 3/4 Envelope (Monarch)**<br>98 x 191 mm (3.9 x 7.5 in.) | X | X | ✓ | X |
| **9 Envelope**<br>98 x 225 mm (3.9 x 8.9 in.) | X | X | ✓ | X |

[1] This size setting formats the page for 216 x 356 mm (8.5 x 14 in.) unless the size is specified by the software application.

[2] Universal is supported in the standard tray only if the paper size is at least 105 x 148 mm (4.1 x 5.8 in.). Universal is supported in the optional 250- or 550-sheet tray only if the paper size is at least 148 x 210 mm (5.8 x 8.3 in.). Universal is supported in duplex mode only if the width is at least 210 mm (8.3 in.) and the length is at least 279 mm (11 in.). The smallest supported Universal size is supported only in the multipurpose feeder.

| Paper size | Standard tray | Optional 250- or 550-sheet tray | Multipurpose feeder | Duplex mode |
|---|---|---|---|---|
| **10 Envelope**<br>105 x 241 mm (4.1 x 9.5 in.) | X | X | ✓ | X |
| **DL Envelope**<br>110 x 220 mm (4.3 x 8.7 in.) | X | X | ✓ | X |
| **C5 Envelope**<br>162 x 229 mm (6.4 x 9 in.) | X | X | ✓ | X |
| **B5 Envelope**<br>176 x 250 mm (6.9 x 9.8 in.) | X | X | ✓ | X |
| **Other Envelope**<br>229 x 356 mm (9 x 14 in.) | X | X | ✓ | X |

[1] This size setting formats the page for 216 x 356 mm (8.5 x 14 in.) unless the size is specified by the software application.

[2] Universal is supported in the standard tray only if the paper size is at least 105 x 148 mm (4.1 x 5.8 in.). Universal is supported in the optional 250- or 550-sheet tray only if the paper size is at least 148 x 210 mm (5.8 x 8.3 in.). Universal is supported in duplex mode only if the width is at least 210 mm (8.3 in.) and the length is at least 279 mm (11 in.). The smallest supported Universal size is supported only in the multipurpose feeder.

## Supported paper types and weights

The standard tray supports 60–90-g/m$^2$ (16–24-lb) paper weights. The optional tray supports 60–120-g/m$^2$ (16–32-lb) paper weights. The multipurpose feeder supports 60–163-g/m$^2$ (16–43-lb) paper weights.

| Paper type | 250- or 550-sheet tray | Multipurpose feeder | Duplex mode |
|---|---|---|---|
| **Plain paper** | ✓ | ✓ | ✓ |
| **Card stock** | X | ✓ | X |
| **Transparencies** | ✓ | ✓ | X |
| **Recycled** | ✓ | ✓ | ✓ |
| **Glossy paper** | X | X | X |
| **Paper labels**[1] | ✓ | ✓ | X |
| **Vinyl labels** | X | X | X |
| **Bond**[2] | ✓ | ✓ | ✓ |
| **Envelope** | X | ✓ | X |
| **Rough envelope** | X | ✓ | X |
| **Letterhead** | ✓ | ✓ | ✓ |

| Paper type | 250- or 550-sheet tray | Multipurpose feeder | Duplex mode |
|---|---|---|---|
| **Preprinted** | ✓ | ✓ | ✓ |
| **Colored Paper** | ✓ | ✓ | ✓ |
| **Light Paper** | ✓ | ✓ | ✓ |
| **Heavy Paper**[2] | ✓ | ✓ | ✓ |
| **Rough/Cotton** | ✓ | ✓ | **X** |

[1] One-sided paper labels designed for laser printers are supported for occasional use. It is recommended to print 20 or fewer pages of paper labels per month. Vinyl, pharmacy, and two-sided labels are not supported.

[2] Bond and Heavy Paper are supported in duplex mode up to 90-g/$m^2$ (24-lb) paper weight.

# Printing

This chapter covers printing, printer reports, and job cancelation. Selection and handling of paper and specialty media can affect how reliably documents print. For more information, see “Avoiding jams” on page 105 and “Storing paper” on page 48.

## Printing a document

### Printing a document

1. From the Paper menu on the printer control panel, set the paper type and size to match the paper loaded.
2. Send the print job:

   **For Windows users**

   a. With a document open, click **File** > **Print**.

   b. Click **Properties**, **Preferences**, **Options**, or **Setup**.

   c. Adjust the settings, if necessary.

   d. Click **OK** > **Print**.

   **For Macintosh users**

   a. Customize the settings in the Page Setup dialog:
      1. With a document open, choose **File** > **Page Setup**.
      2. Choose a paper size or create a custom size to match the paper loaded.
      3. Click **OK**.

   b. Customize the settings in the Print dialog:
      1. With a document open, choose **File** > **Print**.
         If necessary, click the disclosure triangle to see more options.
      2. From the Print dialog and pop-up menus, adjust the settings if necessary.

         **Note:** To print on a specific paper type, adjust the paper type setting to match the paper loaded, or select the appropriate tray or feeder.
      3. Click **Print**.

### Adjusting toner darkness

#### Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Print Settings** > **Quality Menu** > **Toner Darkness**.

3 Adjust the toner darkness setting.

4 Click **Submit**.

### Using the printer settings on the computer

Depending on your operating system, adjust the toner darkness settings using the Local Printer Settings Utility or Printer Settings.

### Using the printer control panel

1 From the printer control panel, navigate to:

> **Settings** > > **Print Settings** > > **Quality Menu** > > **Toner Darkness** >

2 Adjust the toner darkness.

3 Press .

# Printing information pages

For more information on printing information pages, see “Printing a menu settings page” on page 29 and “Printing a network setup page” on page 30.

## Printing a font sample list

From the printer control panel, navigate to either of the following:

> **Reports** > > **Print Fonts** > > **PCL Fonts** >

*or*

> **Reports** > > **Print Fonts** > > **PostScript Fonts** >

# Canceling a print job

## Canceling a print job from the printer control panel

From the printer control panel, press > .

## Canceling a print job from the computer

### For Windows users

1 Open the printers folder.

**In Windows 8**

From the Search charm, type **`run`**, and then navigate to:

Apps list > **Run** > type **`control printers`** > **OK**

**In Windows 7 or earlier**

a Click or click **Start**, and then click **Run**.

b In the Start Search or Run dialog, type **`control printers`**.

c Press **Enter**, or click **OK**.

2 Double-click the printer icon.

3 Select the print job you want to cancel.

4 Click **Delete**.

## For Macintosh users

1 From the Apple menu, navigate to either of the following:

- **System Preferences** > **Print & Scan** > select your printer > **Open Print Queue**
- **System Preferences** > **Print & Fax** > select your printer > **Open Print Queue**

2 From the printer window, select the print job you want to cancel, and then delete it.

# Understanding the printer menus

## Menus list

**Paper Menu**

Default Source
Paper Size/Type
Configure MP
Substitute Size
Paper Texture
Paper Weight
Paper Loading
Custom Types
Universal Setup

**Reports**

Menu Settings Page
Device Statistics
Network Setup Page[1]
Profiles List
Print Fonts
Print Directory
Asset Report

**Network/Ports[3]**

Active NIC
Standard Network[2]
Reports
Network card
TCP/IP
IPv6
Wireless
AppleTalk
Standard USB
SMTP Setup

**Security**

Security Audit Log
Set Date and Time

**Settings**

General Settings
Print Settings

[1] Depending on the printer setup, this menu item appears as Network Setup Page or Network [x] Setup Page.

[2] Depending on the printer setup, this menu item appears as Standard Network or Network [x].

[3] The menu items in this menu appear only in network printers or printers connected to print servers.

## Paper menu

### Default Source menu

| Use | To |
|---|---|
| **Default Source**<br>Tray [x]<br>MP Feeder<br>Manual Paper<br>Manual Envelope | Set a default paper source for all print jobs.<br>**Notes:**<br>• Tray 1 (standard tray) is the factory default setting.<br>• From the Paper menu, set Configure MP to "Cassette" for MP Feeder to appear as a menu setting.<br>• If two trays contain paper of the same size and type, and the trays have the same settings, then the trays are automatically linked. When one tray is empty, the print job continues using the linked tray. |

## Paper Size/Type menu

| Use | To |
|---|---|
| **Tray [x] Size**<br>A4<br>A5<br>A6<br>JIS-B5<br>Letter<br>Legal<br>Executive<br>Oficio (Mexico)<br>Folio<br>Statement<br>Universal | Specify the paper size loaded in each tray.<br>**Notes:**<br>• Letter is the U.S. factory default setting. A4 is the international factory default setting.<br>• If two trays contain paper of the same size and type, and the trays have the same settings, then the trays are automatically linked. When one tray is empty, the print job continues using the linked tray.<br>• The A6 paper size is supported only in Tray 1 and the multipurpose feeder. |
| **Tray [x] Type**<br>Plain Paper<br>Transparency<br>Recycled<br>Labels<br>Bond<br>Letterhead<br>Preprinted<br>Colored Paper<br>Light Paper<br>Heavy Paper<br>Rough/Cotton<br>Custom Type [x] | Specify the type of paper loaded in each tray.<br>**Notes:**<br>• Plain Paper is the factory default setting for Tray 1. Custom Type [x] is the factory default setting for all other trays.<br>• If available, a user-defined name will appear instead of Custom Type [x].<br>• Use this menu to configure automatic tray linking. |
| **Note:** Only installed trays and feeders are listed in this menu. | |

| Use | To |
| --- | --- |
| **MP Feeder Size**<br>A4<br>A5<br>A6<br>JIS B5<br>Letter<br>Legal<br>Executive<br>Oficio (Mexico)<br>Folio<br>Statement<br>Universal<br>7 3/4 Envelope<br>9 Envelope<br>10 Envelope<br>DL Envelope<br>C5 Envelope<br>B5 Envelope<br>Other Envelope | Specify the paper size loaded in the multipurpose feeder.<br>**Notes:**<br>• Letter is the U.S. factory default setting. A4 is the international factory default setting.<br>• From the Paper menu, set Configure MP to “Cassette” for MP Feeder Size to appear as a menu.<br>• The multipurpose feeder does not automatically detect paper size. Make sure to set the paper size value. |
| **MP Feeder Type**<br>Plain Paper<br>Card Stock<br>Transparency<br>Recycled<br>Labels<br>Bond<br>Envelope<br>Rough Envelope<br>Letterhead<br>Preprinted<br>Colored Paper<br>Light Paper<br>Heavy Paper<br>Rough/Cotton<br>Custom Type [x] | Specify the type of paper loaded in the multipurpose feeder.<br>**Notes:**<br>• Custom Type [x] is the factory default setting.<br>• From the Paper menu, set Configure MP to “Cassette” for MP Feeder Type to appear as a menu. |
| **Note:** Only installed trays and feeders are listed in this menu. | |

| Use | To |
|---|---|
| **Manual Paper Size**<br>A4<br>A5<br>A6<br>JIS B5<br>Letter<br>Legal<br>Executive<br>Oficio (Mexico)<br>Folio<br>Statement<br>Universal | Specify the paper size being manually loaded.<br>**Note:** Letter is the U.S. factory default setting. A4 is the international factory default setting. |
| **Manual Paper Type**<br>Plain Paper<br>Card Stock<br>Transparency<br>Recycled<br>Labels<br>Bond<br>Letterhead<br>Preprinted<br>Colored Paper<br>Light Paper<br>Heavy Paper<br>Rough/Cotton<br>Custom Type [x] | Specify the paper type being manually loaded.<br>**Notes:**<br>• Plain Paper is the factory default setting.<br>• From the Paper menu, set Configure MP to “Manual” for Manual Paper Type to appear as a menu. |
| **Manual Envelope Size**<br>7 3/4 Envelope<br>9 Envelope<br>10 Envelope<br>DL Envelope<br>C5 Envelope<br>B5 Envelope<br>Other Envelope | Specify the envelope size being manually loaded.<br>**Note:** 10 Envelope is the U.S. factory default setting. DL Envelope is the international factory default setting. |
| **Manual Envelope Type**<br>Envelope<br>Rough Envelope<br>Custom Type [x] | Specify the envelope type being manually loaded.<br>**Note:** Envelope is the factory default setting. |
| **Note:** Only installed trays and feeders are listed in this menu. | |

## Configure MP menu

| Use | To |
|---|---|
| **Configure MP**<br>Cassette<br>Manual<br>First | Determine when the printer selects paper from the multipurpose feeder.<br>**Notes:**<br>• Cassette is the factory default setting. Cassette configures the multipurpose feeder as the default paper source.<br>• Manual sets the multipurpose feeder only for manual-feed print jobs.<br>• First sets the multipurpose feeder as the primary paper source regardless of settings. |

## Substitute Size menu

| Use | To |
|---|---|
| **Substitute Size**<br>Off<br>Statement/A5<br>Letter/A4<br>All Listed | Substitute a specified paper size if the requested paper size is not available.<br>**Notes:**<br>• All Listed is the factory default setting. All available substitutions are allowed.<br>• Off indicates that no size substitutions are allowed.<br>• Setting a size substitution lets the print job continue without **Change Paper** appearing. |

## Paper Texture menu

| Use | To |
|---|---|
| **Plain Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the plain paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Card Stock Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the card stock loaded.<br>**Notes:**<br>• Normal is the factory default setting.<br>• The options appear only if card stock is supported. |
| **Transparency Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the transparencies loaded.<br>**Note:** Normal is the factory default setting. |
| **Recycled Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the recycled paper loaded.<br>**Note:** Normal is the factory default setting. |

| Use | To |
|---|---|
| **Labels Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the labels loaded.<br>**Note:** Normal is the factory default setting. |
| **Bond Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the bond paper loaded.<br>**Note:** Rough is the factory default setting. |
| **Envelope Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the envelopes loaded.<br>**Note:** Normal is the factory default setting. |
| **Rough Envelope Texture**<br>Rough | Specify the relative texture of the rough envelopes loaded. |
| **Letterhead Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the letterhead loaded.<br>**Note:** Normal is the factory default setting. |
| **Preprinted Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the preprinted paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Colored Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the colored paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Light Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Heavy Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Rough/Cotton Texture**<br>Rough | Specify the relative texture of the cotton paper loaded. |
| **Custom [x] Texture**<br>Smooth<br>Normal<br>Rough | Specify the relative texture of the custom paper loaded.<br>**Notes:**<br>• Normal is the factory default setting.<br>• The options appear only if the custom type is supported. |

## Paper Weight menu

| Use | To |
|---|---|
| **Plain Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the plain paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Card Stock Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the card stock loaded.<br>**Note:** Normal is the factory default setting. |
| **Transparency Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the transparencies loaded.<br>**Note:** Normal is the factory default setting. |
| **Recycled Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the recycled paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Labels Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the labels loaded.<br>**Note:** Normal is the factory default setting. |
| **Bond Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the bond paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Envelope Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the envelope loaded.<br>**Note:** Normal is the factory default setting. |
| **Rough Envelope Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the rough envelope loaded.<br>**Note:** Normal is the factory default setting. |
| **Letterhead Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the letterhead loaded.<br>**Note:** Normal is the factory default setting. |
| **Preprinted Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the preprinted paper loaded.<br>**Note:** Normal is the factory default setting. |

| Use | To |
|---|---|
| **Colored Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the colored paper loaded.<br>**Note:** Normal is the factory default setting. |
| **Light Weight**<br>Light | Specify that the weight of the paper loaded is light. |
| **Heavy Weight**<br>Heavy | Specify that the weight of the paper loaded is heavy. |
| **Cotton/Rough Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the cotton or rough paper loaded.<br>**Note:** Heavy is the factory default setting. |
| **Custom [x] Weight**<br>Light<br>Normal<br>Heavy | Specify the relative weight of the custom paper loaded.<br>**Notes:**<br>• Normal is the factory default setting.<br>• The options appear only when the custom type is supported. |

## Paper Loading menu

| Use | To |
|---|---|
| **Recycled Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Recycled as the paper type. |
| **Bond Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Bond as the paper type. |
| **Letterhead Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Letterhead as the paper type. |
| **Preprinted Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Preprinted as the paper type. |
| **Colored Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Colored as the paper type. |

**Notes:**

- Duplex sets two-sided printing as the default for all print jobs unless one-sided printing is set from Printing Preferences or Print dialog.
- If Duplex is selected, then all print jobs are sent through the duplex unit, including one-sided jobs.
- Off is the factory default setting for all the menus.

| Use | To |
|---|---|
| **Light Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Light as the paper type. |
| **Heavy Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Heavy as the paper type. |
| **Custom [x] Loading**<br>Duplex<br>Off | Determine and set two-sided printing for all print jobs that specify Custom [x] as the paper type.<br>**Note:** Custom [x] Loading is available only if the custom type is supported. |

**Notes:**

- Duplex sets two-sided printing as the default for all print jobs unless one-sided printing is set from Printing Preferences or Print dialog.
- If Duplex is selected, then all print jobs are sent through the duplex unit, including one-sided jobs.
- Off is the factory default setting for all the menus.

## Custom Types menu

| Use | To |
|---|---|
| **Custom Type [x]**<br>Paper<br>Card Stock<br>Transparency<br>Rough/Cotton<br>Labels<br>Envelope | Associate a paper or specialty media type with a Custom Type [x] name or a user-defined custom name created in the Embedded Web Server, in the Local Printer Settings Utility, or in MarkVision™ Professional.<br>**Notes:**<br>• Paper is the factory default setting for Custom Type [x].<br>• The specialty media type must be supported in the selected tray or feeder in order to print from that source. |
| **Recycled**<br>Paper<br>Card Stock<br>Transparency<br>Rough/Cotton<br>Labels<br>Envelope<br>Cotton | Specify a paper type when the Recycled setting is selected in other menus.<br>**Notes:**<br>• Paper is the factory default setting.<br>• The Recycled paper type must be supported in the selected tray or feeder in order to print from that source. |

## Universal Setup menu

| Use | To |
|---|---|
| **Units of Measure**<br>Inches<br>Millimeters | Identify the units of measure.<br>**Notes:**<br>• Inches is the US factory default setting.<br>• Millimeters is the international factory default setting. |
| **Portrait Width**<br>3–8.5 inches<br>76–216 mm | Set the portrait width.<br>**Notes:**<br>• If the width exceeds the maximum, then the printer uses the maximum width allowed.<br>• 8.5 inches is the US factory default setting. You can increase the width in 0.01-inch increments.<br>• 216 mm is the international factory default setting. You can increase the width in 1-mm increments. |
| **Portrait Height**<br>3–14.17 inches<br>76–360 mm | Set the portrait height.<br>**Notes:**<br>• If the height exceeds the maximum, then the printer uses the maximum height allowed.<br>• 14 inches is the US factory default setting. You can increase the height in 0.01-inch increments.<br>• 356 mm is the international factory default setting. You can increase the height in 1-mm increments. |
| **Feed Direction**<br>Short Edge<br>Long Edge | Specify the feed direction if the paper can be loaded in either direction.<br>**Notes:**<br>• Short Edge is the factory default setting.<br>• Long Edge appears only when the longest edge is shorter than the maximum width supported in the tray. |

# Reports menu

## Reports menu

| Use | To |
|---|---|
| **Menu Settings Page** | Print a report containing information about the paper loaded in trays, installed memory, total page count, alarms, timeouts, printer control panel language, TCP/IP address, status of supplies, status of the network connection, and other information. |
| **Device Statistics** | Print a report containing printer statistics, such as supply information and details about printed pages. |

| Use | To |
|---|---|
| **Network Setup Page** | Print a report containing information about the network printer settings, such as the TCP/IP address information.<br>**Note:** This menu item appears only in network printers or in printers connected to print servers. |
| **Profiles List** | Print a list of profiles stored in the printer.<br>**Note:** This menu item appears only when LDSS is enabled. |
| **Print Fonts**<br>PCL Fonts<br>PostScript Fonts | Print a report of all the fonts available for the printer language currently set in the printer.<br>**Note:** A separate list is available for PCL and PostScript emulations. |
| **Print Directory** | Print a list of all the resources stored in an optional flash memory card.<br>**Notes:**<br>• Job Buffer Size must be set to 100%.<br>• Make sure the optional flash memory is installed correctly and working properly.<br>• This menu item appears only when an optional flash memory card is installed. |
| **Asset Report** | Print a report containing printer asset information, such as serial number and model name. |

# Network/Ports menu

The menus in this section only appear in network printers or printers connected to print servers.

## Active NIC menu

| Use | To |
|---|---|
| **Active NIC**<br>Auto<br>[list of available network cards] | **Notes:**<br>• Auto is the factory default setting.<br>• This menu item appears only when an optional network card is installed. |

## Standard Network or Network [x] menu

**Note:** Only active ports appear in this menu. All inactive ports are omitted.

| Use | To |
|---|---|
| **PCL SmartSwitch**<br>On<br>Off | Set the printer to automatically switch to PCL emulation when a print job requires it, regardless of the default printer language.<br>**Notes:**<br>• On is the factory default setting.<br>• If PCL SmartSwitch is disabled, then the printer does not examine incoming data and it uses the default printer language specified in the Setup menu. |

| Use | To |
|---|---|
| **PS SmartSwitch**<br>On<br>Off | Set the printer to automatically switch to PS emulation when a print job requires it, regardless of the default printer language.<br>**Notes:**<br>• On is the factory default setting.<br>• If PS SmartSwitch is disabled, then the printer does not examine incoming data and it uses the default printer language specified in the Setup menu. |
| **NPA Mode**<br>Off<br>Auto | Set the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol.<br>**Notes:**<br>• Auto is the factory default setting.<br>• Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated. |
| **Network Buffer**<br>Disabled<br>Auto<br>3KB to [maximum size allowed] | Set the size of the network input buffer.<br>**Notes:**<br>• Auto is the factory default setting.<br>• The value can be changed in 1-KB increments.<br>• The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off.<br>• To increase the maximum size range for the Network Buffer, disable or reduce the size of the parallel, serial, and USB buffers.<br>• Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated. |
| **Mac Binary PS**<br>On<br>Off<br>Auto | Set the printer to process Macintosh binary PostScript print jobs.<br>**Notes:**<br>• Auto is the factory default setting.<br>• Off filters print jobs using the standard protocol.<br>• On processes raw binary PostScript print jobs. |

## Reports menu

To access the menu, navigate to either of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **Reports**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Reports**

| Use | To |
|---|---|
| **Print Setup Page** | Print a report containing information about the network printer settings, such as the TCP/IP address. |

## Network Card menu

To access the menu, navigate to either of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **Network Card**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Network Card**

| Use | To |
|---|---|
| **View Card Status**<br>Connected<br>Disconnected | View the connection status of the network card. |
| **View Card Speed** | View the speed of an active network card. |
| **Network Address**<br>UAA<br>LAA | View the network addresses. |
| **Job Timeout**<br>0–255 seconds | Set the amount of time it takes for a network print job to be canceled.<br>**Notes:**<br>• 90 seconds is the factory default setting.<br>• A setting value of 0 disables the timeout.<br>• If a value of 1–9 is selected, then the setting is saved as 10. |

## TCP/IP menu

To access the menu, navigate to any of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **TCP/IP**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **TCP/IP**

**Note:** This menu is available only in network printers or printers connected to print servers.

| Use | To |
|---|---|
| **Set Hostname** | Set the host name.<br>**Notes:**<br>• This setting can be changed only from the Embedded Web Server.<br>• The host name can be up to 15 characters and can be a US-ASCII or alphanumeric character, or hyphen. |
| **IP Address** | View or change the current TCP/IP address.<br>**Note:** Manually setting the IP address sets the “Enable DHCP” and “Enable Auto IP” settings to Off. It also sets “Enable BOOTP” and “Enable RARP” to Off on systems that support BOOTP and RARP. |
| **Netmask** | View or change the current TCP/IP netmask. |
| **Gateway** | View or change the current TCP/IP gateway. |
| **Enable DHCP**<br>On<br>Off | Specify the DHCP address and parameter assignment.<br>**Note:** On is the factory default setting. |

| Use | To |
|---|---|
| **Enable AutoIP**<br>Yes<br>No | Specify the Zero Configuration Networking setting.<br>**Note:** Yes is the factory default setting. |
| **Enable FTP/TFTP**<br>Yes<br>No | Enable the built-in FTP server, which lets you send files to the printer using File Transfer Protocol.<br>**Note:** Yes is the factory default setting. |
| **Enable HTTP Server**<br>Yes<br>No | Enable the built-in Web server (Embedded Web Server). When enabled, the printer can be monitored and managed remotely using a Web browser.<br>**Note:** Yes is the factory default setting. |
| **WINS Server Address** | View or change the current WINS server address. |
| **Enable DDNS**<br>Yes<br>No | View or change the current DDNS setting.<br>**Note:** Yes is the factory default setting. |
| **Enable mDNS**<br>Yes<br>No | View or change the current mDNS setting.<br>**Note:** Yes is the factory default setting. |
| **DNS Server Address** | View or change the current DNS server address. |
| **Backup DNS Server Address** | View or change the backup DNS server addresses. |
| **Backup DNS Server Address 2** | |
| **Backup DNS Server Address 3** | |
| **Enable HTTPS**<br>Yes<br>No | View or change the current HTTPS setting.<br>**Note:** Yes is the factory default setting. |

## IPv6 menu

To access the menu, navigate to any of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **IPv6**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **IPv6**

**Note:** This menu is available only in network printers or printers connected to print servers.

| Use | To |
|---|---|
| **Enable IPv6**<br>On<br>Off | Enable Internet Protocol Version Six (IPv6) in the printer.<br>IPv6 uses bigger numbers to create IP addresses.<br>**Note:** On is the factory default setting. |
| **Auto Configuration**<br>On<br>Off | Specify whether or not the network adapter accepts the automatic IPv6 address configuration entries provided by a router.<br>**Note:** On is the factory default setting. |
| * These settings can be changed only from the Embedded Web Server. | |

| Use | To |
|---|---|
| **Set Hostname*** | Set the host name.<br>**Note:** The host name is limited to 15 characters, and accepts US-ASCII, alphanumeric characters and hyphen only. |
| **View Address*** | View the current IPv6 addresses. |
| **View Router Address*** | View the current router address. |
| **Enable DHCPv6**<br>On<br>Off | Enable DHCPv6 in the printer.<br>**Note:** On is the factory default setting. |
| * These settings can be changed only from the Embedded Web Server. | |

## Wireless menu

**Note:** This menu is available only in printers connected to a wireless network or printer models that have a wireless network adapter.

To access the menu, navigate to any of the following:

- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Wireless**

| Use | To |
|---|---|
| **Network Mode**<br>Infrastructure<br>Ad hoc | Specify the network mode.<br>**Notes:**<br>• Ad hoc is the factory default setting. This configures wireless connection directly between the printer and a computer.<br>• Infrastructure lets the printer access a network using an access point. |
| **Compatibility**<br>802.11b/g<br>802.11b/g/n | Specify the wireless standard for the wireless network.<br>**Note:** The 802.11b/g/n is the factory default setting. |
| **Choose Network** | Select an available network for the printer to use. |
| **View Signal Quality** | View the quality of the wireless connection. |
| **View Security Mode** | View the encryption method for the wireless network. |

## AppleTalk menu

**Note:** This menu is available only in printer models connected to a wired network or when an optional network card is installed.

To access the menu, navigate to any of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **AppleTalk**
- **Network/Ports** > **Network Setup [x]** > **AppleTalk**

| Use | To |
|---|---|
| **Activate**<br>Yes<br>No | Enable or disable AppleTalk support.<br>**Note:** Yes is the factory default setting. |
| **View Name** | Show the assigned AppleTalk name.<br>**Note:** The name can be changed only from the Embedded Web Server. |
| **View Address** | Show the assigned AppleTalk address.<br>**Note:** The address can be changed only from the Embedded Web Server. |
| **Set Zone**<br>[list of zones available on the network] | Provide a list of AppleTalk zones available on the network.<br>**Note:** The factory default setting is the default zone for the network. If no default zone exists, then the zone marked with an asterisk (*) is the default setting. |

## Standard USB menu

| Use | To |
|---|---|
| **PCL SmartSwitch**<br>On<br>Off | Set the printer to automatically switch to PCL emulation when a print job received through a USB port requires it, regardless of the default printer language.<br>**Notes:**<br>• On is the factory default setting.<br>• When set to Off, the printer does not examine incoming data. The printer uses PostScript emulation if the PS SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if the PS SmartSwitch is set to Off. |
| **PS SmartSwitch**<br>On<br>Off | Set the printer to automatically switch to PS emulation when a print job received through a USB port requires it, regardless of the default printer language.<br>**Notes:**<br>• On is the factory default setting.<br>• When set to Off, the printer does not examine incoming data. The printer uses PCL emulation if the PCL SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if the PCL SmartSwitch is set to Off. |
| **NPA Mode**<br>On<br>Off<br>Auto | Set the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol.<br>**Notes:**<br>• Auto is the factory default setting. Auto sets the printer to examine data, determine the format, and then process it appropriately.<br>• The printer automatically restarts when changing the setting from the printer control panel. The menu selection is then updated. |

| Use | To |
|---|---|
| **USB Buffer**<br>Disabled<br>Auto<br>3K to [maximum size allowed] | Set the size of the USB input buffer.<br>**Notes:**<br>• Auto is the factory default setting.<br>• Disabled turns off job buffering.<br>• The USB buffer size value can be changed in 1-KB increments.<br>• The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off.<br>• To increase the maximum size range for USB Buffer, disable or reduce the size of the parallel, serial, and network buffers.<br>• The printer automatically restarts when the setting is changed from the printer control panel. The menu selection is then updated. |
| **Mac Binary PS**<br>On<br>Off<br>Auto | Set the printer to process Macintosh binary PostScript print jobs.<br>**Notes:**<br>• Auto is the factory default setting.<br>• On processes raw binary PostScript print jobs.<br>• Off filters print jobs using the standard protocol. |
| **ENA Address**<br>yyy.yyy.yyy.yyy | Set the network address information for an external print server.<br>**Note:** This menu is available only when the printer is attached to an external print server through the USB port. |
| **ENA Netmask**<br>yyy.yyy.yyy.yyy | Set the netmask information for an external print server.<br>**Note:** This menu is available only when the printer is attached to an external print server through the USB port. |
| **ENA Gateway**<br>yyy.yyy.yyy.yyy | Set the gateway information for an external print server.<br>**Note:** This menu is available only when the printer is attached to an external print server through the USB port. |

## SMTP Setup menu

| Use | To |
|---|---|
| **Primary SMTP Gateway** | Specify SMTP server gateway and port information.<br>**Note:** 25 is the default SMTP gateway port. |
| **Primary SMTP Gateway Port** | |
| **Secondary SMTP Gateway** | |
| **Secondary SMTP Gateway Port** | |
| **SMTP Timeout**<br>5–30 | Specify the amount of time in seconds before the server stops trying to send an e-mail.<br>**Note:** 30 seconds is the factory default setting. |
| **Reply Address** | Specify a reply address of up to 128 characters in the e-mail sent by the printer. |

| Use | To |
|---|---|
| **Use SSL**<br>Disabled<br>Negotiate<br>Required | Set the printer to use SSL for increased security when connecting to the SMTP server.<br>**Notes:**<br>• Disabled is the factory default setting.<br>• When the Negotiate setting is used, the SMTP server determines if SSL will be used. |
| **SMTP Server Authentication**<br>No authentication required<br>Login/Plain<br>CRAM-MD5<br>Digest-MD5<br>NTLM<br>Kerberos 5 | Specify the type of user authentication required for printing privileges.<br>**Note:** "No authentication required" is the factory default setting. |
| **Device-Initiated E-mail**<br>None<br>Use Device SMTP Credentials | Specify what credentials will be used when communicating to the SMTP server. Some SMTP servers require credentials to send an e-mail.<br>**Notes:**<br>• None is the factory default setting for Device-Initiated E-mail.<br>• Device Userid and Device Password are used to log in to the SMTP server when Use Device SMTP Credentials is selected. |
| **Device Userid** | |
| **Device Password** | |

# Security menu

## Security Audit Log menu

| Use | To |
|---|---|
| **Export Log** | Let an authorized user export the audit log.<br>**Notes:**<br>• To export the audit log from the printer control panel, connect a flash drive to the printer.<br>• You can also download the audit log from the Embedded Web Server, and then save it on your computer. |
| **Delete Log**<br>Delete now<br>Do not delete | Specify whether or not audit logs are deleted.<br>**Note:** Delete now is the factory default setting. |

| Use | To |
| --- | --- |
| **Configure Log**<br>Enable Audit<br>Yes<br>No<br>Enable Remote Syslog<br>No<br>Yes<br>Remote Syslog Facility<br>0–23<br>Severity of events to log<br>0–7 | Specify how and whether or not audit logs are created.<br>**Notes:**<br>• Enable Audit determines if events are recorded in the secure audit log and remote syslog. No is the factory default setting.<br>• Enable Remote Syslog determines if logs are sent to a remote server. No is the factory default setting.<br>• Remote Syslog Facility determines the value used to send logs to the remote syslog server. 4 is the factory default setting.<br>• If the security audit log is activated, then the severity value of each event is recorded. 4 is the factory default setting. |

## Set Date and Time menu

| Use | To |
| --- | --- |
| **Current Date and Time** | View the current date and time settings for the printer.<br>**Note:** The date and time are set in YYYY-MM-DD HH:MM format. |
| **Manually Set Date and Time**<br>[input date/time] | Enter the date and time.<br>**Note:** Setting the date and time using this menu automatically sets Enable NTP to Off. |
| **Time Zone**<br>[list of time zones] | Select the time zone.<br>**Note:** GMT is the factory default setting. |
| **Automatically observe DST**<br>On<br>Off | Set the printer to use the applicable daylight saving time (DST) start and end times associated with the printer Time Zone setting.<br>**Note:** On is the factory default setting. |
| **Enable NTP**<br>On<br>Off | Enable Network Time Protocol, which synchronizes the clocks of devices on a network.<br>**Notes:**<br>• On is the factory default setting.<br>• Enable NTP is automatically set to Off if you manually set the date and time. |

# Settings menu

## General Settings menu

| Use | To |
|---|---|
| **Display Language**<br>English<br>Francais<br>Deutsch<br>Italiano<br>Espanol<br>Dansk<br>Norsk<br>Nederlands<br>Svenska<br>Portuguese<br>Suomi<br>Russian<br>Polski<br>Greek<br>Magyar<br>Turkce<br>Cesky<br>Simplified Chinese<br>Traditional Chinese<br>Korean<br>Japanese | Set the language of the text appearing on the printer display.<br>**Note:** Not all languages are available for all printers, and you may need to install special hardware for those languages to appear. |
| **Show Supply Estimates**<br>Show estimates<br>Do not show estimates | View the estimates of the supplies on the printer control panel, Embedded Web Server, menu settings, and the device statistics reports. |
| **Eco-Mode**<br>Off<br>Energy<br>Energy/Paper<br>Paper | Minimize the use of energy, paper, or specialty media.<br>**Notes:**<br>• Off is the factory default setting. Off resets the printer to its factory default settings.<br>• Energy minimizes the power used by the printer.<br>• Energy/Paper minimizes the use of power and of paper and specialty media.<br>• Paper minimizes the amount of paper and specialty media needed for a print job. |

| Use | To |
|---|---|
| **Run Initial setup**<br>Yes<br>No | Run the setup wizard.<br>**Notes:**<br>• Yes is the factory default setting.<br>• After completing the setup wizard by selecting Done at the country or region selection screen, the default becomes No. |
| **Paper Sizes**<br>US<br>Metric | Specify the unit of measurement for paper sizes.<br>**Notes:**<br>• US is the factory default setting.<br>• The initial setting is determined by your country or region selection in the initial setup wizard. |
| **Timeouts**<br>Sleep Mode<br>Disabled<br>1–120 min | Set the amount of time the printer waits after a job is printed before it goes into a reduced power state.<br>**Notes:**<br>• "30 min" is the factory default setting.<br>• "Disabled" appears only when Energy Conserve is set to Off.<br>• Lower settings conserve more energy, but may require longer warm-up times.<br>• Select a high setting if the printer is in constant use. Under most circumstances, this keeps the printer ready to print with minimum warm-up time. |
| **Timeouts**<br>Hibernate Timeout<br>Disabled<br>1 hour<br>2 hours<br>3 hours<br>6 hours<br>1 day<br>2 days<br>3 days<br>1 week<br>2 weeks<br>1 month | Set the amount of time the printer waits before it enters Hibernate mode.<br>**Notes:**<br>• "Disabled" is the factory default setting in all countries except European Union countries and Switzerland.<br>• "3 days" is the factory default setting for all European Union countries and Switzerland. |
| **Timeouts**<br>Hibernate Timeout on Connection<br>Hibernate<br>Do Not Hibernate | Set the printer to Hibernate mode even if there is an active Ethernet connection.<br>**Note:** "Do Not Hibernate" is the factory default setting. |
| **Timeouts**<br>Screen Timeout<br>15–300 sec | Set the amount of time in seconds the printer waits before the it returns to a ready state.<br>**Note:** "30 sec" is the factory default setting. |

| Use | To |
|---|---|
| **Timeouts**<br>Prolong Screen Timeout<br>On<br>Off | Display a message that lets you reset the screen timeout timer instead of returning to the printer display.<br>**Note:** Off is the factory default setting. |
| **Timeouts**<br>Print Timeout<br>Disabled<br>1–255 sec | Set the amount of time in seconds the printer waits to receive an end-of-job message before canceling the remainder of the print job.<br>**Notes:**<br>• "90 sec" is the factory default setting.<br>• When the timer expires, any partially printed page still in the printer is printed, and then the printer checks to see if any new print jobs are waiting.<br>• Print Timeout is available only when using PCL emulation. This setting has no effect on PostScript emulation print jobs. |
| **Timeouts**<br>Wait Timeout<br>Disabled<br>15–65535 sec | Set the amount of time in seconds the printer waits for additional data before canceling a print job.<br>**Note:** "40 sec" is the factory default setting. |
| **Print Recovery**<br>Auto Continue<br>Disabled<br>5–255 sec | Let the printer automatically continue printing from certain offline situations when these are not resolved within the specified time period.<br>**Note:** Disabled is the factory default setting. |
| **Print Recovery**<br>Jam Recovery<br>On<br>Off<br>Auto | Specify whether the printer reprints jammed pages.<br>**Notes:**<br>• Auto is the factory default setting. The printer reprints jammed pages unless the memory required to hold the pages is needed for other printer tasks.<br>• On sets the printer to always reprint jammed pages.<br>• Off sets the printer to never reprint jammed pages. |
| **Print Recovery**<br>Jam Assist<br>On<br>Off | **Notes:**<br>• On is the factory default setting. On sets the printer to automatically dump blank pages or partially printed pages to the standard bin after a jammed page has been cleared.<br>• Off requires the user to remove all pages from all possible jam locations. |
| **Print Recovery**<br>Page Protect<br>Off<br>On | Successfully print a page that may not have printed otherwise.<br>**Notes:**<br>• Off is the factory default setting. Off prints a partial page when there is not enough memory to print the whole page.<br>• On sets the printer to process the whole page so that the entire page prints. |

| Use | To |
|---|---|
| **Press Sleep Button**<br>Do nothing<br>Sleep<br>Hibernate | Determine how the printer, while in idle state, reacts to a short press of the Sleep button.<br>**Note:** Sleep is the factory default setting. |
| **Press and Hold Sleep Button**<br>Do nothing<br>Sleep<br>Hibernate | Determine how the printer, while in idle state, reacts to a long press of the Sleep button.<br>**Note:** Sleep is the factory default setting. |
| **Factory Defaults**<br>Do Not Restore<br>Restore Now | Use the printer factory default settings.<br>**Notes:**<br>• Do Not Restore is the factory default setting. Do Not Restore retains the user-defined settings.<br>• Restore Now sets all printer settings to the factory default settings except Network/Ports menu settings. All downloads stored in the RAM are deleted. Downloads stored in the flash memory are not affected. |
| **Custom Home Message**<br>Off<br>IP Address<br>Hostname<br>Contact Name<br>Location<br>Zero Configuration Name<br>Custom Text 1 | Select a custom home message that appears as an alternating display of the printer status.<br>**Note:** Off is the factory default setting. |

# Print Settings

## Setup menu

| Use | To |
|---|---|
| **Printer Language**<br>PCL Emulation<br>PS Emulation | Set the default printer language.<br>**Notes:**<br>• PCL Emulation is the factory default setting.<br>• PostScript emulation uses a PostScript interpreter for processing print jobs.<br>• PCL Emulation uses a PCL interpreter for processing print jobs.<br>• Setting a printer language default does not prevent a software program from sending print jobs that use another printer language. |

| Use | To |
| --- | --- |
| **Print Area**<br>Normal<br>Whole Page | Set the logical and physical printable area.<br>**Notes:**<br>• Normal is the factory default setting. When attempting to print data on the non-printable area defined by the Normal setting, the printer clips the image at the boundary.<br>• Whole Page allows the image to be moved into the non-printable area defined by the Normal setting. This setting affects only pages printed using a PCL 5 interpreter and has no effect on pages printed using the PCL XL or PostScript interpreter. |
| **Download Target**<br>RAM<br>Flash | Set the storage location for downloads.<br>**Notes:**<br>• RAM is the factory default setting. Storing downloads in the RAM is temporary.<br>• Storing downloads in a flash memory places them in permanent storage. Downloads remain in the flash memory even when the printer is turned off.<br>• This menu item appears only when an optional flash memory is installed. |
| **Resource Save**<br>On<br>Off | Specify how the printer handles temporary downloads, such as fonts and macros stored in the RAM, when the printer receives a print job that requires more than the available memory.<br>**Notes:**<br>• Off is the factory default setting. Off sets the printer to retain downloads only until memory is needed. Downloads are deleted in order to process print jobs.<br>• On sets the printer to retain downloads during language changes and printer resets. If the printer runs out of memory, then **`Memory Full [38]`** appears on the printer display, but downloads are not deleted. |

## Finishing menu

| Use | To |
|---|---|
| **Sides (Duplex)**<br>1 sided<br>2 sided | Specify whether two-sided (duplex) printing is set as the default for all print jobs.<br>**Notes:**<br>• "1 sided" is the factory default setting.<br>• You can set two-sided printing from the software program.<br>For Windows users:<br>**1** Click **File** > **Print**.<br>**2** Click **Properties**, **Preferences**, **Options**, or **Setup**.<br>For Macintosh users:<br>**1** Choose **File** > **Print**.<br>**2** Adjust the settings from the print dialog and pop-up menus. |
| **Duplex Binding**<br>Long Edge<br>Short Edge | Define the way two-sided pages are bound and printed.<br>**Notes:**<br>• Long Edge is the factory default setting. Long Edge binds pages along their long edge (left edge for portrait and top edge for landscape).<br>• Short Edge binds pages along their short edge (top edge for portrait and left edge for landscape). |
| **Copies**<br>1–999 | Specify the default number of copies for each print job.<br>**Note:** 1 is the factory default setting. |
| **Blank Pages**<br>Do Not Print<br>Print | Specify whether to insert blank pages in a print job.<br>**Note:** Do Not Print is the factory default setting. |
| **Collate**<br>(1,1,1) (2,2,2)<br>(1,2,3) (1,2,3) | Stack the pages of a print job in sequence when printing multiple copies.<br>**Note:** "(1,2,3) (1,2,3)" is the factory default setting. |
| **Separator Sheets**<br>Off<br>Between Copies<br>Between Jobs<br>Between Pages | Specify whether to insert blank separator sheets.<br>**Notes:**<br>• Off is the factory default setting.<br>• Between Copies inserts a blank sheet between each copy of a print job if Collate is set to (1,1,1) (2,2,2). If Collate is set to (1,2,3) (1,2,3), then a blank page is inserted between each set of printed pages, such as after all page 2's and after all page 3's.<br>• Between Jobs inserts a blank sheet between print jobs.<br>• Between Pages inserts a blank sheet between each page of a print job. This setting is useful when printing transparencies or when inserting blank pages in a document. |
| **Separator Source**<br>Tray [x]<br>Multi-Purpose Feeder | Specify the paper source for separator sheets.<br>**Note:** Tray 1 (standard tray) is the factory default setting. |

| Use | To |
|---|---|
| **Paper Saver**<br>Off<br>2-Up<br>3-Up<br>4-Up<br>6-Up<br>9-Up<br>12-Up<br>16-Up | Print multiple-page images on one side of a paper.<br>**Notes:**<br>• Off is the factory default setting.<br>• The number selected is the number of page images that will print per side. |
| **Paper Saver Ordering**<br>Horizontal<br>Reverse Horizontal<br>Reverse Vertical<br>Vertical | Specify the positioning of multiple-page images when using Paper Saver.<br>**Notes:**<br>• Horizontal is the factory default setting.<br>• Positioning depends on the number of page images and whether they are in portrait or landscape orientation. |
| **Paper Saver Orientation**<br>Auto<br>Landscape<br>Portrait | Specify the orientation of a multiple-page document.<br>**Note:** Auto is the factory default setting. The printer chooses between portrait and landscape. |
| **Paper Saver Border**<br>None<br>Solid | Print a border when using Paper Saver.<br>**Note:** None is the factory default setting. |

## Quality menu

| Use | To |
|---|---|
| **Print Resolution**<br>300 dpi<br>600 dpi<br>1200 dpi<br>1200 Image Q<br>2400 Image Q | Specify the printed output resolution in dots per inch.<br>**Note:** 600 dpi is the factory default setting. |
| **Pixel Boost**<br>Off<br>Fonts<br>Horizontally<br>Vertically<br>Both directions<br>Isolated | Enable more pixels to print in clusters for clarity, in order to enhance images horizontally or vertically, or to enhance fonts.<br>**Note:** Off is the factory default setting. |
| **Toner Darkness**<br>1–10 | Lighten or darken the printed output.<br>**Notes:**<br>• 8 is the factory default setting.<br>• Selecting a smaller number can help conserve toner. |

| Use | To |
|---|---|
| **Enhance Fine Lines**<br>On<br>Off | Enable a print mode preferable for files such as architectural drawings, maps, electrical circuit diagrams, and flow charts.<br>**Notes:**<br>• Off is the factory default setting.<br>• You can set this option from the printer software. For Windows users, click **File** > **Print**, and then click **Properties**, **Preferences**, **Options**, or **Setup**. For Macintosh users, choose **File** > **Print**, and then adjust the settings from the Print dialog and pop-up menus.<br>• To set this option using the Embedded Web Server, type the network printer IP address in the Web browser address field. |
| **Gray Correction**<br>Auto<br>Off | Automatically adjust the contrast enhancement applied to images.<br>**Note:** Auto is the factory default setting. |
| **Brightness**<br>-6 to 6 | Adjust the printed output either by lightening or darkening it. You can conserve toner by lightening the output.<br>**Note:** 0 is the factory default setting. |
| **Contrast**<br>0–5 | Adjust the contrast of printed objects.<br>**Note:** 0 is the factory default setting. |

## Utilities menu

| Use | To |
|---|---|
| **Format Flash**<br>Yes<br>No | Format the flash memory.<br>**Warning—Potential Damage:** Do not turn off the printer while the flash memory is being formatted.<br>**Notes:**<br>• Flash memory refers to the memory added by installing a flash memory card in the printer.<br>• Yes deletes all data stored in the flash memory.<br>• No cancels the format request.<br>• The flash memory option card must not be read/write- or write-protected.<br>• This menu item appears only when a non-defective flash memory card is installed. |
| **Hex Trace** | Assist in isolating the source of a print job problem.<br>**Notes:**<br>• When activated, all data sent to the printer is printed in hexadecimal and character representation, and control codes are not executed.<br>• To exit or deactivate Hex Trace, turn off or reset the printer. |
| **Coverage Estimator**<br>Off<br>On | Provide an estimate of the percentage coverage of toner on a page. The estimate is printed on a separate page at the end of each print job.<br>**Note:** Off is the factory default setting. |

## XPS menu

| Use | To |
|---|---|
| **Print Error Pages**<br>Off<br>On | Print a page containing information on errors, including XML markup errors.<br>**Note:** Off is the factory default setting. |

## PostScript menu

| Use | To |
|---|---|
| **Print PS Error**<br>On<br>Off | Print a page containing the PostScript error.<br>**Note:** Off is the factory default setting. |
| **Lock PS Startup Mode**<br>On<br>Off | Disable the SysStart file.<br>**Note:** Off is the factory default setting. |
| **Font Priority**<br>Resident<br>Flash | Establish the font search order.<br>**Notes:**<br>• Resident is the factory default setting.<br>• This menu item is available only when a formatted flash memory card is installed and operating properly.<br>• Make sure the flash memory card is not read/write-, write-, or password-protected.<br>• Job Buffer Size must not be set to 100%. |

## PCL Emul menu

| Use | To |
|---|---|
| **Font Source**<br>Resident<br>Download<br>Flash<br>All | Specify the set of fonts used by the Font Name menu.<br>**Notes:**<br>• “Resident” is the factory default setting. “Resident” shows the factory default set of fonts downloaded in the RAM.<br>• “Download” shows all the fonts downloaded in the RAM.<br>• “Flash” shows all fonts resident in that option. The optional flash memory card must be properly formatted and cannot be read/write-, write-, or password-protected.<br>• “All” shows all fonts available to any option. |
| **Font Name**<br>Courier 10 | Identify a specific font and the option where it is stored.<br>**Note:** Courier 10 is the factory default setting. Courier 10 shows the font name, font ID, and the storage location in the printer. The font source abbreviation is R for Resident, F for Flash, and D for Download. |

| Use | To |
|---|---|
| **Symbol Set**<br>10U PC-8<br>12U PC-850 | Specify the symbol set for each font name.<br>**Notes:**<br>• 10U PC-8 is the US factory default setting. 12U PC-850 is the international factory default setting.<br>• A symbol set is a set of alphabetic and numeric characters, punctuation, and special symbols. Symbol sets support the different languages or specific program, such as math symbols for scientific text. Only the supported symbol sets are shown. |
| **PCL Emulation Settings**<br>Point Size<br>1.00–1008.00 | Change the point size for scalable typographic fonts.<br>**Notes:**<br>• 12 is the factory default setting.<br>• Point size refers to the height of the characters in the font. One point equals approximately 0.014 inch.<br>• Point sizes can be increased or decreased in 0.25-point increments. |
| **PCL Emulation Settings**<br>Pitch<br>0.08–100 | Specify the font pitch for scalable monospaced fonts.<br>**Notes:**<br>• 10 is the factory default setting.<br>• Pitch refers to the number of fixed-space characters per inch (cpi).<br>• Pitch can be increased or decreased in 0.01-cpi increments.<br>• For nonscalable monospaced fonts, the pitch appears on the display but it cannot be changed. |
| **PCL Emulation Settings**<br>Orientation<br>Portrait<br>Landscape | Specify the orientation of text and graphics on the page.<br>**Notes:**<br>• Portrait is the factory default setting. Portrait prints text and graphics parallel to the short edge of the page.<br>• Landscape prints text and graphics parallel to the long edge of the page. |
| **PCL Emulation Settings**<br>Lines per Page<br>1–255 | Specify the number of lines that print on each page.<br>**Notes:**<br>• 60 is the US factory default setting. 64 is the international default setting.<br>• The printer sets the amount of space between each line based on the Lines per Page, Paper Size, and Orientation settings. Select the Paper Size and Orientation you want before setting Lines per Page. |
| **PCL Emulation Settings**<br>A4 Width<br>198 mm<br>203 mm | Set the printer to print on A4-size paper.<br>**Notes:**<br>• 198 mm is the factory default setting.<br>• The 203-mm setting sets the width of the page to allow printing of eighty 10-pitch characters. |

| Use | To |
|---|---|
| **PCL Emulation Settings**<br>Auto CR after LF<br>On<br>Off | Specify whether the printer automatically performs a carriage return (CR) after a line feed (LF) control command.<br>**Note:** Off is the factory default setting. |
| **PCL Emulation Settings**<br>Auto LF after CR<br>On<br>Off | Specify whether the printer automatically performs a line feed (LF) after a carriage return (CR) control command.<br>**Note:** Off is the factory default setting. |
| **Tray Renumber**<br>Assign MP Feeder<br>Off<br>None<br>0–199<br>Assign Tray [x]<br>Off<br>None<br>0–199<br>Assign Manual Paper<br>Off<br>None<br>0–199<br>Assign Manual Env<br>Off<br>None<br>0–199 | Configure the printer to work with printer software or programs that use different source assignments for trays and feeders.<br>**Notes:**<br>• Off is the factory default setting.<br>• None cannot be selected. It is only displayed when it is selected by the PCL 5 interpreter. It also ignores the Select Paper Feed command.<br>• 0–199 allows a custom setting to be assigned. |
| **Tray Renumber**<br>View Factory Defaults<br>MPF Default = 8<br>T1 Default = 1<br>T1 Default = 4<br>T1 Default = 5<br>T1 Default = 20<br>T1 Default = 21<br>Env Default = 6<br>MPaper Default = 2<br>MEnv Default = 3 | Display the factory default setting assigned to each tray or feeder. |
| **Tray Renumber**<br>Restore Defaults<br>Yes<br>No | Restore all tray and feeder assignments to their factory default settings. |

# Saving money and the environment

Lexmark is committed to environmental sustainability and is continually improving its printers to reduce their impact on the environment. We design with the environment in mind, engineer our packaging to reduce materials, and provide collection and recycling programs. For more information, see:

- The Notices chapter
- The Environmental Sustainability section of the Lexmark Web site at **www.lexmark.com/environment**
- The Lexmark recycling program at **www.lexmark.com/recycle**

By selecting certain printer settings or tasks, you may be able to reduce your printer's impact even further. This chapter outlines the settings and tasks that may yield a greater environmental benefit.

## Saving paper and toner

Studies show that as much as 80% of the carbon footprint of a printer is related to paper usage. You can significantly reduce your carbon footprint by using recycled paper and the following printing suggestions, such as printing on both sides of the paper and printing multiple pages on one side of a single sheet of paper.

For information on how you can quickly save paper and energy using one printer setting, see “Using Eco-Mode” on page 86.

### Using recycled paper

As an environmentally conscious company, Lexmark supports the use of recycled office paper produced specifically for use in laser printers. For more information on recycled papers that work well with your printer, see “Using recycled paper and other office papers” on page 45.

### Conserving supplies

#### Use both sides of the paper

If your printer model supports duplex printing, then you can control whether print appears on one or two sides of the paper by selecting **2-sided printing** from the Print dialog or from the Lexmark Toolbar.

#### Place multiple pages on one sheet of paper

You can print up to 16 consecutive pages of a multiple-page document onto one side of a single sheet of paper by selecting a setting from the Multipage printing (N-Up) section of the Print dialog screen.

#### Check your first draft for accuracy

Before printing or making multiple copies of a document:

- Use the preview feature, which you can select from the Print dialog or from the Lexmark Toolbar to see how the document will look like before you print it.
- Print one copy of the document to check its content and format for accuracy.

### Avoid paper jams

Correctly set the paper type and size to avoid paper jams. For more information, see “Avoiding jams” on page 105.

# Saving energy

## Using Eco-Mode

Use Eco-Mode to quickly select one or more ways to reduce your printer's environmental impact.

1 From the printer control panel, navigate to:

> **Settings** > > **General Settings** > > **Eco-Mode** > > select the setting you want

| Use | To |
|---|---|
| Off | Use the factory default settings for all settings associated with Eco-Mode. This setting supports the performance specifications for your printer. |
| Energy | Reduce energy use, especially when the printer is idle.<br>• Printer engine motors do not start until a document is ready to print. You may notice a short delay before the first page is printed.<br>• The printer enters Sleep mode after one minute of inactivity. |
| Energy/Paper | Use all the settings associated with Energy and Paper modes. |
| Paper | • Enable the automatic two-sided (duplex) printing feature.<br>• Turn off print log features. |

2 Press .

## Using Hibernate mode

Hibernate is an ultra-low-power operating mode. When operating in Hibernate mode, all other systems and devices are powered down safely.

**Note:** Hibernate mode can be scheduled. For more information, see “Using Schedule Power Modes” on page 88.

### Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**

- View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If your are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **General Settings** > **Sleep Button Settings**.

3 From the Press Sleep Button or Press and Hold Sleep Button drop-down menu, select **Hibernate**.

4 Click **Submit**.

**Note:** If the printer is in Hibernate mode, the Embedded Web Server is disabled.

### Using the printer control panel

1 From the printer control panel, navigate to:

> **Settings** > OK > **General Settings** > OK

2 Press **Press Sleep Button** or **Press and Hold Sleep Button**, and then press OK.

3 Press **Hibernate** > OK.

**Notes:**

- When Press Sleep Button is set to Hibernate, a short press of the Sleep button sets the printer to Hibernate mode.
- When Press and Hold Sleep Button is set to Hibernate, a long press of the Sleep button sets the printer to Hibernate mode.

## Adjusting Sleep mode

To save energy, decrease the number of minutes before the printer enters Sleep mode.

Available settings range from 1 to 120 minutes. The factory default setting is 30 minutes.

**Note:** Sleep mode can be scheduled. For more information, see “Using Schedule Power Modes” on page 88.

### Using the Embedded Web Server

1 From the Embedded Web Server, click **Settings** > **General Settings** > **Timeouts**.

2 In the Sleep Mode field, enter the number of minutes you want the printer to wait before it enters Sleep mode.

3 Click **Submit**.

### Using the printer control panel

1 From the printer control panel, navigate to:

> **Settings** > OK > **General Settings** > OK > **Timeouts** > OK > **Sleep Mode** > OK

2 In the Sleep Mode field, select the number of minutes you want the printer to wait before it enters Sleep mode.

3 Press OK.

## Setting Hibernate Timeout

Hibernate Timeout lets you set the amount of time the printer waits after a print job is processed before it goes into a reduced power state.

### Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - Print a network setup page or menu settings page, and then locate the IP address in the TCP/IP section. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **General Settings** > **Timeouts**.
3. From the Hibernate Timeout menu, select the number of hours, days, weeks, or months you want for the printer to wait before it goes into a reduced power state.
4. Click **Submit**.

### Using the printer settings on the computer

Depending on your operating system, access the Hibernate Timeout menu using the Local Printer Settings Utility or Print Settings.

## Using Schedule Power Modes

Schedule Power Modes lets the user schedule when the printer goes into a reduced power state or into the Ready state.

### Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - Print a network setup page or menu settings page, and then locate the IP address in the TCP/IP section. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **General Settings** > **Schedule Power Modes**.
3. From the Action menu, select the power mode.
4. From the Time menu, select the time.
5. From the Day(s) menu, select the day or days.
6. Click **Add**.

### Using the printer settings on the computer (Windows only)

- Access the Schedule Power Modes menu using the Local Printer Settings Utility.

# Recycling

Lexmark provides collection programs and environmentally progressive approaches to recycling. For more information, see:

- The Notices chapter
- The Environmental Sustainability section of the Lexmark Web site at **www.lexmark.com/environment**
- The Lexmark recycling program at **www.lexmark.com/recycle**

## Recycling Lexmark products

To return Lexmark products for recycling:

1. Go to **www.lexmark.com/recycle**.
2. Find the product type you want to recycle, and then select your country or region from the list.
3. Follow the instructions on the computer screen.

**Note:** Printer supplies and hardware not listed in the Lexmark collection program may be recycled through your local recycling center. Contact your local recycling center to determine the items they accept.

## Recycling Lexmark packaging

Lexmark continually strives to minimize packaging. Less packaging helps to ensure that Lexmark printers are transported in the most efficient and environmentally sensitive manner and that there is less packaging to dispose of. These efficiencies result in fewer greenhouse emissions, energy savings, and natural resource savings.

Lexmark cartons are 100% recyclable where corrugated recycling facilities exist. Facilities may not exist in your area.

The foam used in Lexmark packaging is recyclable where foam recycling facilities exist. Facilities may not exist in your area.

When you return a cartridge to Lexmark, you can reuse the box that the cartridge came in. Lexmark will recycle the box.

## Returning Lexmark cartridges for reuse or recycling

Lexmark Cartridge Collection Program diverts millions of Lexmark cartridges from landfills annually by making it both easy and free for Lexmark customers to return used cartridges to Lexmark for reuse or recycling. One hundred percent of the empty cartridges returned to Lexmark are either reused or demanufactured for recycling. Boxes used to return the cartridges are also recycled.

To return Lexmark cartridges for reuse or recycling, follow the instructions that came with your printer or cartridge and use the prepaid shipping label. You can also do the following:

1. Go to **www.lexmark.com/recycle**.
2. From the Toner Cartridges section, select your country or region.
3. Follow the instructions on the computer screen.

# Securing the printer

## Using the security lock feature

The printer is equipped with a security lock feature. Attach a security lock compatible with most laptop computers in the location shown to secure the printer in place.



## Statement of Volatility

Your printer contains various types of memory that can store device and network settings, and user data.

| Type of memory | Description |
|---|---|
| Volatile memory | Your printer uses standard *random access memory* (RAM) to temporarily buffer user data during simple print jobs. |
| Non-volatile memory | Your printer may use two forms of non-volatile memory: EEPROM and NAND (flash memory). Both types are used to store operating system, device settings, and network information. |

Erase the content of any installed printer memory in the following circumstances:

- The printer is being decommissioned.
- The printer is being moved to a different department or location.
- The printer is being serviced by someone from outside your organization.
- The printer is being removed from your premises for service.
- The printer is being sold to another organization.

# Erasing volatile memory

The volatile memory (RAM) installed in your printer requires a power source to retain information. To erase the buffered data, simply turn off the printer.

# Erasing non-volatile memory

1. Turn off the printer.
2. From the printer control panel, hold down OK and the right arrow button while turning the printer on. Release the buttons only when the Configuration menu appears.
3. Press the arrow buttons until **Wipe All Settings** appears, and then press OK.

   The printer will restart several times during this process.

   **Note:** Wipe All Settings securely removes device settings, solutions, jobs, and passwords from the printer memory.
4. Press the arrow buttons until **Exit Config Menu** appears, and then press OK.

The printer will perform a power-on reset, and then return to normal operating mode.

# Finding printer security information

In high-security environments, it may be necessary to take additional steps to make sure that confidential data stored in the printer cannot be accessed by unauthorized persons. For more information, visit the **Lexmark security Web page**.

You can also see the *Embedded Web Server Administrator's Guide* for additional information:

1. Go to **http://support.lexmark.com**, and then navigate to **Software and Solutions** > **Other Applications**.
2. Click the **Manuals** tab, and then select the *Embedded Web Server Administrator's Guide*.

# Maintaining the printer

**Warning—Potential Damage:** Failure to maintain optimum printer performance, or to replace parts and supplies, may cause damage to your printer.

## Cleaning the printer

### Cleaning the printer

**Note:** You may need to perform this task after every few months.

**Warning—Potential Damage:** Damage to the printer caused by improper handling is not covered by the printer warranty.

1. Make sure that the printer is turned off and unplugged from the electrical outlet.

   **CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock when cleaning the exterior of the printer, unplug the power cord from the electrical outlet and disconnect all cables from the printer before proceeding.

2. Remove paper from the standard bin and multipurpose feeder.
3. Remove any dust, lint, and pieces of paper around the printer using a soft brush or vacuum.
4. Dampen a clean, lint-free cloth with water, and use it to wipe the outside of the printer.

   **Warning—Potential Damage:** Do not use household cleaners or detergents to prevent damage to the exterior of the printer.

5. Make sure all areas of the printer are dry before sending a new print job.

## Checking the status of parts and supplies

A message appears on the display when a replacement supply item is needed or when maintenance is required.

### Checking the status of parts and supplies

#### Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Device Status** > **More Details**.

### Using the printer control panel

From the printer control panel, navigate to:

> **Reports** > > **Device Statistics** >

**Note:** You can view the status of parts and supplies in the “Supply Information” section of the pages printed.

# Estimated number of remaining pages

The estimated number of remaining pages is based on the recent printing history of the printer. Its accuracy may vary significantly and is dependent on many factors, such as actual document content, print quality settings, and other printer settings.

The accuracy of the estimated number of remaining pages may decrease when the actual printing consumption is different from the historical printing consumption. Consider the variable level of accuracy before purchasing or replacing supplies based on the estimate. Until an adequate print history is obtained on the printer, initial estimates assume future supplies consumption based on the International Organization for Standardization* test methods and page content.

* Average continuous black declared cartridge yield in accordance with ISO/IEC 19752.

# Ordering supplies

To order supplies in the U.S., contact Lexmark at 1-800-539-6275 for information about Lexmark authorized supplies dealers in your area. In other countries or regions, visit the Lexmark Web Site at **www.lexmark.com** or contact the place where you purchased the printer.

**Note:** All life estimates for printer supplies assume printing on letter- or A4-size plain paper.

## Using genuine Lexmark parts and supplies

Your Lexmark printer is designed to function best with genuine Lexmark supplies and parts. Use of third-party supplies or parts may affect the performance, reliability, or life of the printer and its imaging components. Use of third-party supplies or parts can affect warranty coverage. Damage caused by the use of third-party supplies or parts is not covered by the warranty. All life indicators are designed to function with Lexmark supplies and parts, and may deliver unpredictable results if third-party supplies or parts are used. Imaging component usage beyond the intended life may damage your Lexmark printer or its associated components.

## Ordering toner cartridges

**Notes:**

- The estimated cartridge yield is based on the ISO/IEC 19752 standard.
- Extremely low print coverage for extended periods of time may negatively affect actual yield.

| Item | Return Program cartridge |
|---|---|
| **For the United States and Canada** | |
| Toner Cartridge | 501 |
| High Yield Toner Cartridge | 501H |
| Extra High Yield Toner Cartridge | 501X[1] |
| Ultra High Yield Toner Cartridge | 501U[2] |
| **For the European Union, European Economic Area , and Switzerland** | |
| Toner Cartridge | 502 |
| High Yield Toner Cartridge | 502H |
| Extra High Yield Toner Cartridge | 502X[1] |
| Ultra High Yield Toner Cartridge | 502U[2] |
| **For the Asia Pacific Region (includes Australia and New Zealand)** | |
| Toner Cartridge | 503 |
| High Yield Toner Cartridge | 503H |
| Extra High Yield Toner Cartridge | 503X[1] |
| Ultra High Yield Toner Cartridge | 503U[2] |
| **For Latin America (includes Puerto Rico and Mexico)** | |
| Toner Cartridge | 504 |
| High Yield Toner Cartridge | 504H |
| Extra High Yield Toner Cartridge | 504X[1] |
| Ultra High Yield Toner Cartridge | 504U[2] |
| **For Africa, Middle East, Central Eastern Europe, and Commonwealth of Independent States** | |
| Toner Cartridge | 505 |
| High Yield Toner Cartridge | 505H |
| Extra High Yield Toner Cartridge | 505X[1] |
| Ultra High Yield Toner Cartridge | 505U[2] |

[1] This cartridge is supported only in MS410d, MS410dn, MS510dn, MS610dn, and MS610de printer models.

[2] This cartridge is supported only in MS510dn, MS610dn, and MS610de printer models.

For more information on countries located in each region, visit **www.lexmark.com/regions**.

| Item | Regular cartridge |
|---|---|
| **Worldwide** | |
| High Yield Toner Cartridge | 500HA[1] |

[1] This cartridge is supported only in MS310d and MS310dn printer models.

[2] This cartridge is supported only in MS410d and MS410dn printer models.

[3] This cartridge is supported only in MS510dn, MS610dn, and MS610de printer models.

| Item | Regular cartridge |
|---|---|
| Extra High Yield Toner Cartridge | 500XA[2] |
| Ultra High Yield Toner Cartridge | 500UA[3] |

[1] This cartridge is supported only in MS310d and MS310dn printer models.

[2] This cartridge is supported only in MS410d and MS410dn printer models.

[3] This cartridge is supported only in MS510dn, MS610dn, and MS610de printer models.

## Ordering an imaging unit

Extremely low print coverage for extended periods of time may cause imaging unit parts to fail prior to exhaustion of toner from toner cartridge.

For more information on replacing the imaging unit, see the instruction sheet that came with the supply.

| Part name | Lexmark Return Program | Regular |
|---|---|---|
| Imaging unit | 500Z | 500ZA |

# Storing supplies

Choose a cool, clean storage area for the printer supplies. Store supplies right side up in their original packing until you are ready to use them.

Do not expose supplies to:

- Direct sunlight
- Temperatures above 35°C (95°F)
- High humidity above 80%
- Salty air
- Corrosive gases
- Heavy dust

# Replacing supplies

## Replacing the toner cartridge

1 Press the button on the right side of the printer, and then open the front door.




2 Pull the toner cartridge out using the handle.



3 Unpack the toner cartridge, and then remove all packing materials.

4 Shake the new cartridge to redistribute the toner.



5 Insert the toner cartridge into the printer by aligning the side rails of the cartridge with the arrows on the side rails inside the printer.

**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.



6 Close the front door.

## Replacing the imaging unit

1 Press the button on the right side of the printer, and then open the front door.




2 Pull the toner cartridge out using the handle.



**3** Lift the green handle, and then pull the imaging unit out of the printer.



**4** Unpack the new imaging unit, and then shake it.



**5** Remove all packing materials from the imaging unit.

**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.

**Warning—Potential Damage:** Do not touch the photoconductor drum. Doing so may affect the print quality of future print jobs.



6 Insert the imaging unit into the printer by aligning the arrows on the side rails of the imaging unit with the arrows on the side rails inside the printer.



7 Insert the toner cartridge into the printer by aligning the side rails of the cartridge with the arrows on the side rails inside the printer.



8 Close the front door.

# Moving the printer

## Before moving the printer

**CAUTION—POTENTIAL INJURY:** Before moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Turn the printer off using the power switch, and then unplug the power cord from the electrical outlet.
- Disconnect all cords and cables from the printer before moving it.

- If an optional tray is installed, then remove it from the printer. To remove the optional tray, slide the latch on the right side of the tray toward the front of the tray until it *clicks* into place.

- Use the handholds located on both sides of the printer to lift it.
- Make sure your fingers are not under the printer when you set it down.
- Before setting up the printer, make sure there is adequate clearance around it.

Use only the power cord provided with this product or the manufacturer's authorized replacement.

**Warning—Potential Damage:** Damage to the printer caused by improper moving is not covered by the printer warranty.

## Moving the printer to another location

The printer and its hardware options can be safely moved to another location by following these precautions:

- Any cart used to move the printer must have a surface able to support the full footprint of the printer.
- Any cart used to move the hardware options must have a surface able to support the dimensions of the hardware options.
- Keep the printer in an upright position.
- Avoid severe jarring movements.

## Shipping the printer

When shipping the printer, use the original packaging.

# Managing the printer

## Finding advanced networking and administrator information

This chapter covers basic administrative support tasks using the Embedded Web Server. For more advanced system support tasks, see the *Networking Guide* on the *Software and Documentation* CD or the *Embedded Web Server Administrator's Guide* on the Lexmark Web site at **http://support.lexmark.com**.

## Checking the virtual display

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - Print a network setup page or menu settings page, and then locate the IP address in the TCP/IP section. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Press **Enter** to open the Web page of your printer.
3. Click **Applications** > **Remote Operator Panel** > **Launch VNC Applet**.

   **Note:** VNC Applet requires a Java plug-in to launch.

4. Click **Click here to continue**.

The virtual display works as an actual display would work on a printer control panel.

## Viewing reports

You can view some reports from the Embedded Web Server. These reports are useful for assessing the status of the printer, network, and supplies.

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Reports**, and then click the type of report you want to view.

## Configuring supply notifications from the Embedded Web Server

You can determine how you would like to be notified when supplies run nearly low, low, very low, or reach their end-of-life by setting the selectable alerts.

**Notes:**

- Selectable alerts can be set on the toner cartridge and imaging unit.
- All selectable alerts can be set for nearly low, low, and very low supply conditions. Not all selectable alerts can be set for the end-of-life supply condition. E-mail selectable alert is available for all supply conditions.
- The percentage of estimated remaining supply that prompts the alert can be set on some supplies for some supply conditions.

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Print Settings** > **Supply Notifications**.

3. From the drop-down menu for each supply, select one of the following notification options:

| Notification | Description |
|---|---|
| Off | The normal printer behavior for all supplies occurs. |
| E-mail Only | The printer generates an e-mail when the supply condition is reached. The status of the supply will appear on the menus page and status page. |
| Warning | The printer displays the warning message and generates an e-mail about the status of the supply. The printer does not stop when the supply condition is reached. |
| Continuable Stop[1] | The printer stops processing jobs when the supply condition is reached, and the user needs to press a button to continue printing. |
| Non Continuable Stop[1,2] | The printer stops when the supply condition is reached. The supply must be replaced to continue printing. |
| [1] The printer generates an e-mail about the status of the supply when supply notification is enabled.<br>[2] The printer stops when some supplies become empty to prevent damage. | |

4. Click **Submit**.

# Modifying confidential print settings

**Note:** This feature is available only in network printers or printers connected to print servers.

1. Open a Web browser, and then type the printer IP address in the address field.

   **Notes:**

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Configuration** > **Other Settings** tab > **Security** > **Confidential Print Setup**.

3 Modify the settings:
- Set a maximum number of PIN entry attempts. When a user exceeds a specific number of PIN entry attempts, all of the jobs for that user are deleted.
- Set an expiration time for confidential print jobs. When a user has not printed the jobs within the specified time, all of the jobs for that user are deleted.

4 Save the modified settings.

# Copying printer settings to other printers

**Note:** This feature is available only in network printers.

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**
- View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click the **Copy Printer Settings**.

3 To change the language, select a language from the drop-down menu, and then click **Click here to submit language**.

4 Click **Printer Settings**.

5 Type the IP addresses of the source and target printers in their appropriate fields.

**Note:** If you want to add or remove a target printer, then click **Add Target IP** or **Remove Target IP**.

6 Click **Copy Printer Settings**.

# Restoring factory default settings

If you want to keep a list of the current menu settings for reference, then print a menu settings page before restoring the factory default settings. For more information, see “Printing a menu settings page” on page 29.

If you want a more comprehensive method of restoring the printer factory default settings, then perform the Wipe All Settings option. For more information, see “Erasing non-volatile memory” on page 91.

**Warning—Potential Damage:** Restoring factory defaults returns most printer settings to the original factory default settings. Exceptions include the display language, custom sizes and messages, and Network/Port menu settings. All downloads stored in the RAM are deleted.

From the printer control panel, navigate to:

> **Settings** > > **General Settings** > > **Factory Defaults** > > **Restore Now** >

# Creating a printer control panel PIN

The Panel PIN Protect menu lets you restrict access to the menus from the printer control panel. To restrict access to the menus, create a Personal Identification Number (PIN), and then assign the PIN to each menu.

1 Open a Web browser, and then type the printer IP address in the address field.

**Notes:**

- View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Security** > **Panel PIN Protect**.
3. From the Create User PIN or Create Admin PIN sections, enter your PIN.

   **Note:** Your can enter up to 16 digits for your PIN.
4. Click **Modify**.
5. From any menu in the Administrative Menus, Management, or Function Access sections, select **User PIN Protected** or **Admin PIN Protected** or **Admin PIN and User PIN Protected**.

   **Note:** Using an Admin PIN, you can still access a menu assigned with a User PIN.
6. Click **Submit**.

If you try to access a PIN-protected menu from the printer control panel, the printer will require you to enter the PIN.

**Note:** After you enter the last digit of the PIN, make sure to press OK on the printer control panel for more than three seconds.

# Clearing jams

Carefully select paper and specialty media and load them properly to avoid most jams. For more information, see “Avoiding jams” on page 105. If jams occur, then follow the steps outlined in this chapter.

**Note:** Jam recovery is set to Auto by default. The printer reprints jammed pages unless the memory required to hold the pages is needed for other printer tasks.

## Avoiding jams

### Load paper properly

- Make sure paper lies flat in the tray.




- Do not remove a tray while the printer is printing.
- Do not load a tray while the printer is printing. Load it before printing, or wait for a prompt to load it.
- Do not load too much paper. Make sure the stack height is below the maximum paper fill indicator.

- Do not slide the paper into the tray. Load paper as shown in the illustration.

- Make sure the guides in the tray or the multipurpose feeder are properly positioned and are not pressing tightly against the paper or envelopes.
- Push the tray firmly into the printer after loading paper.

### Use recommended paper

- Use only recommended paper or specialty media.
- Do not load wrinkled, creased, damp, bent, or curled paper.
- Flex, fan, and straighten paper before loading it.



- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, weights, or types in the same tray.
- Make sure the paper size and type are set correctly on the computer or printer control panel.
- Store paper according to manufacturer recommendations.

## Understanding jam messages and locations

When a jam occurs, a message indicating the jam location and information to clear the jam appears on the printer display. Open the doors, covers, and trays indicated on the display to remove the jam.

**Notes:**

- When Jam Assist is set to On, the printer automatically flushes blank pages or pages with partial prints to the standard bin after a jammed page has been cleared. Check your printed output stack for discarded pages.

- When Jam Recovery is set to On or Auto, the printer reprints jammed pages. However, the Auto setting does not guarantee that the page will print.




| | Area | Printer control panel message | What to do |
|---|---|---|---|
| **1** | Standard bin | Jam, standard bin [20y.xx] | Remove the jammed paper. |
| **2** | Rear door | Jam, rear door [20y.xx] | Open the rear door, and then remove the jammed paper. |
| **3** | Tray 1 | Jam, pull tray 1. Push down blue flap. [23y.xx] | Pull tray 1 completely out, then push the front duplex flap down, and then remove the jammed paper.<br>**Note:** You may need to open the rear door to clear some 23y.xx paper jams. |
| **4** | Tray [x] | Jam, tray [x] [24y.xx] | Pull the indicated tray out, and then remove the jammed paper. |
| **5** | Multipurpose feeder | Jam, MP feeder. [250.xx] | Remove all paper from the multipurpose feeder, and then remove the jammed paper. |
| **6** | Front door | Jam, front door. [20y.xx] | Open the front door, and then remove the toner cartridge, imaging unit, and jammed paper. |

# Jam, front door [20y.xx]

**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.

1 Press the button on the right side of the printer, and then open the front door.




2 Pull the toner cartridge out using the handle.



3 Lift the green handle, and then pull the imaging unit out of the printer.



**Warning—Potential Damage:** Do not touch the photoconductor drum. Doing so may affect the print quality of future print jobs.



4 Place the imaging unit aside on a flat, smooth surface.

**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light can cause print quality problems.

5 Lift the green flap in front of the printer.



6 Firmly grasp the jammed paper on each side, and then gently pull it out.

**Note:** Make sure all paper fragments are removed.



**7** Insert the imaging unit by aligning the arrows on the side rails of the unit with the arrows on the side rails inside the printer, and then insert the imaging unit into the printer.



**8** Insert the toner cartridge by aligning the side rails of the cartridge with the arrows on the side rails inside the printer, and then insert the cartridge into the printer.



**9** Close the front door.

**10** From the printer control panel, press OK to clear the message and continue printing.

# Jam, rear door [20y.xx]

1 Press the button on the right side of the printer, and then open the front door.




2 Gently pull down the rear door.

**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



3 Firmly grasp the jammed paper on each side, and then gently pull it out.

**Note:** Make sure all paper fragments are removed.



4 Close the rear and front doors.

5 From the printer control panel, press OK to clear the message and continue printing.

# Jam, standard bin [20y.xx]

1 Firmly grasp the jammed paper on each side, and then gently pull it out.

**Note:** Make sure all paper fragments are removed.



2 From the printer control panel, press OK to clear the message and continue printing.

# Jam, pull tray 1. Push down blue flap. [23y.xx]

**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.

1 Pull the tray out completely.

2 Locate the blue lever, and then pull it down to release the jam.



**Note:** If the jammed paper is not visible in the duplex area, then open the rear door, and then gently remove the jammed paper. Make sure all paper fragments are removed.

3 Firmly grasp the jammed paper on each side, and then gently pull it out.

**Note:** Make sure all paper fragments are removed.



4 Insert the tray.

5 From the printer control panel, press OK to clear the message and continue printing.

# Jam, tray [x] [24y.xx]

1 Pull out the tray completely.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.

**Note:** Make sure all paper fragments are removed.



3 Insert the tray.

4 From the printer control panel, press OK to clear the message and continue printing.

# Jam, MP feeder [250.xx]

1 From the multipurpose feeder, firmly grasp the jammed paper on each side, and then gently pull it out.

**Note:** Make sure all paper fragments are removed.



2 Flex the sheets of paper back and forth to loosen them, and then fan them. Do not fold or crease the paper. Straighten the edges on a level surface.



3 Reload paper into the multipurpose feeder.

**Note:** Make sure the paper guide lightly rests against the edge of the paper.

4 From the printer control panel, press OK to clear the message and continue printing.

# Troubleshooting

## Understanding the printer messages

### Cartridge, imaging unit mismatch [41.xy]

1 Check if both the toner cartridge and imaging unit are *MICR* (Magnetic Ink Character Recognition) or non-MICR supplies.

**Note:** For a list of supported supplies, see the “Ordering supplies” section of the *User's Guide* or visit www.lexmark.com.

2 Change the toner cartridge or imaging unit so that both are MICR or non-MICR supplies.

**Notes:**

- Use a MICR toner cartridge and imaging unit for printing checks and other similar documents.
- Use a non-MICR toner cartridge and imaging unit for regular print jobs.

### Cartridge nearly low [88.xy]

If necessary, press OK on the printer control panel to clear the message and continue printing.

### Cartridge very low, [x] estimated pages remain [88.xy]

You may need to replace a toner cartridge very soon. For more information, see the “Replacing supplies” section of the *User’s Guide*.

If necessary, press OK on the printer control panel to clear the message and continue printing.

### Cartridge low [88.xy]

You may need to order a toner cartridge. If necessary, press OK on the printer control panel to clear the message and continue printing.

### Imaging unit nearly low [84.xy]

If necessary, press OK on the printer control panel to clear the message and continue printing.

### Imaging unit very low, [x] estimated pages remain [84.xy]

You may need to replace the imaging unit very soon. For more information, see the “Replacing supplies” section of the *User’s Guide*.

If necessary, press OK on the printer control panel to clear the message and continue printing.

## Imaging unit low [84.xy]

You may need to order an imaging unit. If necessary, press OK on the printer control panel to clear the message and continue printing.

## Change [paper source] to [custom type name]. Load [orientation].

Try one or more of the following:

- Load the correct size and type of paper in the tray, and then press OK on the printer control panel.

  **Note:** Make sure the paper size and type settings are specified in the Paper menu on the printer control panel.
- Cancel the print job.

## Change [paper source] to [custom string]. Load [orientation].

Try one or more of the following:

- Load the correct size and type of paper in the tray, and then press OK on the printer control panel.

  **Note:** Make sure the paper size and type settings are specified in the Paper menu on the printer control panel.
- Cancel the print job.

## Change [paper source] to [paper size]. Load [orientation].

Try one or more of the following:

- Load the correct size and type of paper in the tray, and then press OK on the printer control panel.

  **Note:** Make sure the paper size and type settings are specified in the Paper menu on the printer control panel.
- Cancel the print job.

## Change [paper source] to [paper type] [paper size]. Load [orientation].

Try one or more of the following:

- Load the correct size and type of paper in the tray, and then press OK on the printer control panel.

  **Note:** Make sure the paper size and type settings are specified in the Paper menu on the printer control panel.
- Cancel the print job.

## Close front door

Close the front door of the printer.

## Complex page may misprint [39]

Try one or more of the following:

- From the printer control panel, press OK to clear the message and continue printing.
- Reduce the number and size of fonts, the number and complexity of images, and the number of pages in the print job.
- Cancel the print job.
- Install additional printer memory.

## Defective flash memory [51]

Try one or more of the following:

- Replace the defective flash memory card.
- From the printer control panel, press OK to ignore the message and continue printing.
- Cancel the current print job.

## Paper too short [34]

Try one or more of the following:

- Load the correct size of paper in the tray.
- From the printer control panel, press OK to clear the message and print using a different tray.
- Check the tray length and width guides and make sure the paper is loaded properly in the tray.
- Make sure the correct paper size and type are specified in Print Properties or in the Print dialog.
- Make sure the paper size and type settings are specified in the Paper menu on the printer control panel.
- Make sure the paper size is correctly set. For example, if the MP Feeder Size is set to Universal, then make sure the paper is large enough for the data being printed.
- Cancel the print job.

## Insert tray [x]

Insert the indicated tray into the printer.

## Memory low, no Resource Save [35]

Try one or more of the following:

- From the printer control panel, press OK to disable Resource Save, clear the message, and continue printing.
- Install additional printer memory.

## Cannot collate large document [37]

Try one or more of the following:

- From the printer control panel, press OK to print the portion of the job already stored and begin collating the rest of the print job.
- Cancel the current print job.

## Cannot defrag flash memory [37]

Try one or more of the following:

- From the printer control panel, press OK to stop the defragmentation and continue printing.
- Delete fonts, macros, and other data in the printer memory. From the printer control panel, navigate to:

  > **Settings** > OK > **Print Settings** > OK > **Utilities Menu** > OK > **Format Flash** > OK > **Yes** > OK
- Install additional printer memory.

## Load [paper source] with [custom type name] [orientation]

Try one or more of the following:

- Load the tray or feeder with the correct size and type of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If the printer finds a tray that has the correct size and type of paper, then it feeds from that tray. If the printer cannot find a tray that has the correct size and type of paper, then it prints from the default paper source.
- Cancel the current job.

## Load [paper source] with [custom string] [orientation]

Try one or more of the following:

- Load the indicated tray or feeder with the correct size and type of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If the printer finds a tray that has the correct paper type and size, then it feeds from that tray. If the printer cannot find a tray that has the correct size and type of paper, then it prints from the default paper source.
- Cancel the current job.

## Load [paper source] with [paper size] [orientation]

Try one or more of the following:

- Load the tray or feeder with the correct size of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If the printer finds a tray that has the correct paper size, then it feeds from that tray. If the printer cannot find a tray that has the correct size of paper, then it prints from the default paper source.
- Cancel the current job.

## Load [paper source] with [paper type] [paper size] [orientation]

Try one or more of the following:

- Load the tray or feeder with the correct size and type of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If the printer finds a tray that has the correct size and type of paper, then it feeds from that tray. If the printer cannot find a tray that has the correct size and type of paper, then it prints from the default paper source.
- Cancel the current job.

## Load MP feeder with [custom type name] [orientation]

Try one or more of the following:

- Load the feeder with the correct size and type of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If no paper is loaded in the feeder, then the printer manually overrides the request, and then prints from an automatically selected tray.
- Cancel the current job.

## Load MP feeder with [custom string] [orientation]

Try one or more of the following:

- Load the feeder with the correct size and type of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If no paper is loaded in the feeder, then the printer manually overrides the request, and then prints from an automatically selected tray.
- Cancel the current job.

## Load MP feeder with [paper size] [orientation]

Try one or more of the following:

- Load the feeder with the correct size of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If no paper is loaded in the feeder, then the printer manually overrides the request, and then prints from an automatically selected tray.
- Cancel the current job.

## Load MP feeder with [paper type] [paper size] [orientation]

Try one or more of the following:

- Load the feeder with the correct size and type of paper.
- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** If no paper is loaded in the feeder, then the printer manually overrides the request, and then prints from an automatically selected tray.
- Cancel the current job.

## Memory full [38]

Try one or more of the following:

- From the printer control panel, press OK to clear the message.
- Decrease the resolution setting.
- Install additional printer memory.

## Non-Lexmark [supply type], see User's Guide [33.xy]

**Note:** The supply type can either be a toner cartridge or imaging unit.

The printer has detected a non-Lexmark supply or part installed in the printer.

Your Lexmark printer is designed to function best with genuine Lexmark supplies and parts. Use of third-party supplies or parts may affect the performance, reliability, or life of the printer and its imaging components.

All life indicators are designed to function with Lexmark supplies and parts, and may deliver unpredictable results if third-party supplies or parts are used. Imaging component usage beyond the intended life may damage your Lexmark printer or associated components.

**Warning—Potential Damage:** Use of third-party supplies or parts can affect warranty coverage. Damage caused by the use of third-party supplies or parts are not covered by the warranty.

To accept any and all of these risks and to proceed with the use of non-genuine supplies or parts in your printer, press OK and ✕ on the printer control panel simultaneously for 15 seconds to clear the message and continue printing.

If you do not wish to accept these risks, then remove the third-party supply or part from your printer, and then install a genuine Lexmark supply or part.

**Note:** For the list of supported supplies, see the “Ordering supplies” section of the *User's Guide* or visit **http://support.lexmark.com**.

## Network error, port [x] [54]

Try one or more of the following:

- From the printer control panel, press OK to clear the message and continue printing.
- Unplug the router, then wait for 30 seconds, and then plug it back again.
- Turn off the printer, then wait for about 10 seconds, and then turn the printer back on.
- Update the network firmware in the printer or the print server. For more information, contact customer support.

## Flash memory full [52]

Try one or more of the following:

- From the printer control panel, press OK to clear the message and continue printing.
- Delete fonts, macros, and other data stored in the flash memory. From the printer control panel, navigate to:

  > **Settings** > OK > **Print Settings** > OK > **Utilities Menu** > OK > **Format Flash** > OK > **Yes** > OK
- Use a larger-capacity flash memory card.

**Note:** Downloaded fonts and macros that are not stored in the flash memory are deleted when the printer is powered off or restarted.

## Replace cartridge, 0 estimated pages remain [88.xy]

Replace the toner cartridge to clear the message and continue printing. For more information, see the instruction sheet that came with the supply or see the “Replacing supplies” section of the *User’s Guide*.

**Note:** If you do not have a replacement cartridge, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

## Printer restart. Check last job.

Press OK on the printer control panel to clear the message and continue printing.

For more information, visit **http://support.lexmark.com** or contact customer support.

## Replace cartridge, printer region mismatch [42.xy]

Install a toner cartridge that matches the region number of the printer. *x* indicates the value of the printer region. *y* indicates the value of the cartridge region. x and y can have the following values:

**Printer and toner cartridge regions**

| Region number | Region |
|---|---|
| 0 | Global |
| 1 | United States, Canada |
| 2 | European Economic Area (EEA), Switzerland |
| 3 | Asia Pacific, Australia, New Zealand |
| 4 | Latin America |
| 5 | Africa, Middle East, rest of Europe |
| 9 | Invalid |

**Notes:**

- The x and y values represent .**xy** in the code that appears on the printer control panel.
- The x and y values must match for printing to continue.

## Replace imaging unit, 0 estimated pages remain [84.xy]

Replace the imaging unit to clear the message and continue printing. For more information, see the instruction sheet that came with the supply or see the “Replacing supplies” section of the *User’s Guide*.

**Note:** If you do not have a replacement imaging unit, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

## Reinstall missing or unresponsive cartridge [31.xy]

Try one or more of the following:

- Check if the toner cartridge is missing. If missing, install the toner cartridge.

  For information on installing the cartridge, see the “Replacing supplies” section of the *User’s Guide*.
- If the toner cartridge is installed, then remove the unresponsive toner cartridge, and then reinstall it.

  **Note:** If the message appears after reinstalling the supply, then the cartridge is defective. Replace the toner cartridge.

## Reinstall missing or unresponsive imaging unit [31.xy]

Try one or more of the following:

- Check if the imaging unit is missing. If missing, install the imaging unit.

  For information on installing the imaging unit, see the “Replacing supplies” section of the *User’s Guide*.
- If the imaging unit is installed, then remove the unresponsive imaging unit, and then reinstall it.

  **Note:** If the message appears after reinstalling the supply, then the imaging unit is defective. Replace the imaging unit.

## Replace unsupported cartridge [32.xy]

Remove the toner cartridge, and then install a supported one to clear the message and continue printing. For more information, see the instruction sheet that came with the supply or see the “Replacing supplies” section of the *User’s Guide*.

**Note:** If you do not have a replacement cartridge, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

## Replace unsupported imaging unit [32.xy]

Remove the imaging unit, and then install a supported one to clear the message and continue printing. For more information, see the instruction sheet that came with the supply or see the “Replacing supplies” section of the *User’s Guide*.

**Note:** If you do not have a replacement imaging unit, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

## Bin full. Remove paper.

Remove the paper stack from the standard bin.

## Network error, standard port [54]

Try one or more of the following:

- From the printer control panel, press OK to clear the message and continue printing.
- Unplug the router, then wait for 30 seconds, and then plug it back again.
- Turn off the printer, then wait for about 10 seconds, and then turn the printer back on.
- Update the network firmware in the printer or the print server. For more information, contact customer support.

## Parallel port disabled [56]

Try one or more of the following:

- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** The printer discards any data received through the parallel port.
- From the printer control panel, set Parallel Buffer to Auto.

## Rear USB port disabled [56]

Try one or more of the following:

- From the printer control panel, press OK to clear the message and continue printing.

  **Note:** The printer discards any data received through the USB port.
- From the printer control panel, set USB Buffer to Auto.

## Too many trays. Remove some. [58]

1. Turn off the printer.
2. Unplug the power cord from the electrical outlet.
3. Remove the extra trays.
4. Connect the power cord to the electrical outlet.
5. Turn the printer back on.

## Flash memory unformatted [53]

Try one or more of the following:

- From the printer control panel, press OK to stop the defragmentation and continue printing.
- Format the flash memory device.

**Note:** If the error message remains, then the flash memory device may be defective and need to be replaced.

# Solving printer problems


- “Basic printer problems” on page 125
- “Option problems” on page 127
- “Paper feed problems” on page 130


## Basic printer problems

### The printer is not responding

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Make sure the printer is turned on.<br><br>Is the printer turned on? | Go to step 2. | Turn on the printer. |
| **Step 2**<br>Check if the printer is in Sleep mode or Hibernate mode.<br><br>Is the printer in Sleep mode or Hibernate mode? | Press the Sleep button to wake the printer from Sleep mode or Hibernate mode. | Go to step 3. |
| **Step 3**<br>Check if one end of the power cord is plugged into the printer and the other to a properly grounded electrical outlet.<br><br>Is the power cord plugged into the printer and a properly grounded electrical outlet? | Go to step 4. | Plug one end of the power cord into the printer and the other to a properly grounded electrical outlet. |

| Action | Yes | No |
|---|---|---|
| **Step 4**<br>Check other electrical equipment plugged into the electrical outlet.<br><br>Does other electrical equipment work? | Unplug the other electrical equipment, and then turn on the printer. If the printer does not work, then reconnect the other electrical equipment. | Go to step 5. |
| **Step 5**<br>Check if the cables connecting the printer and the computer are inserted in the correct ports.<br><br>Are the cables inserted in the correct ports? | Go to step 6. | Make sure to match the following:<br>• The USB symbol on the cable with the USB symbol on the printer<br>• The appropriate Ethernet cable with the Ethernet port |
| **Step 6**<br>Make sure the electrical outlet is not turned off by a switch or breaker.<br><br>Is the electrical outlet turned off by a switch or breaker? | Turn on the switch or reset the breaker. | Go to step 7. |
| **Step 7**<br>Check if the printer is plugged into any surge protectors, uninterruptible power supplies, or extension cords.<br><br>Is the printer plugged into any surge protectors, uninterruptible power supplies, or extension cords? | Connect the printer power cord directly to a properly grounded electrical outlet. | Go to step 8. |
| **Step 8**<br>Check if one end of the printer cable is plugged into a port on the printer and the other to the computer, print server, option, or other network device.<br><br>Is the printer cable securely attached to the printer and the computer, print server, option, or other network device? | Go to step 9. | Connect the printer cable securely to the printer and the computer, print server, option, or other network device. |
| **Step 9**<br>Make sure to install all hardware options properly and remove any packing material.<br><br>Are all hardware options properly installed and all packing material removed? | Go to step 10. | Turn off the printer, remove all packing materials, then reinstall the hardware options, and then turn on the printer. |
| **Step 10**<br>Check if you have selected the correct port settings in the printer driver.<br><br>Are the port settings correct? | Go to step 11. | Use correct printer driver settings. |

| Action | Yes | No |
|---|---|---|
| **Step 11**<br>Check the installed printer driver.<br><br>Is the correct printer driver installed? | Go to step 12. | Install the correct printer driver. |
| **Step 12**<br>Turn off the printer, then wait for about 10 seconds, and then turn the printer back on.<br><br>Is the printer working? | The problem is solved. | Contact **customer support**. |

### Printer display is blank

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Press the Sleep button on the printer control panel.<br><br>Does **Ready** appear on the printer display? | The problem is solved. | Go to step 2. |
| **Step 2**<br>Turn off the printer, then wait for about 10 seconds, and then turn the printer back on.<br><br>Do **Please wait** and **Ready** appear on the printer display? | The problem is solved. | Turn off the printer, and then contact **customer support**. |

## Option problems

### Cannot detect internal option

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Turn off the printer, then wait for about 10 seconds, and then turn on the printer.<br><br>Does the internal option operate correctly? | The problem is solved. | Go to step 2. |
| **Step 2**<br>Check if the internal option is properly installed in the controller board.<br>**a** Turn off the printer using the power switch, and then unplug the power cord from the electrical outlet.<br>**b** Make sure the internal option is installed in the appropriate connector in the controller board.<br>**c** Connect the power cord to the printer, then to a properly grounded electrical outlet, and then turn on the printer.<br><br>Is the internal option properly installed in the controller board? | Go to step 3. | Connect the internal option to the controller board. |

| Action | Yes | No |
|---|---|---|
| **Step 3**<br>Print a menu settings page, and then check to see if the internal option is listed in the Installed Features list.<br><br>Is the internal option listed in the menu settings page? | Go to step 4. | Reinstall the internal option. |
| **Step 4**<br>**a** Check if the internal option is selected.<br>It may be necessary to manually add the internal option in the printer driver to make it available for print jobs. For more information, see “Updating available options in the printer driver” on page 22.<br>**b** Resend the print job.<br><br>Does the internal option operate correctly? | The problem is solved. | Contact **customer support**. |

## Tray problems

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Open the tray and do one or more of the following:<br>• Check for paper jams or misfeeds.<br>• Check if the paper size indicators on the paper guides are aligned with the paper size indicators on the tray.<br>• If you are printing on custom-size paper, then make sure that the paper guides rest against the edges of the paper.<br>• Make sure the paper is below the maximum paper fill indicator.<br>• Make sure paper lies flat in the tray.<br>**b** Check if the tray closes properly.<br><br>Is the tray working? | The problem is solved. | Go to step 2. |
| **Step 2**<br>**a** Turn off the printer, then wait about 10 seconds, and then turn the printer back on.<br>**b** Resend the print job.<br><br>Is the tray working? | The problem is solved. | Go to step 3. |
| **Step 3**<br>Check if the tray is installed.<br>Print a menu settings page, and then check if the tray is listed in the Installed Options list.<br><br>Is the tray listed in the menu settings page? | Go to step 4. | Reinstall the tray. For more information, see the setup documentation that came with the tray. |

| Action | Yes | No |
|---|---|---|
| **Step 4**<br>Check if the tray is available in the printer driver.<br>**Note:** If necessary, manually add the tray in the printer driver to make it available for print jobs. For more information, see “Updating available options in the printer driver” on page 22.<br>Is the tray available in the printer driver? | Go to step 5. | Manually add the tray in the printer driver. |
| **Step 5**<br>Check if the option is selected.<br>**a** From the application you are using, select the option. For Mac OS X version 9 users, make sure the printer is set up in Chooser.<br>**b** Resend the print job.<br>Is the tray working? | The problem is solved. | Contact **customer support**. |

## Cannot detect memory card

| Action | Yes | No |
|---|---|---|
| Make sure the memory card is installed.<br>**a** Install the memory card. For more information, see “Installing a memory card” on page 15.<br>**Note:** Check if the memory card is securely connected to the printer controller board.<br>**b** Print a menu settings page, and then check if the card is listed in the Installed Options list.<br>Is the card listed in the Installed Options list? | The problem is solved. | Contact **customer support**. |

# Paper feed problems

## Paper frequently jams

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Pull out the tray, and then do one or more of the following:<br>• Make sure paper lies flat in the tray.<br>• Check if the paper size indicators on the paper guides are aligned with the paper size indicators on the tray.<br>• Check if the paper guides are aligned against the edges of the paper.<br>• Make sure the paper is below the maximum paper fill indicator.<br>• Check if you are printing on a recommended paper size and type.<br>**b** Insert the tray properly.<br>If jam recovery is enabled, then the print jobs will reprint automatically.<br><br>Do paper jams still occur frequently? | Go to step 2. | The problem is solved. |
| **Step 2**<br>**a** Load paper from a fresh package.<br>**Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.<br>**b** Resend the print job.<br><br>Do paper jams still occur frequently? | Go to step 3. | The problem is solved. |
| **Step 3**<br>**a** Review the tips on avoiding jams. For more information, see “Avoiding jams” on page 105.<br>**b** Follow the recommendations, and then resend the print job.<br><br>Do paper jams still occur frequently? | Contact **customer support**. | The problem is solved. |

## Paper jam message remains after jam is cleared

| Action | Yes | No |
|---|---|---|
| Open front door and remove all trays.<br>**a** Clear any jammed pages.<br>**Note:** Make sure all paper fragments are removed.<br>**b** Press OK to clear the message and continue printing.<br><br>Does the paper jam message remain? | Contact **customer support.** | The problem is solved. |

### Jammed pages are not reprinted

| Action | Yes | No |
|---|---|---|
| **a** Turn on jam recovery.<br>**1** From the printer control panel, navigate to:<br> > **Settings** > > **General Settings** > > **Print Recovery** > > **Jam Recovery** > <br>**2** Press the arrow buttons until **On** or **Auto** appears, and then press .<br>**b** Resend the pages that did not print.<br><br>Were the jammed pages reprinted? | The problem is solved. | Contact **customer support.** |

# Solving print problems

## Printing problems

### Print jobs do not print

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** From the document you are trying to print, open the Print dialog and check if you have selected the correct printer.<br>**Note:** If the printer is not the default printer, then you must select the printer for each document that you want to print.<br>**b** Resend the print job.<br><br>Do the jobs print? | The problem is solved. | Go to step 2. |
| **Step 2**<br>**a** Check if the printer is plugged in and turned on, and if **Ready** appears on the printer display.<br>**b** Resend the print job.<br><br>Do the jobs print? | The problem is solved. | Go to step 3. |
| **Step 3**<br>If an error message appears on the printer display, then clear the message.<br>**Note:** The printer continues to print after clearing the message.<br><br>Do the jobs print? | The problem is solved. | Go to step 4. |

| Action | Yes | No |
|---|---|---|
| **Step 4**<br>**a** Check if the ports (USB, serial, or Ethernet) are working and if the cables are securely connected to the computer and the printer.<br>**Note:** For more information, see the setup documentation that came with the printer.<br>**b** Resend the print job.<br><br>Do the jobs print? | The problem is solved. | Go to step 5. |
| **Step 5**<br>**a** Turn off the printer, then wait for about 10 seconds, and then turn the printer back on.<br>**b** Resend the print job.<br><br>Do the jobs print? | The problem is solved. | Go to step 6. |
| **Step 6**<br>**a** Remove, and then reinstall the printer software. For more information, see “Installing the printer software” on page 21.<br>**Note:** The printer software is available at **http://support.lexmark.com**.<br>**b** Resend the print job.<br><br>Do the jobs print? | The problem is solved. | Contact **customer support**. |

## Printing slows down

**Notes:**

- When printing using narrow paper, the printer prints at a reduced speed to prevent damage to the fuser.
- The printer speed may be reduced when printing for long periods of time, or printing at elevated temperatures.
- The printer speed may also be reduced when the printed output resolution is set to 1,200 dpi.

| Action | Yes | No |
|---|---|---|
| Place letter- or A4-size paper in the tray, and then resend the print job.<br>Does the print speed increase? | The problem is solved. | Contact **customer support**. |

## Print job takes longer than expected

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Reduce the number and size of fonts, the number and complexity of images, and the number of pages in the print job, and then resend the print job.<br><br>Does the print job still take long? | Go to step 2. | The problem is solved. |
| **Step 2**<br>Disable the Page Protect feature.<br>From the printer control panel, navigate to:<br> > **Settings** > > **General Settings** > > **Print Recovery** > > **Page Protect** > > **Off** > <br><br>Does the print job still take long? | Go to step 3. | The problem is solved. |
| **Step 3**<br>Change the environmental settings.<br>From the printer control panel, navigate to:<br> > **Settings** > > **General Settings** > > **Eco-Mode** > select a setting > <br>**Note:** When using the Eco-Mode setting, you may notice a reduction in performance.<br><br>Does the print job still take long? | Install additional printer memory.<br>For more information, contact **customer support**. | The problem is solved. |

## Job prints from the wrong tray or on the wrong paper

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Check if you are printing on paper that is supported by the tray.<br>**b** Resend the print job.<br><br>Did the job print from the correct tray or on the correct paper? | The problem is solved. | Go to step 2. |
| **Step 2**<br>**a** From the Paper menu on the printer control panel, set the paper size and type to match the paper loaded in the tray.<br>**b** Resend the print job.<br><br>Did the job print from the correct tray or on the correct paper? | The problem is solved. | Go to step 3. |

| Action | Yes | No |
|---|---|---|
| **Step 3**<br>**a** Depending on your operating system, open Printing Preferences or the Print dialog, and then specify the paper type.<br>**b** Resend the print job.<br><br>Did the job print from the correct tray or on the correct paper? | The problem is solved. | Go to step 4. |
| **Step 4**<br>**a** Check if the trays are not linked.<br>**b** Resend the print job.<br><br>Did the job print from the correct tray or on the correct paper? | The problem is solved. | Contact **customer support**. |

## Incorrect characters print

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Make sure the printer is not in Hex Trace mode.<br>**Note:** If **Ready Hex** appears on the printer display, then turn off the printer, and then turn it back on to deactivate Hex Trace mode.<br><br>Is the printer in Hex Trace mode? | Deactivate Hex Trace mode. | Go to step 2. |
| **Step 2**<br>**a** From the printer control panel, select **Standard Network** or **Network [x]**, and then set SmartSwitch to On.<br>**b** Resend the print job.<br><br>Do incorrect characters print? | Contact **customer support**. | The problem is solved. |

## Tray linking does not work

**Note:** The trays and the multipurpose feeder do not automatically detect the paper size. You must set the size from the Paper Size/Type menu.

| Action | Yes | No |
|---|---|---|
| **a** From the printer control panel, set the paper size and type in the Paper menu to match the paper loaded in the trays to be linked.<br>**Note:** The paper size and type must match for trays to be linked.<br>**b** Resend the print job.<br><br>Do the trays link correctly? | The problem is solved. | Contact **customer support**. |

## Large jobs do not collate

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** From the Finishing menu on the printer control panel, set Collate to (1,2,3) (1,2,3).<br>**b** Resend the print job.<br><br>Did the job print and collate correctly? | The problem is solved. | Go to step 2. |
| **Step 2**<br>**a** From the printer software, set Collate to (1,2,3) (1,2,3).<br>**Note:** Setting Collate to (1,1,1) (2,2,2) in the software overrides the setting in the Finishing menu.<br>**b** Resend the print job.<br><br>Did the job print and collate correctly? | The problem is solved. | Go to step 3. |
| **Step 3**<br>Reduce the complexity of the print job by eliminating the number and size of fonts, the number and complexity of images, and the number of pages in the job.<br><br>Did the job print and collate correctly? | The problem is solved. | Contact **customer support**. |

## Unexpected page breaks occur

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Adjust the print timeout settings.<br>**a** From the printer control panel, navigate to:<br>**Settings** > **General Settings** > **Timeouts** > **Print Timeout**<br>**b** Select a higher setting and then, depending on your printer model, select OK or **Submit**.<br>**c** Resend the print job.<br><br>Did the file print correctly? | The problem is solved. | Go to step 2. |
| **Step 2**<br>**a** Check the original file for manual page breaks.<br>**b** Resend the print job.<br><br>Did the file print correctly? | The problem is solved. | Contact **customer support**. |

# Print quality problems

## Characters have jagged or uneven edges




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Print a font sample list to check if the fonts you are using are supported by the printer.<br>**1** From the printer control panel, navigate to:<br> > **Reports** > > **Print Fonts** > <br>**2** Press the arrow buttons until **PCL Fonts** or **PostScript Fonts** appears, and then press .<br>**b** Use a font that is supported by the printer or install the font that you want to use. For more information, contact your system support person.<br>**c** Resend the print job.<br><br>Do prints still contain characters that have jagged or uneven edges? | Go to step 2. | The problem is solved. |
| **Step 2**<br>**a** Use a font that is supported by the printer or install the font that you want to use in your computer. For more information, contact your system support person.<br>**b** Resend the print job.<br><br>Do prints still contain characters that have jagged or uneven edges? | Contact **customer support**. | The problem is solved. |

## Printer is printing blank pages



| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Check if there is packing material left on the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**2** Check if the packing material is properly removed from the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**3** Reinstall the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Is the printer still printing blank pages? | Go to step 2. | The problem is solved. |
| **Step 2**<br>**a** Redistribute the toner in the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**2** Firmly shake the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**3** Reinstall the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Is the printer still printing blank pages? | Go to step 3. | The problem is solved. |
| **Step 3**<br>Replace the imaging unit, and then resend the print job.<br><br>Is the printer still printing blank pages? | Contact **customer support**. | The problem is solved. |

## Clipped pages or images






| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Move the width and length guides in the tray to the correct positions for the paper loaded.<br>**b** Resend the print job.<br><br>Is the page or image clipped? | Go to step 2. | The problem is solved. |
| **Step 2**<br>From the printer control panel, set the paper size and type in the Paper menu to match the paper loaded in the tray.<br><br>Do the paper size and type match the paper loaded in the tray? | Go to step 3. | Do one or more of the following:<br>• Specify the paper size from the tray settings to match the paper loaded in the tray.<br>• Change the paper loaded in the tray to match the paper size specified in the tray settings. |
| **Step 3**<br>**a** Depending on your operating system, specify the paper size from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Is the page or image clipped? | Go to step 4. | The problem is solved. |
| **Step 4**<br>**a** Reinstall the imaging unit.<br>**1** Remove the toner cartridge.<br>**2** Remove the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**3** Install the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Is the page or image clipped? | Contact **customer support**. | The problem is solved. |

## Shadow images appear on prints



| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Load paper with the correct paper type and weight in the tray.<br><br>Is paper with the correct paper type and weight loaded in the tray? | Go to step 2. | Load paper with the correct paper type and weight in the tray. |
| **Step 2**<br>From the printer control panel, set the paper type and weight in the Paper menu to match the paper loaded in the tray.<br><br>Is the tray set to the type and weight of the paper loaded? | Go to step 3. | Change the paper loaded in the tray to match the paper type and weight specified in the tray settings. |
| **Step 3**<br>**a** Depending on your operating system, specify the paper type and weight from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Do shadow images still appear on prints? | Go to step 4. | The problem is solved. |
| **Step 4**<br>Replace the imaging unit, and then resend the print job.<br><br>Do shadow images still appear on prints? | Contact **customer support**. | The problem is solved. |

## Gray background on prints



| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** From the Quality Menu on the printer control panel, decrease the toner darkness.<br>**Note:** 8 is the factory default setting.<br>**b** Resend the print job.<br><br>Did the gray background disappear from the prints? | The problem is solved. | Go to step 2. |

| Action | Yes | No |
|---|---|---|
| **Step 2**<br>Reinstall the imaging unit and the toner cartridge.<br>**a** Remove the toner cartridge.<br>**b** Remove the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light can cause print quality problems.<br>**c** Install the imaging unit, and then the cartridge.<br>**d** Resend the print job.<br><br>Did the gray background disappear from the prints? | The problem is solved. | Go to step 3. |
| **Step 3**<br>Replace the imaging unit, and then resend the print job.<br><br>Did the gray background disappear from the prints? | The problem is solved. | Contact **customer support**. |

## Incorrect margins on prints




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Move the width and length guides in the tray to the correct positions for the paper size loaded.<br>**b** Resend the print job.<br><br>Are the margins correct? | The problem is solved. | Go to step 2. |
| **Step 2**<br>From the printer control panel, set the paper size in the Paper menu to match the paper loaded in the tray.<br><br>Does the paper size match the paper loaded in the tray? | Go to step 3. | Do one or more of the following:<br>• Specify the paper size from the tray settings to match the paper loaded in the tray.<br>• Change the paper loaded in the tray to match the paper size specified in the tray settings. |

| Action | Yes | No |
|---|---|---|
| **Step 3**<br>**a** Depending on your operating system, specify the paper size from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Are the margins correct? | The problem is solved. | Contact **customer support**. |

## Paper curl

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Move the width and length guides in the tray to the correct positions for the size of the paper loaded.<br><br>Are the width and length guides positioned correctly? | Go to step 2. | Adjust the width and length guides. |
| **Step 2**<br>From the printer control panel, set the paper type and weight in the Paper menu to match the paper loaded in the tray.<br><br>Do the paper type and weight match the type and weight of the paper in the tray? | Go to step 3. | Specify the paper type and weight from the tray settings to match the paper loaded in the tray. |
| **Step 3**<br>**a** Depending on your operating system, specify the paper type and weight from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Is the paper still curled? | Go to step 4. | The problem is solved. |
| **Step 4**<br>**a** Remove the paper from the tray, and then turn it over.<br>**b** Resend the print job.<br><br>Is the paper still curled? | Go to step 5. | The problem is solved. |
| **Step 5**<br>**a** Load paper from a fresh package.<br>**Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.<br>**b** Resend the print job.<br><br>Is the paper still curled? | Contact **customer support**. | The problem is solved. |

## Print irregularities



| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Move the width and length guides in the tray to the correct positions for the size of the paper loaded in the tray.<br>**b** Resend the print job.<br><br>Do print irregularities still appear? | Go to step 2. | The problem is solved. |
| **Step 2**<br>From the printer control panel, set the paper size and type in the Paper menu to match the paper loaded in the tray.<br><br>Do the printer settings match the type and weight of the paper loaded in the tray? | Go to step 3. | Specify the paper size and type from the tray settings to match the paper loaded in the tray. |
| **Step 3**<br>**a** Depending on your operating system, specify the paper type and weight from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Do print irregularities still appear? | Go to step 4. | The problem is solved. |
| **Step 4**<br>Check if the paper loaded in the tray has texture or rough finishes.<br><br>Are you printing on textured or rough paper? | From the printer control panel, set the paper texture in the Paper menu to match the paper loaded in the tray. | Go to step 5. |
| **Step 5**<br>**a** Load paper from a fresh package.<br>**Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.<br>**b** Resend the print job.<br><br>Do print irregularities still appear? | Go to step 6. | The problem is solved. |
| **Step 6**<br>Replace the imaging unit, and then resend the print job.<br><br>Do print irregularities still appear? | Contact **customer support** at **http://support.lexmark.com** or your service representative. | The problem is solved. |

## Repeating defects appear on prints



| Action | Yes | No |
|---|---|---|
| **Step 1**<br>Measure the distance between the defects.<br>Check for a distance between the defects that equals:<br>• 97 mm (3.82 in.)<br>• 47 mm (1.85 in.)<br>• 38 mm (1.5 in.)<br>Is the distance between defects equal to one of the listed measurements? | Go to step 2. | **1** Check if the distance between the defects equal to 80 mm (3.15 in.)<br>**2** Take note of the distance, and then contact **customer support** at **http://support.lexmark.com** or your service representative. |
| **Step 2**<br>Replace the imaging unit, and then resend the print job.<br>Do the repeating defects still appear? | Contact **customer support** at **http://support.lexmark.com** or your service representative. | The problem is solved. |

## Print is too dark




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** From the Quality menu on the printer control panel, reduce the toner darkness.<br>**Note:** 8 is the factory default setting.<br>**b** Resend the print job.<br>Is the print still too dark? | Go to step 2. | The problem is solved. |

| Action | Yes | No |
|---|---|---|
| **Step 2**<br>**a** From the printer control panel, set the paper type, texture and weight in the Paper menu to match the paper loaded in the tray.<br>**b** Resend the print job.<br><br>Is the tray set to the type, texture, and weight of the paper loaded? | Go to step 3. | Do one or more of the following:<br>• Specify the paper type, texture, and weight from the tray settings to match the paper loaded in the tray.<br>• Change the paper loaded in the tray to match the paper type, texture and weight specified in the tray settings. |
| **Step 3**<br>**a** Depending on your operating system, specify the paper type, texture and weight from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Is the print still too dark? | Go to step 4. | The problem is solved. |
| **Step 4**<br>Check if the paper loaded in the tray has texture or rough finishes.<br><br>Are you printing on textured or rough paper? | From the printer control panel, change the texture settings in the Paper Texture menu to match the paper you are printing on. | Go to step 5. |
| **Step 5**<br>**a** Load paper from a fresh package.<br>**Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.<br>**b** Resend the print job.<br><br>Is the print still too dark? | Go to step 6. | The problem is solved. |
| **Step 6**<br>Replace the imaging unit, and then resend the print job.<br><br>Is the print still too dark? | Contact **customer support**. | The problem is solved. |

## Print is too light




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** From the Quality menu on the printer control panel, increase the toner darkness.<br>**Note:** 8 is the factory default setting.<br>**b** Resend the print job.<br><br>Is the print still too light? | Go to step 2. | The problem is solved. |
| **Step 2**<br>From the printer control panel, set the paper type, texture, and weight in the Paper menu to match the paper loaded in the tray.<br><br>Is the tray set to the type, texture, and weight of the paper loaded? | Go to step 3. | Change the paper type, texture, and weight to match the paper loaded in the tray. |
| **Step 3**<br>**a** Depending on your operating system, specify the paper type, texture, and weight from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Is the print still too light? | Go to step 4. | The problem is solved. |
| **Step 4**<br>Make sure that the paper has no texture or rough finishes.<br><br>Are you printing on textured or rough paper? | From the printer control panel, change the texture settings in the Paper Texture menu to match the paper you are printing on. | Go to step 5. |
| **Step 5**<br>**a** Load paper from a fresh package.<br>**Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.<br>**b** Resend the print job.<br><br>Is the print still too light? | Go to step 6. | The problem is solved. |

| Action | Yes | No |
|---|---|---|
| **Step 6**<br>**a** Redistribute the toner in the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**2** Firmly shake the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**3** Install the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Is the print still too light? | Go to step 7. | The problem is solved. |
| **Step 7**<br>Replace the imaging unit, and then resend the print job.<br><br>Is the print still too light? | Contact **customer support**. | The problem is solved. |

## Skewed print




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Move the width and length guides in the tray to the correct positions for the size of the paper loaded.<br>**b** Resend the print job.<br><br>Is the print still skewed? | Go to step 2. | The problem is solved. |
| **Step 2**<br>**a** Check if you are printing on a paper that is supported by the tray.<br>**b** Resend the print job.<br><br>Is the print still skewed? | Contact **customer support**. | The problem is solved. |

## Printer is printing solid black pages

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Reinstall the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**2** Install the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Is the printer printing solid black pages? | Go to step 2. | The problem is solved. |
| **Step 2**<br>Replace the imaging unit, and then resend the print job.<br><br>Is the printer printing solid black pages? | Contact **customer support**. | The problem is solved. |

## Transparency print quality is poor

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>From the printer control panel, set the paper type in the Paper menu to match the paper loaded in the tray.<br><br>Is the paper type for the tray set to Transparency? | Go to step 2. | Set the paper type to Transparency. |
| **Step 2**<br>**a** Check if you are using a recommended type of transparency.<br>**b** Resend the print job.<br><br>Is the print quality still poor? | Contact **customer support**. | The problem is solved. |

## Streaked horizontal lines appear on prints




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Depending on your operating system, specify the tray or feeder from Printing Preferences or the Print dialog.<br>**b** Resend the print job.<br><br>Do streaked horizontal lines appear on prints? | Go to step 2. | The problem is solved. |
| **Step 2**<br>From the printer control panel, set the paper type and weight in the Paper menu to match the paper loaded in the tray.<br><br>Do the paper type and weight match the type and weight of the paper in the tray? | Go to step 3. | Change the paper type and weight to match the paper loaded in the tray. |
| **Step 3**<br>**a** Load paper from a fresh package.<br>**Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.<br>**b** Resend the print job.<br><br>Do streaked horizontal lines appear on prints? | Go to step 4. | The problem is solved. |
| **Step 4**<br>**a** Reinstall the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**2** Install the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Do streaked horizontal lines appear on prints? | Go to step 5. | The problem is solved. |
| **Step 5**<br>Replace the imaging unit, and then resend the print job.<br><br>Do streaked horizontal lines appear on prints? | Contact **customer support**. | The problem is solved. |

## Streaked vertical lines appear on prints







| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Depending on your operating system, specify the paper type, texture, and weight from Printing Preferences or from the Print dialog.<br>**b** Resend the print job.<br><br>Do streaked vertical lines appear on prints? | Go to step 2. | The problem is solved. |
| **Step 2**<br>From the printer control panel, set the paper texture, type, and weight in the Paper menu to match the paper loaded in the tray.<br><br>Do the paper texture, type, and weight match the paper in the tray? | Go to step 3. | Do one or more of the following:<br>• Specify the paper texture, type, and weight from the tray settings to match the paper loaded in the tray.<br>• Change the paper loaded in the tray to match the paper texture, type, and weight specified in the tray settings. |
| **Step 3**<br>**a** Load paper from a fresh package.<br>**Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.<br>**b** Resend the print job.<br><br>Do streaked vertical lines appear on prints? | Go to step 4. | The problem is solved. |
| **Step 4**<br>**a** Reinstall the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**2** Install the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Do streaked vertical lines appear on prints? | Go to step 5. | The problem is solved. |

| Action | Yes | No |
|---|---|---|
| **Step 5**<br>Replace the imaging unit, and then resend the print job.<br><br>Do streaked vertical lines appear on prints? | Contact **customer support** at **http://support.lexmark.com** or your service representative. | The problem is solved. |

## Horizontal voids appear on prints




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Make sure your software program is using a correct fill pattern.<br>**b** Resend the print job.<br><br>Do horizontal voids appear on prints? | Go to step 2. | The problem is solved. |
| **Step 2**<br>**a** Load the specified tray or feeder with a recommended type of paper.<br>**b** Resend the print job.<br><br>Do horizontal voids appear on prints? | Go to step 3. | The problem is solved. |
| **Step 3**<br>**a** Redistribute the toner in the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**2** Firmly shake the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**3** Reinstall the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Do horizontal voids appear on prints? | Go to step 4. | The problem is solved. |
| **Step 4**<br>Replace the imaging unit, and then resend the print job.<br><br>Do horizontal voids appear on prints? | Contact **customer support**. | The problem is solved. |

## Vertical voids appear on prints




| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Make sure your software program is using a correct fill pattern.<br>**b** Resend the print job.<br><br>Do vertical voids appear on prints? | Go to step 2. | The problem is solved. |
| **Step 2**<br>**a** From the printer control panel, set the paper type and weight in the Paper menu to match the paper loaded in the tray.<br>**b** Resend the print job.<br><br>Do vertical voids appear on prints? | Go to step 3. | The problem is solved. |
| **Step 3**<br>Check if you are using a recommended type of paper.<br>**a** Load the indicated tray or feeder with a recommended type of paper.<br>**b** Resend the print job.<br><br>Do vertical voids appear on prints? | Go to step 4. | The problem is solved. |
| **Step 4**<br>**a** Redistribute the toner in the imaging unit.<br>**1** Remove the toner cartridge, and then the imaging unit.<br>**2** Firmly shake the imaging unit.<br>**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.<br>**3** Reinstall the imaging unit, and then the cartridge.<br>**b** Resend the print job.<br><br>Do vertical voids appear on prints? | Contact **customer support**.<br>**Note:** The laser scanning unit may be defective. | The problem is solved. |

## Toner specks appear on prints

| Action | Yes | No |
|---|---|---|
| Replace the imaging unit, and then resend the print job.<br><br>Do toner specks appear on prints? | Contact **customer support**. | The problem is solved. |

## Toner rubs off







| Action | Yes | No |
|---|---|---|
| **Step 1**<br>From the Paper menu on the printer control panel, check the paper type and weight.<br><br>Do the paper type and texture match the paper loaded in the tray? | Go to step 2. | Specify the paper type and weight from the tray settings to match the paper loaded in the tray. |
| **Step 2**<br>Check if you are printing on paper with texture or rough finishes.<br><br>Are you printing on textured or rough paper? | From the Paper menu on the printer control panel, set the paper texture. | Contact **customer support**. |

## Uneven print density




| Action | Yes | No |
|---|---|---|
| Replace the imaging unit, and then resend the print job.<br><br>Is the print density uneven? | Contact **customer support**. | The problem is solved. |

# Embedded Web Server does not open

| Action | Yes | No |
|---|---|---|
| **Step 1**<br>**a** Turn on the printer.<br>**b** Open a Web browser, and then type the printer IP address.<br>**c** Press **Enter**.<br><br>Does the Embedded Web Server open? | The problem is solved. | Go to step 2. |
| **Step 2**<br>Make sure the printer IP address is correct.<br>**a** View the printer IP address:<br>• From the TCP/IP section in the Network/Ports menu<br>• By printing a network setup page or menu settings page, and then finding the TCP/IP section<br>**Note:** An IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.<br>**b** Open a Web browser, and then type the IP address.<br>**Note:** Depending on the network settings, you may need to type "**`https://`**" instead of "**`http://`**" before the printer IP address to access the Embedded Web Server.<br>**c** Press **Enter**.<br><br>Does the Embedded Web Server open? | The problem is solved. | Go to step 3. |
| **Step 3**<br>Check if the network is working.<br>**a** Print a network setup page.<br>**b** Check the first section of the network setup page and confirm that the status is Connected.<br>**Note:** If the status is Not Connected, then the connection may be intermittent, or the network cable may be defective. Contact your system support person for a solution, and then print another network setup page.<br>**c** Open a Web browser, and then type the printer IP address.<br>**d** Press **Enter**.<br><br>Does the Embedded Web Server open? | The problem is solved. | Go to step 4. |
| **Step 4**<br>Check if the cable connections to the printer and print server are secure.<br>**a** Connect the cables properly. For more information, see the setup documentation that came with the printer.<br>**b** Open a Web browser, and then type the printer IP address.<br>**c** Press **Enter**.<br><br>Does the Embedded Web Server open? | The problem is solved. | Go to step 5. |

| Action | Yes | No |
|---|---|---|
| **Step 5**<br>Temporarily disable the Web proxy servers.<br>Proxy servers may block or restrict you from accessing certain Web sites including the Embedded Web Server.<br><br>Does the Embedded Web Server open? | The problem is solved. | Contact your system support person. |

# Contacting customer support

When you contact customer support, describe the problem you are experiencing, the message on the printer display, and the troubleshooting steps you have already taken to find a solution.

You need to know your printer model type and serial number. For more information, see the label on the inside top front cover or at the back of the printer. The serial number is also listed on the menu settings page.

Lexmark has various ways to help you solve your printing problem. Visit the Lexmark Web site at **http://support.lexmark.com**, and then select one of the following:

| | |
|---|---|
| **Tech Library** | You can browse our library of manuals, support documentation, drivers, and other downloads to help you solve common problems. |
| **E-mail** | You can send an e-mail to the Lexmark team, describing your problem. A service representative will respond and provide you with information to solve your problem. |
| **Live chat** | You can chat directly with a service representative. They can work with you to solve your printer problem or provide assistance through Assisted Service where the service representative can remotely connect to your computer through the Internet to troubleshoot problems, install updates, or complete other tasks to help you successfully use your Lexmark product. |

Telephone support is also available. In the U.S. or Canada, call 1-800-539-6275. For other countries or regions, visit the Lexmark Web site at **http://support.lexmark.com**.

# Notices

## Product information

Product name:

Lexmark MS410d, MS410dn

Machine type:

4514

Model(s):

420, 430

## Edition notice

September 2012

**The following paragraph does not apply to any country where such provisions are inconsistent with local law:** LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user’s responsibility.

For Lexmark technical support, visit **http://support.lexmark.com**.

For information on supplies and downloads, visit **www.lexmark.com**.

**© 2012 Lexmark International, Inc.**

**All rights reserved.**

## GOVERNMENT END USERS

The Software Program and any related documentation are "Commercial Items," as that term is defined in 48 C.F.R. 2.101, "Computer Software" and "Commercial Computer Software Documentation," as such terms are used in 48 C.F.R. 12.212 or 48 C.F.R. 227.7202, as applicable. Consistent with 48 C.F.R. 12.212 or 48 C.F.R. 227.7202-1 through 227.7207-4, as applicable, the Commercial Computer Software and Commercial Software Documentation are licensed to the U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other end users pursuant to the terms and conditions herein.

## Trademarks

Lexmark, Lexmark with diamond design, and MarkVision are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Mac and the Mac logo are trademarks of Apple Inc., registered in the U.S. and other countries.

PCL® is a registered trademark of the Hewlett-Packard Company. PCL is Hewlett-Packard Company's designation of a set of printer commands (language) and functions included in its printer products. This printer is intended to be compatible with the PCL language. This means the printer recognizes PCL commands used in various application programs, and that the printer emulates the functions corresponding to the commands.

All other trademarks are the property of their respective owners.

## Federal Communications Commission (FCC) compliance information statement

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The FCC Class B limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your point of purchase or service representative for additional suggestions.

The manufacturer is not responsible for radio or television interference caused by using other than recommended cables or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate this equipment.

**Note:** To assure compliance with FCC regulations on electromagnetic interference for a Class B computing device, use a properly shielded and grounded cable such as Lexmark part number 1021231 for parallel attach or 1021294 for USB attach. Use of a substitute cable not properly shielded and grounded may result in a violation of FCC regulations.

Any questions regarding this compliance information statement should be directed to:

Director of Lexmark Technology & Services
Lexmark International, Inc.
740 West New Circle Road
Lexington, KY 40550
(859) 232–3000

## Industry Canada compliance statement

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003.

## Avis de conformité aux normes de l’industrie du Canada

Cet appareil numérique de classe B est conforme aux exigences de la norme canadienne relative aux équipements pouvant causer des interférences NMB-003.

## Modular component notice

This product may contain the following modular component(s):

Lexmark Regulatory Type/Model LEX-M01-005; FCC ID:IYLLEXM01005; IC:2376A-M01005

## Licensing notices

All licensing notices associated with this product can be viewed from the root directory of the installation software CD.

## Noise emission levels

The following measurements were made in accordance with ISO 7779 and reported in conformance with ISO 9296.

**Note:** Some modes may not apply to your product.

| 1-meter average sound pressure, dBA | |
|---|---|
| Printing | 54 dBA |
| Ready | N/A |

Values are subject to change. See **www.lexmark.com** for current values.

## Waste from Electrical and Electronic Equipment (WEEE) directive

The WEEE logo signifies specific recycling programs and procedures for electronic products in countries of the European Union. We encourage the recycling of our products.

If you have further questions about recycling options, visit the Lexmark Web site at **www.lexmark.com** for your local sales office phone number.

## Product disposal

Do not dispose of the printer or supplies in the same manner as normal household waste. Consult your local authorities for disposal and recycling options.

## Static sensitivity notice

This symbol identifies static-sensitive parts. Do not touch in the areas near these symbols without first touching the metal frame of the printer.

## ENERGY STAR

Any Lexmark product bearing the ENERGY STAR emblem on the product or on a start-up screen is certified to comply with Environmental Protection Agency (EPA) ENERGY STAR requirements as configured when shipped by Lexmark.

## Temperature information

| | |
|---|---|
| Ambient temperature | 16 to 32°C (60 to 90°F) |
| Shipping and storage temperature | -20 to 40°C (-4 to 104°F) |

## Laser notice

The printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR, Chapter I, Subchapter J for Class I (1) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 60825-1.

Class I laser products are not considered to be hazardous. The printer contains internally a Class IIIb (3b) laser that is nominally a 7 milliwatt gallium arsenide laser operating in the wavelength of 655-675 nanometers. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance, or prescribed service condition.

## Laser advisory label

A laser notice label may be affixed to this printer as shown:

DANGER - Invisible laser radiation when cartridges are removed and interlock defeated. Avoid exposure to laser beam.
PERIGO - Radiação a laser invisível será liberada se os cartuchos forem removidos e o lacre rompido. Evite a exposição aos feixes de laser.
Opasnost - Nevidljivo lasersko zračenje kada su kasete uklonjene i poništena sigurnosna veza. Izbjegavati izlaganje zracima.
NEBEZPEČÍ - Když jsou vyjmuty kazety a je odblokována pojistka, ze zařízení je vysíláno neviditelné laserové záření. Nevystavujte se působení laserového paprsku.
FARE - Usynlig laserstråling, når patroner fjernes, og spærreanordningen er slået fra. Undgå at blive udsat for laserstrålen.
GEVAAR - Onzichtbare laserstraling wanneer cartridges worden verwijderd en een vergrendeling wordt genegeerd. Voorkom blootstelling aan de laser.
DANGER - Rayonnements laser invisibles lors du retrait des cartouches et du déverrouillage des loquets. Eviter toute exposition au rayon laser.
VAARA - Näkymätöntä lasersäteilyä on varottava, kun värikasetit on poistettu ja lukitus on auki. Vältä lasersäteelle altistumista.
GEFAHR - Unsichtbare Laserstrahlung beim Herausnehmen von Druckkassetten und offener Sicherheitssperre. Laserstrahl meiden.
ΚΙΝΔΥΝΟΣ - Έκλυση αόρατης ακτινοβολίας laser κατά την αφαίρεση των κασετών και την απασφάλιση της μανδάλωσης. Αποφεύγετε την έκθεση στην ακτινοβολία laser.
VESZÉLY – Nem látható lézersugárzás fordulhat elő a patronok eltávolításakor és a zárószerkezet felbontásakor. Kerülje a lézersugárnak való kitettséget.
PERICOLO - Emissione di radiazioni laser invisibili durante la rimozione delle cartucce e del blocco. Evitare l´esposizione al raggio laser.
FARE – Usynlig laserstråling når kassettene tas ut og sperren er satt ut av spill. Unngå eksponering for laserstrålen.
NIEBEZPIECZEŃSTWO - niewidzialne promieniowanie laserowe podczas usuwania kaset i blokady. Należy unikać naświetlenia promieniem lasera.
ОПАСНО! Невидимое лазерное излучение при извлеченных картриджах и снятии блокировки. Избегайте воздействия лазерных лучей.
Pozor – Nebezpečenstvo neviditeľného laserového žiarenia pri odobratých kazetách a odblokovanej poistke. Nevystavujte sa lúčom.
PELIGRO: Se producen radiaciones láser invisibles al extraer los cartuchos con el interbloqueo desactivado. Evite la exposición al haz de láser.
FARA – Osynlig laserstrålning när patroner tas ur och spärrmekanismen är upphävd. Undvik exponering för laserstrålen.
危**险** - 当移除碳粉盒及互**锁**失效**时**会**产**生看不**见**的激光**辐**射，**请**避免暴露在激光光束下。
危險 - 移除碳粉匣與安全連續開關失效時會**產**生看不見的雷射輻射。請避免曝露在雷射光束下。
危険 - カートリッジが取り外され、内部ロックが無効になると、見えないレーザー光が放射されます。 このレーザー光に当たらないようにしてください。

# Power consumption

## Product power consumption

The following table documents the power consumption characteristics of the product.

**Note:** Some modes may not apply to your product.

| Mode | Description | Power consumption (Watts) |
|---|---|---|
| Printing | The product is generating hard-copy output from electronic inputs. | 560 W |
| Copy | The product is generating hard-copy output from hard-copy original documents. | NA |
| Scan | The product is scanning hard-copy documents. | NA |
| Ready | The product is waiting for a print job. | 8 W |
| Sleep Mode | The product is in a high-level energy-saving mode. | 5 W |
| Hibernate | The product is in a low-level energy-saving mode. | 0.5 W |
| Off | The product is plugged into an electrical outlet, but the power switch is turned off. | 0.0 W |

The power consumption levels listed in the previous table represent time-averaged measurements. Instantaneous power draws may be substantially higher than the average.

Values are subject to change. See **www.lexmark.com** for current values.

### Sleep Mode

This product is designed with an energy-saving mode called *Sleep Mode*. The Sleep Mode saves energy by lowering power consumption during extended periods of inactivity. The Sleep Mode is automatically engaged after this product is not used for a specified period of time, called the *Sleep Mode Timeout*.

| | |
|---|---|
| Factory default Sleep Mode Timeout for this product (in minutes): | 30 |

By using the configuration menus, the Sleep Mode Timeout can be modified between 1 minute and 120 minutes. Setting the Sleep Mode Timeout to a low value reduces energy consumption, but may increase the response time of the product. Setting the Sleep Mode Timeout to a high value maintains a fast response, but uses more energy.

### Hibernate Mode

This product is designed with an ultra-low power operating mode called *Hibernate mode*. When operating in Hibernate Mode, all other systems and devices are powered down safely.

The Hibernate mode can be entered in any of the following methods:

- Using the Hibernate Timeout
- Using the Schedule Power modes
- Using the Sleep/Hibernate button

| | |
|---|---|
| Factory default Hibernate Timeout for this product in all countries or regions except for EU countries and Switzerland | Disabled |
| Factory default value for this product in EU countries or regions and Switzerland | 3 days |

The amount of time the printer waits after a job is printed before it enters Hibernate mode can be modified between one hour and one month.

### Off mode

If this product has an off mode which still consumes a small amount of power, then to completely stop product power consumption, disconnect the power supply cord from the electrical outlet.

### Total energy usage

It is sometimes helpful to calculate the total product energy usage. Since power consumption claims are provided in power units of Watts, the power consumption should be multiplied by the time the product spends in each mode in order to calculate energy usage. The total product energy usage is the sum of each mode's energy usage.

## European Community (EC) directives conformity

This product is in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC and 2009/125/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and the ecodesign of energy-related products.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium

Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class B limits of EN 55022 and safety requirements of EN 60950.

## Regulatory notices for wireless products

This section contains the following regulatory information pertaining to wireless products that contain transmitters, for example, but not limited to, wireless network cards or proximity card readers.

## Exposure to radio frequency radiation

The radiated output power of this device is far below the radio frequency exposure limits of the FCC and other regulatory agencies. A minimum separation of 20 cm (8 inches) must be maintained between the antenna and any persons for this device to satisfy the RF exposure requirements of the FCC and other regulatory agencies.

## Industry Canada (Canada)

This device complies with Industry Canada specification RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate only with the antenna provided. Use of any other antenna is strictly prohibited per regulations of Industry Canada.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF fields in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site www.hc-sc.gc.ca/rpb.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

### Industry Canada (Canada)

Cet appareil est conforme à la norme RSS-210 d'Industry Canada. Son fonctionnement est soumis aux deux conditions suivantes :

(1) cet appareil ne doit pas provoquer d'interférences et (2) il doit accepter toute interférence reçue, y compris celles risquant d'altérer son fonctionnement.

Cet appareil a été conçu pour fonctionner uniquement avec l'antenne fournie. L'utilisation de toute autre antenne est strictement interdite par la réglementation d'Industry Canada.

En application des réglementations d'Industry Canada, l'utilisation d'une antenne de gain supérieur est strictement interdite.

Pour empêcher toute interférence radio au service faisant l'objet d'une licence, cet appareil doit être utilisé à l'intérieur et loin des fenêtres afin de garantir une protection optimale.

Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

L'installateur de cet équipement radio doit veiller à ce que l'antenne soit implantée et dirigée de manière à n'émettre aucun champ HF dépassant les limites fixées pour l'ensemble de la population par Santé Canada. Reportez-vous au Code de sécurité 6 que vous pouvez consulter sur le site Web de Santé Canada www.hc-sc.gc.ca/rpb.

Le terme « IC » précédant le numéro de d'accréditation/inscription signifie simplement que le produit est conforme aux spécifications techniques d'Industry Canada.

## Notice to users in the European Union

This product is in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, 1999/5/EC, and 2009/125/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits, radio equipment and telecommunications terminal equipment and on the ecodesign of energy-related products.

Compliance is indicated by the CE marking.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class B limits of EN 55022 and safety requirements of EN 60950.

Products equipped with 2.4GHz Wireless LAN option are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, 1999/5/EC, and 2009/125/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment and on the ecodesign of energy-related products.

Compliance is indicated by the CE marking.

Operation is allowed in all EU and EFTA countries, but is restricted to indoor use only.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product may be used in the countries indicated in the table below.

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| AT | BE | BG | CH | CY | CZ | DE | DK | EE |
| EL | ES | FI | FR | HR | HU | IE | IS | IT |
| LI | LT | LU | LV | MT | NL | NO | PL | PT |
| RO | SE | SI | SK | TR | UK | | | |

| | |
|---|---|
| Česky | Společnost Lexmark International, Inc. tímto prohlašuje, že výrobek tento výrobek je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES. |
| Dansk | Lexmark International, Inc. erklærer herved, at dette produkt overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF. |
| Deutsch | Hiermit erklärt Lexmark International, Inc., dass sich das Gerät dieses Gerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet. |
| Ελληνική | ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η LEXMARK INTERNATIONAL, INC. ΔΗΛΩΝΕΙ ΟΤΙ ΑΥΤΟ ΤΟ ΠΡΟΪΟΝ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ. |
| English | Hereby, Lexmark International, Inc., declares that this type of equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. |
| Español | Por medio de la presente, Lexmark International, Inc. declara que este producto cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE. |
| Eesti | Käesolevaga kinnitab Lexmark International, Inc., et seade see toode vastab direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele muudele asjakohastele sätetele. |
| Suomi | Lexmark International, Inc. vakuuttaa täten, että tämä tuote on direktiivin 1999/5/EY oleellisten vaatimusten ja muiden sitä koskevien direktiivin ehtojen mukainen. |
| Français | Par la présente, Lexmark International, Inc. déclare que l'appareil ce produit est conforme aux exigences fondamentales et autres dispositions pertinentes de la directive 1999/5/CE. |
| Magyar | Alulírott, Lexmark International, Inc. nyilatkozom, hogy a termék megfelel a vonatkozó alapvetõ követelményeknek és az 1999/5/EC irányelv egyéb elõírásainak. |
| Íslenska | Hér með lýsir Lexmark International, Inc. yfir því að þessi vara er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC. |
| Italiano | Con la presente Lexmark International, Inc. dichiara che questo questo prodotto è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE. |
| Latviski | Ar šo Lexmark International, Inc. deklarē, ka šis izstrādājums atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem. |
| Lietuvių | Šiuo Lexmark International, Inc. deklaruoja, kad šis produktas atitinka esminius reikalavimus ir kitas 1999/5/EB direktyvos nuostatas. |
| Malti | Bil-preżenti, Lexmark International, Inc., jiddikjara li dan il-prodott huwa konformi mal-ħtiġijiet essenzjali u ma dispożizzjonijiet oħrajn relevanti li jinsabu fid-Direttiva 1999/5/KE. |
| Nederlands | Hierbij verklaart Lexmark International, Inc. dat het toestel dit product in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG. |
| Norsk | Lexmark International, Inc. erklærer herved at dette produktet er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF. |
| Polski | Niniejszym Lexmark International, Inc. oświadcza, że niniejszy produkt jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC. |
| Português | A Lexmark International Inc. declara que este este produto está conforme com os requisitos essenciais e outras disposições da Diretiva 1999/5/CE. |
| Slovensky | Lexmark International, Inc. týmto vyhlasuje, že tento produkt spĺňa základné požiadavky a všetky príslušné ustanovenia smernice 1999/5/ES. |

| | |
|---|---|
| Slovensko | Lexmark International, Inc. izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES. |
| Svenska | Härmed intygar Lexmark International, Inc. att denna produkt står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG. |

# STATEMENT OF LIMITED WARRANTY FOR LEXMARK LASER PRINTERS, LEXMARK LED PRINTERS, AND LEXMARK MULTIFUNCTION LASER PRINTERS

### Lexmark International, Inc., Lexington, KY

This limited warranty applies to the United States and Canada. For customers outside the U.S., refer to the country-specific warranty information that came with your product.

This limited warranty applies to this product only if it was originally purchased for your use, and not for resale, from Lexmark or a Lexmark Remarketer, referred to in this statement as “Remarketer.”

### Limited warranty

Lexmark warrants that this product:

—Is manufactured from new parts, or new and serviceable used parts, which perform like new parts

—Is, during normal use, free from defects in material and workmanship

If this product does not function as warranted during the warranty period, contact a Remarketer or Lexmark for repair or replacement (at Lexmark's option).

If this product is a feature or option, this statement applies only when that feature or option is used with the product for which it was intended. To obtain warranty service, you may be required to present the feature or option with the product.

If you transfer this product to another user, warranty service under the terms of this statement is available to that user for the remainder of the warranty period. You should transfer proof of original purchase and this statement to that user.

### Limited warranty service

The warranty period starts on the date of original purchase as shown on the purchase receipt and ends 12 months later provided that the warranty period for any supplies and for any maintenance items included with the printer shall end earlier if it, or its original contents, are substantially used up, depleted, or consumed. Fuser Units, Transfer/Transport Units, Paper Feed items, if any, and any other items for which a Maintenance Kit is available are substantially consumed when the printer displays a “Life Warning” or “Scheduled Maintenance” message for such item.

To obtain warranty service you may be required to present proof of original purchase. You may be required to deliver your product to the Remarketer or Lexmark, or ship it prepaid and suitably packaged to a Lexmark designated location. You are responsible for loss of, or damage to, a product in transit to the Remarketer or the Lexmark designated location.

When warranty service involves the exchange of a product or part, the item replaced becomes the property of the Remarketer or Lexmark. The replacement may be a new or repaired item.

The replacement item assumes the remaining warranty period of the original product.

Replacement is not available to you if the product you present for exchange is defaced, altered, in need of a repair not included in warranty service, damaged beyond repair, or if the product is not free of all legal obligations, restrictions, liens, and encumbrances.

As part of your warranty service and/or replacement, Lexmark may update the firmware in your printer to the latest version. Firmware updates may modify printer settings and cause counterfeit and/or unauthorized products, supplies, parts, materials (such as toners and inks), software, or interfaces to stop working. Authorized use of genuine Lexmark products will not be impacted.

Before you present this product for warranty service, remove all print cartridges, programs, data, and removable storage media (unless directed otherwise by Lexmark).

For further explanation of your warranty alternatives and the nearest Lexmark authorized servicer in your area contact Lexmark on the World Wide Web.

Remote technical support is provided for this product throughout its warranty period. For products no longer covered by a Lexmark warranty, technical support may not be available or only be available for a fee.

### Extent of limited warranty

Lexmark does not warrant uninterrupted or error-free operation of any product or the durability or longevity of prints produced by any product.

Warranty service does not include repair of failures caused by:

—Modification or unauthorized attachments

—Accidents, misuse, abuse or use inconsistent with Lexmark user's guides, manuals, instructions or guidance

—Unsuitable physical or operating environment

—Maintenance by anyone other than Lexmark or a Lexmark authorized servicer

—Operation of a product beyond the limit of its duty cycle

—Use of printing media outside of Lexmark specifications

—Refurbishment, repair, refilling or remanufacture by a third party of products, supplies or parts

—Products, supplies, parts, materials (such as toners and inks), software, or interfaces not furnished by Lexmark

**TO THE EXTENT PERMITTED BY APPLICABLE LAW, NEITHER LEXMARK NOR ITS THIRD PARTY SUPPLIERS OR REMARKETERS MAKE ANY OTHER WARRANTY OR CONDITION OF ANY KIND, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS PRODUCT, AND SPECIFICALLY DISCLAIM THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND SATISFACTORY QUALITY. ANY WARRANTIES THAT MAY NOT BE DISCLAIMED UNDER APPLICABLE LAW ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES, EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD. ALL INFORMATION, SPECIFICATIONS, PRICES, AND SERVICES ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE.**

### Limitation of liability

Your sole remedy under this limited warranty is set forth in this document. For any claim concerning performance or nonperformance of Lexmark or a Remarketer for this product under this limited warranty, you may recover actual damages up to the limit set forth in the following paragraph.

Lexmark's liability for actual damages from any cause whatsoever will be limited to the amount you paid for the product that caused the damages. This limitation of liability will not apply to claims by you for bodily injury or damage to real property or tangible personal property for which Lexmark is legally liable. **IN NO EVENT WILL LEXMARK BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, INCIDENTAL DAMAGE, OR OTHER ECONOMIC OR CONSEQUENTIAL DAMAGES.**

This is true even if you advise Lexmark or a Remarketer of the possibility of such damages. Lexmark is not liable for any claim by you based on a third party claim.

This limitation of remedies also applies to claims against any Suppliers and Remarketers of Lexmark. Lexmark's and its Suppliers' and Remarketers' limitations of remedies are not cumulative. Such Suppliers and Remarketers are intended beneficiaries of this limitation.

### Additional rights

Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations or exclusions contained above may not apply to you.

This limited warranty gives you specific legal rights. You may also have other rights that vary from state to state.

## Patent acknowledgment

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Elliptic Curve Cryptography (ECC) Cipher Suites for Transport Layer Security (TLS) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for TLS Elliptic Curve Cipher Suites with SHA-256/382 and AES Galois Counter Mode (GCM) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for TLS Suite B Profile for Transport Layer Security (TLS) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Addition of the Camellia Cipher Suites to Transport Layer Security (TLS) implemented in the product or service.

The use of certain patents in this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for AES-CCM ECC Cipher Suites for TLS implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for IKE and IKEv2 Authentication Using the Eliptic Curve Digital Signature Algorithm (ECDSA) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Suite B Cryptographic Suites for IPSec implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Algorithms for Internet Key Exchange version 1 (IKEv1) implemented in the product or service.

# Index


## A

accessing the controller board 14
Active NIC menu 65
adjusting Sleep mode 87
adjusting toner darkness 52
administrator settings
  Embedded Web Server 101
AppleTalk menu 69
assigning custom paper types 42
attaching cables 20
available internal options 14
avoiding jams 48
avoiding paper jams 105

## B

Bin full. Remove paper. 124

## C

cables
  Ethernet 20
  parallel 20
  USB 20
canceling
  print job, from computer 53
canceling a print job
  from a computer 53
  from the printer control panel 53
Cannot collate large document [37] 119
Cannot defrag flash memory [37] 119
cannot open Embedded Web Server 153
card stock
  loading, multipurpose feeder 37
  tips 46
Cartridge low [88.xy] 116
Cartridge nearly low [88.xy] 116
Cartridge very low, [x] estimated pages remain [88.xy] 116
Cartridge, imaging unit mismatch [41.xy] 116
Change [paper source] to [custom string]. Load [orientation]. 117
Change [paper source] to [custom type name]. Load [orientation]. 117
Change [paper source] to [paper size]. Load [orientation]. 117
Change [paper source] to [paper type] [paper size]. Load [orientation]. 117
checking an unresponsive printer 125
checking the status of parts and supplies 92
checking the virtual display
  using the Embedded Web Server 101
cleaning
  exterior of the printer 92
cleaning the printer 92
Close front door 117
Complex page may misprint [39] 118
confidential data
  information on securing 91
confidential jobs
  modifying print settings 102
configuration information
  wireless network 26
configurations
  printer 9
Configure MP menu 59
configuring
  multiple printers 103
  supply notifications, imaging unit 101
  supply notifications, toner cartridge 101
configuring custom paper types 41
configuring supply notifications 101
connecting to a wireless network
  using Personal Identification Number (PIN) method 27
  using Push Button Configuration (PBC) method 27
  using the Embedded Web Server 29
conservation settings
  conserving supplies 85
  Eco-Mode 86
  Hibernate mode 86
  Hibernate Timeout 88
  Schedule Power Modes 88
  Sleep mode 87
conserving supplies 85
contacting customer support 154
control panel, printer
  buttons 11
  indicator light 11, 12
  Sleep button light 12
  using 11
controller board
  accessing 14
creating the printer control panel PIN 103
Custom Name [x] name
  configuring 41
custom paper type
  assigning 42
  configuring 41
custom paper type name
  configuring 41
Custom Types menu 63

## D

Default Source menu 55
Defective flash memory [51] 118
display troubleshooting
  printer display is blank 127
documents, printing
  from Macintosh 52
  from Windows 52

## E

Eco-Mode setting 86
Embedded Web Server
  accessing 12
  administrator settings 101
  copying settings to other printers 103
  functions 12
  modifying confidential print settings 102
  networking settings 101
  problem accessing 153
  using 12
Embedded Web Server Administrator's Guide
  where to find 91, 101
emission
notices 156, 157, 160, 161, 162

envelopes
loading, multipurpose feeder 37
tips on using 47
environmental settings
conserving supplies 85
Eco-Mode 86
Hibernate mode 86
Hibernate Timeout 88
Schedule Power Modes 88
Sleep mode 87
erasing non-volatile memory 91
erasing volatile memory 91
Ethernet network
preparing to set up for Ethernet printing 24
Ethernet network setup
using Macintosh 24
using Windows 24
Ethernet networking
Macintosh 24
Windows 24
Ethernet port 20
Ethernet setup
preparing for an 24
exterior of the printer
cleaning 92

## F

factory defaults, restoring 103
FCC notices 156, 161
finding more information about the printer 7
Finishing menu 79
Flash memory full [52] 122
Flash memory unformatted [53] 125
font sample list, printing 53

## G

General Settings menu 74
green settings
Eco-Mode 86
Hibernate mode 86
Hibernate Timeout 88
Schedule Power Modes 88

## H

Hibernate mode
using 86
Hibernate Timeout
setting 88

## I

imaging unit
ordering 95
replacing 97
Imaging unit low [84.xy] 117
Imaging unit nearly low [84.xy] 116
Imaging unit very low, [x] estimated pages remain [84.xy] 116
Insert tray [x] 118
installing
optional tray 19
installing an optional card 17
installing optional tray 19
installing printer on a network
Ethernet networking 24
installing printer software
adding options 22
installing printer software (Windows) 21
installing software
Local Printer Settings Utility 22
IPv6 menu 68

## J

Jam, front door [20y.xx] 108
Jam, MP feeder [250.xx] 115
Jam, pull tray 1. Push down blue flap. [23y.xx] 113
Jam, rear door [20y.xx] 111
Jam, standard bin [20y.xx] 112
Jam, tray [x] [24y.xx] 114
jams
accessing 106
avoiding 105
understanding messages 106
jams, clearing
behind front door 108
behind rear door 111
in duplex area 113
in standard bin 112
in Tray 1 114
in Tray 2 114
Multipurpose feeder 115

## L

labels, paper
tips on using 47
letterhead
loading, multipurpose feeder 37
tips on using 48
linking trays 40
Load [paper source] with [custom string] [orientation] 119
Load [paper source] with [custom type name] [orientation] 119
Load [paper source] with [paper size] [orientation] 120
Load [paper source] with [paper type] [paper size] [orientation] 120
Load MP feeder with [custom string] [orientation] 120
Load MP feeder with [custom type name] [orientation] 120
Load MP feeder with [paper size] [orientation] 121
Load MP feeder with [paper type] [paper size] [orientation] 121
loading
multipurpose feeder 37
trays 32
loading the optional tray 32
loading the standard tray 32
Local Printer Settings Utility
installing 22
using 13
lock, security 90

## M

memory
types installed on printer 90
memory card
installing 15
troubleshooting 129
Memory full [38] 121
Memory low, no Resource Save [35] 118
menu settings
loading on multiple printers 103
menu settings page
printing 29
menus
Active NIC 65
AppleTalk 69
Configure MP 59
Custom Types 63
Default Source 55
Finishing 79
General Settings 74
in Local Printer Settings Utility 13
IPv6 68
list of 55
Network [x] 65
Network Card 67

Network Reports 66
Paper Loading 62
Paper Size/Type 56
Paper Texture 59
Paper Weight 61
PCL Emul 82
PostScript 82
Quality 80
Reports 64
Security Audit Log 72
Set Date and Time 73
Setup 77
SMTP Setup menu 71
Standard Network 65
Standard USB 70
Substitute Size 59
TCP/IP 67
Universal Setup 64
Utilities 81
Wireless 69
XPS 82
menus list 55
moving the printer 8, 99, 100
multipurpose feeder
loading 37

## N

Network [x] menu 65
Network Card menu 67
Network error, port [x] [54] 122
Network error, standard port [54] 124
Network Reports menu 66
network settings
Embedded Web Server 101
network setup page
printing 30
Networking Guide
where to find 101
noise emission levels 157
Non-Lexmark [supply type], see User's Guide [33.xy] 121
non-volatile memory 90
erasing 91
notices 156, 157, 158, 159, 160, 161, 162
number of remaining pages
estimate 93

## O

optional card
installing 17
optional tray
installing 19
loading 32
options
memory card 15
memory cards 14
updating in printer driver 22
ordering
imaging unit 95
ordering supplies
toner cartridges 93

## P

paper
characteristics 43
letterhead 44
loading, multipurpose feeder 37
preprinted forms 44
recycled 45, 85
selecting 44
storing 48
unacceptable 44, 45
Universal size setting 31
paper feed troubleshooting
message remains after jam is cleared 130
paper jams
avoiding 105
paper jams, clearing
behind front door 108
behind rear door 111
in duplex area 113
in standard bin 112
in Tray 1 114
in Tray 2 114
Multipurpose feeder 115
paper labels
loading, multipurpose feeder 37
Paper Loading menu 62
paper messages
Jam, pull tray 1. Push down blue flap. [23y.xx] 113
paper size
setting 31
Paper Size/Type menu 56
paper sizes
supported by the printer 49
paper stop, using 32
Paper Texture menu 59
Paper too short [34] 118
paper type
setting 31
paper types
duplex support 50
supported by printer 50
where to load 50
Paper Weight menu 61
parallel port 20
Parallel port disabled [56] 124
parts
checking status 92
using genuine Lexmark 93
PCL Emul menu 82
Personal Identification Number method
using 27
PostScript menu 82
preparing to set up the printer on an Ethernet network 24
print irregularities 142
print job
canceling from the printer control panel 53
canceling, from computer 53
print quality troubleshooting
blank pages 136
characters have jagged edges 136
clipped pages or images 137
gray background on prints 139
horizontal voids appear on prints 150
print irregularities 142
print is too dark 143
print is too light 145
printer is printing solid black pages 147
repeating print defects appear on prints 143
shadow images appear on prints 138
skewed print 146
streaked horizontal lines appear on prints 148
streaked vertical lines 149
toner rubs off 152
toner specks appear on prints 152
transparency print quality is poor 147
uneven print density 152
white streaks 151

print troubleshooting
  incorrect characters print 134
  incorrect margins on prints 140
  jammed pages are not reprinted 131
  job prints from wrong tray 133
  job prints on wrong paper 133
  jobs do not print 131
  Large jobs do not collate 135
  paper curl 141
  paper frequently jams 130
  print job takes longer than expected 133
  printing slows down 132
  tray linking does not work 134
  unexpected page breaks occur 135
printer
  configurations 9
  minimum clearances 8
  moving 8, 99, 100
  selecting a location 8
  shipping 100
printer configurations
  basic model 9
  configured model 9
printer control panel
  buttons 11
  factory defaults, restoring 103
  indicator light 11, 12
  Sleep button light 12
  using 11
printer control panel PIN
  creating 103
printer control panel, virtual display
  using the Embedded Web Server 101
printer information
  where to find 7
printer is printing blank pages 136
printer messages
  Bin full. Remove paper. 124
  Cannot collate large document [37] 119
  Cannot defrag flash memory [37] 119
  Cartridge low [88.xy] 116
  Cartridge nearly low [88.xy] 116
  Cartridge very low, [x] estimated pages remain [88.xy] 116
  Cartridge, imaging unit mismatch [41.xy] 116
  Change [paper source] to [custom string]. Load [orientation]. 117
  Change [paper source] to [custom type name]. Load [orientation]. 117
  Change [paper source] to [paper size]. Load [orientation]. 117
  Change [paper source] to [paper type] [paper size]. Load [orientation]. 117
  Close front door 117
  Complex page may misprint [39] 118
  Defective flash memory [51] 118
  Flash memory full [52] 122
  Flash memory unformatted [53] 125
  Imaging unit low [84.xy] 117
  Imaging unit nearly low [84.xy] 116
  Imaging unit very low, [x] estimated pages remain [84.xy] 116
  Insert tray [x] 118
  Jam, front door [20y.xx] 108
  Jam, MP feeder [250.xx] 115
  Jam, rear door [20y.xx] 111
  Jam, standard bin [20y.xx] 112
  Jam, tray [x] [24y.xx] 114
  Load [paper source] with [custom string] [orientation] 119
  Load [paper source] with [custom type name] [orientation] 119
  Load [paper source] with [paper size] [orientation] 120
  Load [paper source] with [paper type] [paper size] [orientation] 120
  Load MP feeder with [custom string] [orientation] 120
  Load MP feeder with [custom type name] [orientation] 120
  Load MP feeder with [paper size] [orientation] 121
  Load MP feeder with [paper type] [paper size] [orientation] 121
  Memory full [38] 121
  Memory low, no Resource Save [35] 118
  Network error, port [x] [54] 122
  Network error, standard port [54] 124
  Non-Lexmark [supply type], see User's Guide [33.xy] 121
  Paper too short [34] 118
  Parallel port disabled [56] 124
  Printer restart. Check last job. 122
  Rear USB port disabled [56] 124
  Reinstall missing or unresponsive cartridge [31.xy] 123
  Reinstall missing or unresponsive imaging unit [31.xy] 123
  Replace cartridge, 0 estimated pages remain [88.xy] 122
  Replace cartridge, printer region mismatch [42.xy] 122
  Replace imaging unit, 0 estimated pages remain [84.xy] 123
  Replace unsupported cartridge [32.xy] 124
  Replace unsupported imaging unit [32.xy] 124
  Too many trays. Remove some. [58] 125
printer options troubleshooting
  internal option is not detected 127
  memory card 129
  tray problems 128
printer problems, solving basic 125
Printer restart. Check last job. 122
printer security
  information on 91
printer software, installing (Windows) 21
printing
  font sample list 53
  from Macintosh 52
  from Windows 52
  menu settings page 29
  network setup page 30
printing a document 52
publications
  where to find 7
Push Button Configuration method
  using 27

## Q

Quality menu 80

## R

Rear USB port disabled [56] 124
recycled paper
  using 45, 85
recycling
  Lexmark packaging 89
  Lexmark products 89
  toner cartridges 89
Reinstall missing or unresponsive cartridge [31.xy] 123
Reinstall missing or unresponsive imaging unit [31.xy] 123
repeating print defects appear on prints 143
Replace cartridge, 0 estimated pages remain [88.xy] 122
Replace cartridge, printer region mismatch [42.xy] 122
Replace imaging unit, 0 estimated pages remain [84.xy] 123
Replace unsupported cartridge [32.xy] 124
Replace unsupported imaging unit [32.xy] 124
replacing
  imaging unit 97
  toner cartridge 96
reports
  viewing 101
Reports menu 64
restoring factory default settings 103

## S

safety information 5, 6
Schedule Power Modes
  using 88
security
  modifying confidential print settings 102
Security Audit Log menu 72
security lock 90
security Web page
  where to find 91
selecting a location for the printer 8
selecting paper 44
Set Date and Time menu 73
setting
  paper size 31
  paper type 31
  TCP/IP address 67
  Universal paper size 31
setting Hibernate Timeout 88
setting up the printer
  on an Ethernet network (Macintosh only) 24
  on an Ethernet network (Windows only) 24
Setup menu 77
shipping the printer 100
Sleep mode
  adjusting 87
SMTP Setup menu 71
standard bin, using 32
Standard Network menu 65
standard tray
  loading 32
Standard USB menu 70
statement of volatility 90
storing
  paper 48
  supplies 95
streaked horizontal lines appear on prints 148
streaked vertical lines appear on prints 149
streaks appear 151
Substitute Size menu 59
supplies
  checking status 92
  conserving 85
  storing 95
  using genuine Lexmark 93
  using recycled paper 85
supplies, ordering
  imaging unit 95
  toner cartridges 93
supply notifications
  configuring 101
supported paper sizes 49
supported paper types and weights 50

## T

TCP/IP menu 67
tips
  card stock 46
  letterhead 48
  on using envelopes 47
  on using labels 47
  transparencies 48
tips on using envelopes 47
toner cartridge
  replacing 96
toner cartridges
  ordering 93
  recycling 89
toner darkness
  adjusting 52
Too many trays. Remove some. [58] 125
transparencies
  loading, multipurpose feeder 37
  tips 48
trays
  linking 40
  loading 32
  unlinking 40
troubleshooting
  cannot open Embedded Web Server 153
  checking an unresponsive printer 125
  contacting customer support 154
  solving basic printer problems 125
troubleshooting, display
  printer display is blank 127
troubleshooting, paper feed
  message remains after jam is cleared 130
troubleshooting, print
  incorrect characters print 134
  incorrect margins on prints 140
  jammed pages are not reprinted 131
  job prints from wrong tray 133
  job prints on wrong paper 133
  jobs do not print 131
  Large jobs do not collate 135
  paper curl 141
  paper frequently jams 130
  print job takes longer than expected 133
  printing slows down 132
  tray linking does not work 134
  unexpected page breaks occur 135
troubleshooting, print quality
  blank pages 136
  characters have jagged edges 136
  clipped pages or images 137
  gray background on prints 139

horizontal voids appear on prints 150
print irregularities 142
print is too dark 143
print is too light 145
printer is printing solid black pages 147
repeating print defects appear on prints 143
shadow images appear on prints 138
skewed print 146
streaked horizontal lines appear on prints 148
streaked vertical lines 149
toner rubs off 152
toner specks appear on prints 152
transparency print quality is poor 147
uneven print density 152
white streaks on a page 151
troubleshooting, printer options
internal option is not detected 127
memory card 129
tray problems 128

## U

unacceptable paper 44
uneven print density 152
Universal paper size
setting 31
Universal Setup menu 64
unlinking trays 40
updating options in printer
driver 22
USB port 20
using
Wireless Setup Assistant 28
Wireless Setup Utility 27
using Hibernate mode 86
using Schedule Power Modes 88
using the Embedded Web
Server 12
Utilities menu 81

## V

vertical voids appear 151
viewing
reports 101
virtual display
checking, using Embedded Web Server 101
voids appear 151
volatile memory 90
erasing 91
volatility
statement of 90

## W

Wireless menu 69
wireless network
configuration information 26
wireless network setup
using the Embedded Web Server 29
Wireless Setup Assistant
using 28
Wireless Setup Utility
using 27

## X

XPS menu 82